


iDimension[®] CLS Bridge

PC Software

Software Manual



© Rice Lake Weighing Systems. All rights reserved.

Rice Lake Weighing Systems® is a registered trademark of
Rice Lake Weighing Systems.

All other brand or product names within this publication are trademarks or
registered trademarks of their respective companies.

All information contained within this publication is, to the best of our knowledge, complete and
accurate at the time of publication. Rice Lake Weighing Systems reserves the right to make
changes to the technology, features, specifications and design of the equipment without notice.

The most current version of this publication, software, firmware and all other product
updates can be found on our website:

www.ricelake.com

Revision History

This section tracks and describes manual revisions for awareness of major updates.

Revision	Date	Description
A	December 18, 2023	Initial manual release with product launch; Software version 1.0.0.0
B	March 22, 2024	Added language configuration; Menu updates; Software version 1.1.0.0
C	December 27, 2024	Added manual dimensioning configuration and operation; Software version 1.2.0.0
D	April 4, 2025	Updated screenshots and home configuration parameters; added operation mode features; Software version 1.3.0.0

Table i. Revision Letter History



Technical training seminars are available through Rice Lake Weighing Systems. Course descriptions and dates can be viewed at www.ricelake.com/training or obtained by calling 715-234-9171 and asking for the training department.

Contents

1.0	Introduction	5
1.1	System Requirements	5
2.0	Installation and Software Access	6
2.1	iDim CLS Bridge Installation	6
3.0	Basic iDim CLS Bridge Functions	7
3.1	Launch iDim CLS Bridge Software	7
3.2	Language Configuration	8
4.0	iDim CLS Bridge Elements	9
4.1	Main View Elements	9
4.2	Settings Menu	11
4.2.1	Access Settings Menu	11
4.2.2	Settings Menu Elements	12
4.3	About Window	13
4.3.1	Access About Window	13
4.3.2	About Elements	14
5.0	Configuration	15
5.1	Default Language Configuration	15
5.2	Home View Configuration	16
5.3	Barcode Scanner Settings Configuration	18
5.4	iDimSS Integration Configuration	19
5.4.1	Add a iDimSS Integration	19
5.4.2	Edit a Dimensioner	20
5.4.3	Delete a Dimensioner	21
5.5	Forklift Settings Configuration	22
5.6	Dini Argeo LTP Scale Settings Configuration	22
5.7	CLS-680 Scale Settings Configuration	23
5.8	VIRTUi3 Configuration	24
5.8.1	VIRTUi3 Scale Settings	24
5.8.2	VIRTUi3 Viewer Settings	24
6.0	Operation	25
6.1	Using a Dimensioner	25
6.2	Using Manual Dimensioning Functions	26
7.0	Error Messages	29
7.1	Application Error Message	29
7.2	Capture Result Errors	30



Rice Lake continually offers web-based video training on a growing selection of product-related topics at no cost. Visit www.ricelake.com/webinars

1.0 Introduction

This manual provides an overview of the iDim (iDimension®) CLS Bridge software installation and configuration procedures. The iDim CLS Bridge software interfaces the industrial PC it is installed on with a scale (CLS-680 indicator, Dini Argeo® LTP indicator or VIRTUi³®) and the iDimSS (iDimension Software Suite).



Manuals are available from Rice Lake Weighing Systems at www.ricelake.com/manuals

Warranty information is available at www.ricelake.com/warranties



IMPORTANT: Read and adhere to all safety instructions and warnings from forklift and indicator manufacturers.

1.1 System Requirements

- Windows 10® build 1607 or newer (64 bit only) or equivalent Windows® Server Operating System
- 2.0 GHz processor or faster
- 250 MB drive space needed for install. Additional space will vary based on data retention requirements.
- 8 GB ram or greater
- Ethernet TCP/IP connection for equipment and external system integration
- 802.11 ac/a/b/g/n Wi-Fi or greater for external data communication
- Touchscreen display (suggested)
- iDimSS Version 2.22 or greater running on external PC
- If using a scale, one of the following: VIRTUi³, CLS-680, or Dini Argeo LTP scale

2.0 Installation and Software Access

2.1 iDim CLS Bridge Installation

1. Download the iDim CLS Bridge software from <https://www.ricelake.com/software>.
2. Unzip the file and then launch **IDim_CLS_Bridge_PN220981.Installer.exe**.
3. Read the Rice Lake Weighing Systems License Agreement. Enable the check box if the terms are acceptable.




Figure 2-1. iDim CLS Bridge Installation Window

4. (Optional) Perform the following to change the installation location:
 - Select **Options** and then **Browse** to install iDimSS CLS Bridge in a user specified file location.
 - Select **OK** to return to the previous window.




Figure 2-2. iDim CLS Bridge Installation Options

5. Select **Install**.
6. The Installation Successfully Completed window displays, select **Close**. The iDim CLS Bridge is successfully installed.





Figure 2-3. iDim CLS Bridge Complete Installation Window

3.0 Basic iDim CLS Bridge Functions

3.1 Launch iDim CLS Bridge Software

1. In the Windows Start menu, open the **Rice Lake Weighing Systems** folder.
2. Select  **iDim CLS Bridge**.
3. The application displays.




Figure 3-1. iDim CLS Bridge

3.2 Language Configuration

1. Navigate to the main view.
2. Select the flag that corresponds to the desired language.




Figure 3-2. iDim CLS Bridge Language Selection

3. The language in the application changes.




Figure 3-3. New Language Selected in iDim CLS Bridge

4.0 iDim CLS Bridge Elements

This section discusses iDim CLS Bridge software elements. Topics in this section include:

- Main View Elements ([Section 4.1 on page 9](#))
- Settings Menu ([Section 4.2 on page 11](#))
- About Window ([Section 4.3 on page 13](#))

4.1 Main View Elements

The main view displays when the software is launched and provides several elements that facilitate operation. Each element is identified in [Figure 4-1](#).




Figure 4-1. Main View Elements

Item	Function	Description
A	virtui	Launches VIRTUI ³ software if installed and configured in iDim CLS Bridge (see Section 5.8 on page 24).
B	settings	Opens the Settings menu (see Section 4.2 on page 11). NOTE: The Settings menu can only be accessed when the iDim CLS Bridge software is run as an administrator.
C	about	Opens the About window (see Section 4.3 on page 13).
D	Weight	Displays weight and unit of measure.
E	Pro Number/Container ID	Configures the Pro Number or a container ID with the integrated keypad or optional barcode scanner (see Section 6.0 on page 25).
F	Eraser Button	Erases data from the Pro Number/Container ID field.
G	Select Dimensioner	Selects which dimensioner will be used. NOTE: The software automatically selects the first name in the drop-down menu when the application launches.
H	Dims and Weight	Processes the object's dimensions and weight.
I	Dimensions Only	Processes the object's dimensions.
J	Weight Only	Processes the object's weight.
K	Weight Hold	Puts captured weight value in Captured Weight section
L	Operation Mode	Allows user to toggle between Drop and Clear and Stop and Go functions.
M	Zero	Zeros scale if supported by indicator type.
N	Tare	Tares scale if supported by indicator type.
O	Captured Weight	Displays captured weight value.

Table 4-1. Main View Elements Descriptions

Item	Function	Description
P	QR code	Displays a QR Code containing data received from iDimSS. NOTE: The QR code is configured in the iDimSS. See iDimension Software Suite Software Manual (PN 201231) for more information.
Q	Languages	Changes the language of the user interface <ul style="list-style-type: none"> • See Section 3.2 on page 8 for quick change configuration. • See Section 5.1 on page 15 for default language configuration.

Table 4-1. Main View Elements Descriptions



NOTE: Alibi compatibility is embedded in the software. There are no software parameters to modify this feature.

4.2 Settings Menu

4.2.1 Access Settings Menu

1. From the main view, select **settings**.



NOTE: Administrator privileges are required to access the Settings menu. To run the CLS Bridge software with administrator permissions in Windows 11, right click the application and select “Run as administrator”.




Figure 4-2. Main View settings Button

2. The Settings menu appears.




Figure 4-3. Settings Menu

4.2.2 Settings Menu Elements

Settings Menu contains several elements launch additional menus that facilitate configuration. Each element is identified in Figure 4-4.




Figure 4-4. Settings Menu with Elements Identified

Item	Function	Description
A	Languages	Opens Language Settings (see Section 5.1 on page 15)
B	Forklift	Opens Forklift Settings (see Section 5.5 on page 22)
C	VIRTUI3 Viewer	Opens VIRTUI3 Viewer (see Section 5.8.2 on page 24)
D	Home View	Opens Home View Settings (see Section 5.2 on page 16)
E	Dini Scale	Opens Dini Scale Settings (see Section 5.6 on page 22)
F	Barcode Scanner	Opens Barcode Scanner Settings (see Section 5.1 on page 15)
G	CLS-680 Scale	Opens CLS-680 Settings (see Section 5.7 on page 23)
H	iDimSS Integration	Opens iDimSS Integration Settings (see Section 5.4 on page 19)
I	VIRTUI3 Scale	Opens VIRTUI3 Scale Settings (see Section 5.8.1 on page 24)

Table 4-2. Settings Menu Element Descriptions

4.3 About Window

4.3.1 Access About Window

1. Navigate to the main view.
2. Select **about**.




Figure 4-5. Main View about Button

3. The About window slides out from the right side.




Figure 4-6. About Window

4.3.2 About Elements

The About window contains several elements that provide supplemental information about the software. Each element is identified in [Figure 4-7](#).




Figure 4-7. About Window with Elements Identified

Item	Function	Description
A	Product	Displays the product name
B	Version	Displays the software version number
C	Build Date	Displays when the software was released
D	Copyright	Displays copyright information
E	Company	Displays developer company name
F	Details	Displays name and part number of the software
G	iDimSS Requirements	Displays iDimSS version requirements

Table 4-3. About Window Element Descriptions

5.0 Configuration

This section discusses how to configure settings. In order for the iDim CLS Bridge to operate, ensure iDimSS, Forklift and Scale settings are configured.



NOTE: The Settings menu contains multiple scale settings menus (VIRTU³, CLS-680, or Dini Argeo LTP scale), only settings for the scale installed on the forklift must be configured.

The following topics are discussed in this section:

- Default Language Configuration (see [Section 5.1](#))
- Home View Configuration (see [Section 5.2 on page 16](#))
- iDimSS Integration Configuration (see [Section 5.4 on page 19](#))
- Forklift Settings Configuration (see [Section 5.5 on page 22](#))
- Dini Argeo LTP Scale Settings Configuration (see [Section 5.6 on page 22](#))
- CLS-680 Scale Settings Configuration (see [Section 5.7 on page 23](#))
- VIRTU³ Configuration (see [Section 5.7 on page 23](#))

5.1 Default Language Configuration

1. Navigate to Language Settings
2. Select the Default Language drop-down menu.
3. Select the default language.
4. Select **Save** to commit the changes or select **Cancel** to abort.




Figure 5-1. iDim CLS Bridge Default Language Selection



NOTE: The language changes only on the application screen.




Figure 5-2. New Language Selected in iDim CLS Bridge

5.2 Home View Configuration

1. Navigate to Home View Settings.
2. Configure the following parameters:
 - **Dim and Weight Button Enabled:** Check the box to enable the Dim and Weight Button function.
 - **Dim Only Button Enabled:** Check the box to enable the Dim Only Button function.
 - **Weight Only Button Enabled:** Check the box to enable the Weight Only Button function.
 - **Select Capture Results Display Method:** Choose between the following display options.
 - **As Text:** Shows weight results as numerical data. (see [Section Figure 5-4. on page 17](#))
 - **As Thumbs Up/Down:** Shows weight results as a thumbs up or down icon (see [Section Figure 5-5. on page 17](#))
 - **Default Operation Mode:** Choose between the following default operation modes:
 - **Drop and Clear:** Enable if dropping freight under the dimensioner and backing out the forklift
 - **Stop and Go:** Enable if keeping freight on the forklift during dimensioning
 - **Operation Mode Toggle is Transient:** Check the box to enable the temporary selection of a Mode of Operation. When enabled, the Mode of Operation returns to its default setting after a transaction.




Figure 5-3. Home View Settings

3. Select **Save** to commit the changes or select **Cancel** to abort.




Figure 5-4. Weight Results as Numerical Data




Figure 5-5. Weight Results as Thumbs Up/Down

5.3 Barcode Scanner Settings Configuration



NOTE: A barcode scanner is optional and configuration may not apply to all systems.

1. Navigate to Barcode Scanner Settings.
2. Activate the Enabled check box.
3. Set the **Connection type** as either **TCP/IP** or **RS232**.
4. Perform one of the following:
 - A. If using TCP/IP, configure the **Listening Port** as the TCP Port number used by the application to listen for incoming TCP/IP data from the barcode scanner.
 - B. If using RS232, configure the following:
 - **Serial Port:** Set the communication port number on the PC the barcode scanner is connected to.
 - **Baud Rate:** Set the baud rate of the serial port (1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200).
 - **Data Bits:** Set data bits of the serial port (7 or 8).
 - **Parity:** Set the parity of the serial port (none, odd, even, mark or space).
 - **Stop Bits:** Set the number of stop bits transmitted or received by the port (none, one, two, onepointfive).

Barcode Scanner Settings

Enabled:

Connection Type: TCP/IP

Listening Port: 39171

Serial Port:

Baud Rate: 9600

Data Bits: 8

Parity: None

Stop Bits: One

Changing these settings will require a restart of the application for the changes to take effect.

Save Cancel

Figure 5-6. Barcode Scanner Settings

5. Select **Save** to commit the changes or select **Cancel** to abort.

5.4 iDimSS Integration Configuration

5.4.1 Add a iDimSS Integration

1. Navigate to iDimSS Integration.
2. Select **Add**.




Figure 5-7. Edit iDimSS Integration Add Button

3. The Edit iDimSS Integration window displays.
4. Configure the following parameters:
 - **Enabled:** Enable this check box to display the dimensioner in the Select Dimensioner drop-down menu (see [Figure 4-2 on page 11](#)) in the main view.
 - **Manual Entry:** Enable this check box to allow for manual dimensioning.
 - **Dimensioner Name:** Add the exact name of the dimensioner that is configured in iDimSS.
 - **IP Address:** Enter the IP address of the computer running iDimSS. The IP address can be configured as the same value for multiple dimensioners setup in the iDimSS.
 - **Port:** Enter the listening port used by the computer running iDimSS (the default port for iDimSS is 5001).
5. Select **Save** to commit the changes or select **Cancel** to abort.




Figure 5-8. Edit iDimSS Integration Configured

6. If **Save** is selected, the new dimensioner is added to iDimSS Integration.




Figure 5-9. Edit iDimSS Integration Configured

5.4.2 Edit a Dimensioner

1. Navigate to **iDimSS Integration**.
2. Select **Edit** to change a configured iDimSS integration.




Figure 5-10. Edit iDimSS Integration Edit Button

3. The Edit iDimSS Integration window displays.
4. Edit parameters as required (see [Section 5.4.1 on page 19](#) for parameter descriptions).
5. Select **Save** to commit the changes or select **Cancel** to abort.




Figure 5-11. Edit iDimSS Integration

6. If **Save** is selected, the changes to the dimensioner's configuration are saved.




Figure 5-12. Edit iDimSS Integration Configured

5.4.3 Delete a Dimensioner

1. Navigate to **iDimSS Integration**.
2. Select **Delete** adjacent to the iDimSS integration to be removed.




Figure 5-13. iDimSS Integration Delete Button

3. A delete confirmation window appears.
4. Select **Yes** to delete or **No** to cancel.




Figure 5-14. iDimSS Integration Delete Confirmation

5. If **Yes** is selected, the iDimSS Integration is removed.




Figure 5-15. iDimSS Entry Removed

5.5 Forklift Settings Configuration

1. Navigate to Forklift Settings.
2. Configure the following parameters:
 - **Forklift Id:** Set the forklift Id that is used to identify the forklift in iDimSS. This enables dimensioner Stop and Go functionality.



NOTE: If the selected dimensioner does not support Stop and Go functionality, avoid configuring this field. Configuring this parameter for dimensioners incompatible with Stop and Go causes the capture operation to function incorrectly.

- **Indicator Type:** Set the type of indicator used on the forklift as either VIUTUi3, Dini LTP, CLS-680 or None. This configuration must match the type of installed hardware to receive weight information.
3. Select **Save** to commit the changes or select **Cancel** to abort.

Figure 5-16. Forklift Settings

4. If **Save** is selected, the configuration settings are saved.

5.6 Dini Argeo LTP Scale Settings Configuration



NOTE: The Dini Argeo LTP scale requires the Alibi memory module to be installed to function correctly with iDim CLS Bridge.

1. Navigate to Dini LTP Scale Settings.
2. Configure the following parameters:
 - **Serial Port:** Set the communication port number on the PC the Dini Argeo LTP scale is connected to.
 - **Baud Rate:** Set the baud rate of the serial port (9600, 19200, 38400, 57600, or 115200).
 - **Data Bits:** Set data bits of the serial port (7 or 8).
 - **Parity:** Set the parity of the serial port (none, odd, even, mark or space).
 - **Stop Bits:** Set the number of stop bits transmitted or received by the port (none, one, two, onepointfive).
3. Select **Save** to commit the changes or select **Cancel** to abort.

Figure 5-17. Dini LTP Scale Settings

4. If **Save** is selected, the configuration settings are saved.

5.7 CLS-680 Scale Settings Configuration

1. Navigate to CLS-680 Scale Settings.
2. Set the **Connection type** as either **TCP** or **RS232**.
3. Perform one of the following:
 - A. If using TCP, configure the following:
 - **IP Address:** Set as the IP address of the CLS-680 scale.
 - **Port:** Set as the port of the CLS-680 scale.
 - B. If using RS232, configure the following:
 - **Serial Port:** Set the communication port number on the PC the CLS-680 scale is connected to.
 - **Baud Rate:** Set the baud rate of the serial port (9600, 19200, 38400, 57600, or 115200).
 - **Data Bits:** Set data bits of the serial port (7 or 8).
 - **Parity:** Set the parity of the serial port (none, odd, even, mark or space).
 - **Stop Bits:** Set the number of stop bits transmitted or received by the port (none, one, two, onepointfive).
4. Select **Save** to commit the changes or select **Cancel** to abort.

CLS-680 Scale Settings

Connection Type: TCP

IP Address: 192.168.1.145

Port: 10001

Serial Port: COM3

Baud Rate: 9600

Data Bits: 8

Parity: None

Stop Bits: One

Save Cancel

Figure 5-18. CLS-680 Scale Settings

5. If **Save** is selected, the configuration settings are saved.

5.8 VIRTUi³ Configuration

5.8.1 VIRTUi³ Scale Settings

1. Navigate to VIRTUi³ Scale Settings.
2. Configure the following:
 - **IP Address:** Set as the IP address of the PC running VIRTUi³.
 - **Port:** Set as the port of the PC running VIRTUi³.
3. Select **Save** to commit the changes or select **Cancel** to abort.




Figure 5-19. VIRTUi³ Scale Settings

4. If **Save** is selected, the configuration settings are saved.

5.8.2 VIRTUi³ Viewer Settings

1. Navigate to VIRTUi³ Viewer Settings.
2. Set VIRTUi³ Path as the file path of the VIRTUi³ viewer.
3. Select **Save** to commit the changes or select **Cancel** to abort.




Figure 5-20. VIRTUi³ Viewer Settings

4. If **Save** is selected, the configuration settings are saved.

6.0 Operation

Processing a container transmits the container Id and results to iDimSS. The type of results vary depending on the acquisition function (Dims and Weight, Dimensions Only or Weight Only).



WARNING: The following procedure involves using a forklift. Before using the forklift, read and adhere to the manufacturer's safety warnings and information.

6.1 Using a Dimensioner

1. Select a dimensioner from the **Select Dimensioner** drop-down menu.




Figure 6-1. iDim CLS Bridge with Select Dimensioner Expanded

2. Select the **PRO Number/Container Id** field. A keypad adjacent to the field appears.
3. Enter a value in the **PRO Number/Container Id** field by using the keypad or optional barcode scanner.




Figure 6-2. iDim CLS Bridge with Keypad Displayed

4. Lift the container with the forklift. If using a scale, ensure a valid weight is displayed in the application.
5. Transport the object to the dimensioner and align with the dimensioning system.
6. Park the forklift.

7. Select **Dims and Weight**, **Dimensions Only** or **Weight Only** to perform data acquisition.



NOTE: Acquisition buttons are only available when the scale is stabilized.

8. Once complete, the captured data displays in the application and is sent to the iDimSS.




Figure 6-3. iDim CLS Bridge with Capture Results (Using Dimensioner)

9. Resume transporting the container.

6.2 Using Manual Dimensioning Functions

1. Select a dimensioner from the **Select Dimensioner** drop-down menu.




Figure 6-4. iDim CLS Bridge with Select Dimensioner Expanded



NOTE: Manual Dimensioning functions will not be accessible unless the Manual Entry option was checked when adding the dimensioner (See “iDimSS Integration Configuration” on page 19).

2. Select the **Units** drop-down menu and select desired unit of measure.




Figure 6-5. iDim CLS Bridge with Units Expanded

3. Enter values for **Length**, **Width** and **Height** fields.




Figure 6-6. iDim CLS Bridge with Units Entered

4. Select the **PRO Number/Container Id** field. A keypad adjacent to the field appears.
5. Enter a value in the **PRO Number/Container Id** field by using the keypad or optional barcode scanner.
6. Lift the container with the forklift to weigh.
7. Select **Dims and Weight** or **Dimensions Only** to perform data acquisition using manual dimension input.

- Once complete, the captured data displays in the application and is sent to the iDimSS.




Figure 6-7. iDim CLS Bridge with Capture Results (Manual Dimensioner)

- Resume transporting the container.

7.0 Error Messages

7.1 Application Error Message

In the event of an error, the application displays an error message. These messages provide details regarding what caused the error to occur. Read the message and attempt to resolve the issue. The following is an example when an IP Address was incorrectly set in the CLS-680 configuration.




Figure 7-1. Application Error Message Example

The application records errors in log files on the PC in the following location:

C:\ProgramData\Rice Lake Weighing Systems\IDim_CLS_Bridge_PN220981\logs\



NOTE: See Windows Help to display Hidden Folders if the ProgramData folder is missing.

The file creation date is embedded into the log filename using the format of logYYYYMMDD.JSON. Where:

YYYY = Year

MM = Month

DD = Day

JSON = JavaScript Object Notation

For example, log20231127.JSON

7.2 Capture Result Errors

The following examples display an error where capture results return err (error) messages. Frequently these messages occur when the iDimSS IP address is set incorrectly. Verify IP addresses are set correctly and retry processing.




Figure 7-2. Capture Results Error Messages Example as Text




Figure 7-3. Capture Results Error Messages Example as Thumbs Up/Down



© Rice Lake Weighing Systems Content subject to change without notice.

230 W. Coleman St. • Rice Lake, WI 54868 • USA USA: 800-472-6703 • International: +1-715-234-9171