

DC-400

Counting Scale

Operation Manual



An ISO 9001 registered company
© Rice Lake Weighing Systems. All rights reserved.

Rice Lake Weighing Systems® is a registered trademark of
Rice Lake Weighing Systems.

All other brand or product names within this publication are trademarks or
registered trademarks of their respective companies.

All information contained within this publication is, to the best of our knowledge, complete and
accurate at the time of publication. Rice Lake Weighing Systems reserves the right to make
changes to the technology, features, specifications and design of the equipment without notice.

The most current version of this publication, software, firmware and all other product
updates can be found on our website:

www.ricelake.com

Contents

1.0	Introduction	1
1.1	Safety	1
1.2	Standard Features	2
1.3	Display	2
1.4	Key Sheet Layout	3
2.0	Setup	5
2.1	Weigh Mode	5
2.2	Change Mode	5
2.3	Span Switch	5
2.4	Set Country	6
2.5	Calibration	6
2.5.1	Calibration for Scale 1 (Internal Scale)	6
2.5.2	Calibration for Scale 2	7
2.6	Set Password	8
2.6.1	Using Passwords	8
2.7	Adjustment	8
2.7.1	Span Switch Setting Display	8
2.7.2	Internal Count Display	8
2.8	Clear Files	9
3.0	Program Mode	10
3.1	Program Mode Entry	10
3.2	PLU FILE	10
3.2.1	Program Item File	11
3.2.2	Delete Item Code	12
3.2.3	Label Format List	12
3.2.4	Factory Name File	13
3.2.5	Print Factory Name Report	13
3.2.6	Delete Factory Name File	14
3.3	Program Date and Time	14
3.4	Address File	15
3.4.1	Program Address File	15
3.4.2	Print Address File	15
3.4.3	Delete Address File	16
3.5	Memory Status	16
3.6	Programming Multi Barcode Files	16
3.7	2D Barcode Text File	17
3.7.1	Deleting 2D Barcode Text Files	17
4.0	Registration Mode	18
4.1	Rezero and Weighing Check	18
4.2	Tare Subtraction	18
4.3	Item Call Up	18
4.4	Set New Item Code in Registration Mode	18
4.5	Accumulation and Subtraction	19
4.5.1	Accumulation and Subtraction	19
4.6	Unit Weight Operation	20
4.6.1	Sampling	20



Technical training seminars are available through Rice Lake Weighing Systems. Course descriptions and dates can be viewed at www.ricelake.com/training or obtained by calling 715-234-9171 and asking for the training department.

4.6.2	Numeric Key	20
4.6.3	Recomputing Unit Weight in Memory	20
4.7	Inventory Operation	20
4.7.1	Manual Transaction	21
4.7.2	Total Transaction	21
4.8	Function Key	21
4.8.1	Net/Gross Key	21
4.8.2	Switch Platform Key	22
4.8.3	Switch Weight Unit Key	22
4.8.4	View Item Key	22
4.8.5	Address No Key	23
4.8.6	Lot Number Key	23
4.8.7	Sequence Number Key	23
5.0	Report Mode	24
5.1	Report Mode Entry	24
5.2	Item Report	24
5.2.1	One Item Print	24
5.2.2	All Item Print	24
5.3	Inventory Report	25
5.3.1	Threshold Report	25
5.3.2	In/Out Count Report	25
5.4	Shelf Location	26
5.4.1	Shelf Location Print	26
6.0	Specification Setting	27
6.1	Customer Specification Settings	27
6.2	Weight and Measurement Specification Settings	39



Rice Lake continually offers web-based video training on a growing selection of product-related topics at no cost. Visit www.ricelake.com/webinars

1.0 Introduction

The DC-400 Series is capable of dealing with a wide variety of items, both large and small, through the skillful control of two sensors. From paper products to steel, the DC-400 can count almost anything.



Manuals are available for viewing and/or downloading from the Rice Lake Weighing Systems website at www.ricelake.com/manuals

Warranty information can be found on the website at www.ricelake.com/warranties

1.1 Safety

Safety Signal Definitions:



Indicates an imminently hazardous situation that, if not avoided, will result in death or serious injury. Includes hazards that are exposed when guards are removed.



Indicates a potentially hazardous situation that, if not avoided, could result in serious injury or death. Includes hazards that are exposed when guards are removed.



Indicates a potentially hazardous situation that, if not avoided, could result in minor or moderate injury.



Indicates information about procedures that, if not observed, could result in damage to equipment or corruption to and loss of data.

General Safety



Do not operate or work on this equipment unless this manual has been read and all instructions are understood. Failure to follow the instructions or heed the warnings could result in injury or death. Contact any Rice Lake Weighing Systems dealer for replacement manuals.



Failure to heed could result in serious injury or death.

Do not allow minors (children) or inexperienced persons to operate this unit.

Do not step on the unit.

Do not jump on the scale.

Do not use for purposes other than weight taking.

Do not place fingers into slots or possible pinch points.

Do not use this product if any of the components are cracked.

Do not exceed the rated specifications of the unit.

Do not make alterations or modifications to the unit.

Do not remove or obscure warning labels.

1.2 Standard Features

- Digital printing scale consists of counting function and label printing function via RS-232
- Easy paper handing achieved by a special designed mechanism
- Built-in clock automatically updates date and time
- Quick response to weight changes
- Capacity: 500g/5kg, 2.5kg/25kg
- High Resolution Display: 1/50,000, 4-interval
- Internal Resolution: 1/1,000,000
- Remote platform connector support four 350 Ohm load cells
- 202 x 32 pixels FSTN type LCD with back-light
- Integrated touch panel
- 55 switch keys
 - On/Off key
 - 10 numeric keys
 - 26 character keys
 - 18 operational keys
- Ethernet function
- RS-232C I/F for data communication and barcode scanner connection

1.3 Display




Figure 1-1. Display

Indicator	Function
→0←	Displays when zero point is adjusted and weight is stable
NET	Displays when tare subtraction is performed
SCALE 1	Displays when Scale 1 (built-in platform) is selected
SCALE 2	Displays when Scale 2 (remote platform) is selected
RECOMP	Displays when unit weight recomputing is possible
INSUFF	Displays when net weight is below a specific percentage range of the capacity weight
LABEL	Displays when label printing mode is chosen
SUM	Displays when quantity accumulation is done
IN	Displays when Inventory IN (for Counting mode)
OUT	Displays when Inventory OUT (for Counting mode)
X	Displays when in Report mode
S	Displays when in Programming mode
Z	Displays when in Service mode

Table 1-1. Display Functions

1.4 Key Sheet Layout

!	#	\$	%	&	-	()	7	8	9	UNIT WEIGHT	MODE	ON/OFF
A	B	C	D	E	F	G	H	4	5	6	CODE		* REPRINT
ID CODE	P. NAME	PART NO	LOCATE	INVENT	THHOLD	SET PT	NON-ADD	1	2	3	+	-	PIECES
*	'	@	:	:	+	-	/	0	.	CLEAR	REZERO	TARE	
I	J	K	L	M	N	O	P						
IN	OUT	SEQ NO	ADDR	NET/G	KG/LB								
SPACE	R	S	INSERT	DEL	CHAR TYPE	LETTER SZ	CHAR SZ						
Q			T	U	V	W	X						
Y	Z	LOT NO	SHIFT UP	SHIFT DOWN	SCALE	<<	>>						

Figure 1-2. Key Overview

Key	Function
	Turns display on and off
	Issue label or receipt in R mode , print out report in X mode
	Compute unit weight by sampling, escape the programming screen without saving the data in X and S mode
	Set unit weight in Registration mode
	Switch control modes
	Call up PLU data in Registration mode, store the programmed data in S mode
	Feed paper
	Add total quantity, select programming item such as item code, factory name is S mode , select Report Type in X mode
	Correct the sales data, select programming item such as Item Code, Factory Name in S mode , select Report Type in X mode
	Clear Alphanumeric Data, select "YES" in S, X and Z mode
	Reset weight display to zero
	Set or clear tare values, select "NO" in S, X and Z mode , Item test print in S mode
0-9	Input numerical value
.	Enter decimal point
A to Z	View the Preset data such as ID CODE, PART NAME in R mode , enter Alphabetic data in R mode (ID CODE) and S mode
	Switch between scale 1 and scale 2
	View the Lot Number or program new Lot Number for temporarily printing
	Select Top function or symbol of the desired key for entering

Table 1-2. Key Descriptions









Key	Function
	Select Bottom function of desired key for entering
	Move cursor LEFT
	Move cursor RIGHT
	Insert data
	Code type entered
	Switch from upper and lowercase
	Change font size

Table 1-2. Key Descriptions (Continued)

2.0 Setup

2.1 Weigh Mode

To enter **Weigh mode**:

1. Plug unit into electrical outlet.
2. Ensure power switch on bottom of scale is switched to on position.
3. The screen will display **C-RETRY** and **T-IGNORE**.
4. Press  to enter **Weigh mode**.

2.2 Change Mode

Start in **Weigh mode**.










Mode	Operation
To enter X mode	Press  twice within 3 seconds
To enter S mode	Press  again
To enter Z mode	Press  again
To enter Password Set mode	Press  again
To enter Weigh mode	Press  again

Table 2-1. Change Mode

2.3 Span Switch

To enable Span Switch:

1. Locate span switch threaded opening on the bottom of the scale.
2. Insert non-conductive tool into opening until switch is enabled.
1. To verify Span Switch is enabled enter **Z mode**.
2. Press and hold  and enter , , .
3. Unit will display **SPAN SWITCH OFF or ON**, exits after 3 seconds.



Note *Span Switch will remain enabled until unit is turned off or button is pressed again.*

2.4 Set Country

The country is set on initial use of the scale. Enter **Z mode** before setting country. Span Switch must be enabled to set country.

















Operation	Function
Press and hold  and press  ,  ,  , 	To enter Country Setting mode
Press  or 	Select country
Press 	Update country setting
Press  or  to skip this step	Load default SPEC setting
Press 	Change scale type
Press 	Update scale setting
Press 	Select capacity
Press 	Update capacity
Press  or  to skip this step	Clear Memory

Table 2-2. Set Country

2.5 Calibration

Span Switch must be enabled. Enter **Z mode** before calibrating.

2.5.1 Calibration for Scale 1 (Internal Scale)












Operation	Function
Press and hold  while pressing  ,  ,  , 	Enter Calibration
Press 	Ready to calibrate zero point
Confirm no weight is on scale, press 	Calibrating zero point
Put weight on scale, press 	Calibrating Span Point 1
Take weight off scale	Scale is ready for second weight
Place a second weight on scale, press 	Calibrating Span Point 2
Take second weight off scale	Scale is ready for third weight
Place a third weight on scale, press 	Calibrating Span Point 3
Take third weight off scale	Scale is ready for fourth weight
Place fourth weight on scale, press 	Calibrating Span Point 4
Take weight off scale	Return to Z mode

Table 2-3. Calibration for Scale 1

2.5.2 Calibration for Scale 2





















Operation	Function
Press and hold  while pressing  ,  ,  , 	Enter Calibration
Press 	Select Scale 2
Press 	Set weight decimal point
Press  or 	Increase or decrease the number of decimal points
Press 	Store weight decimal point setting, ready to enter platform capacity
Enter capacity, press 	Store capacity setting, ready to enter minimum display
Enter minimum display, press 	Store minimum display setting, ready to select Single- or Multi-Interval
Press  or  to select Single- or Multi-Interval and then press 	Store interval setting
Enter Max1 setting, press 	Store Max1 setting, ready to enter minimum display in weighing range Max1 The operation scenario only occurs on multi-interval
Enter Min D1, press 	Store Min D1, ready to calibrate zero point Reference weight for calibration must exceed or equal 10% full scale capacity
Confirm no weight is on scale, press 	Calibrating zero point
Enter Span calibration weight, press 	Calibrating span
Press 	Return to Z mode

Table 2-4. Calibration for Scale 2

2.6 Set Password

Enter **Z mode** before setting passwords.











Operation	Function
Press 	Display password for X mode XXXX: Password If 0 displays, no password is set
Enter 4-digit numerical password, press 	Set X mode password using keypad Press  to save password for X mode
Press 	Display password for Z mode
Enter two-digit numerical password, press  	Clear Z password
Press 	Display password for PWD mode
Enter 4-digit numerical password	Set four-digit PWD mode password using keypad
Press 	Return to Weigh mode





Table 2-5. Set Password

2.6.1 Using Passwords





1. Press  twice within 3 seconds to enter setup menu. If a mode is password protected there is a prompt for a password.
2. Enter password then  to enter into mode.
3. If no password is set prompt is not given.

2.7 Adjustment

2.7.1 Span Switch Setting Display

1. Enter **Z mode**.
2. Press and hold  and enter , , .
3. Unit will display **SPAN SWITCH OFF or ON**, exits after 3 seconds.

2.7.2 Internal Count Display

1. Enter **Z mode**.
2. Press and hold  and enter , , .

2.8 Clear Files

This function is used to clear files in Memory.

Enter **Z mode** before operation.












Operation	Function
Press  and enter  ,  , 	PLU File
Press 	Select to clear report files
Press 	Select to clear memory data
Press 	To save
Press  or 	Press  to clear file data or  to quit

Table 2-6. Clear Files

3.0 Program Mode

In Program mode there are two ways to select a programming file:

1. Enter the number key corresponding to the program
2. Press **+** or **-** key to select the data file

The following are programmed in Program mode (**S mode**):

Key	Data Files
1	PROGRAM PLU
2	PROGRAM FACTORY
4	PROGRAM DATE AND TIME
5	PROGRAM ADDRESS
7	PROGRAM TEXT
8	PROGRAM FREE FORMAT
9	PROGRAM LOGO
10	MEMORY STATUS
11	INTERFACE TEST
12	PROGRAM MULTI-BARCODE
13	PROGRAM 2D BARCODE TEXT

Table 3-1. Program Mode files

3.1 Program Mode Entry

1. From **Weigh mode** press **MODE** three times to enter **S mode**.
2. Press **+** or **-** to scroll through programs in **S mode** or press numerical program key to go directly to program desired.

3.2 PLU FILE

The following are programmed in **PLU Program** mode.

Step	Items
S1.0	ID CODE ENTRY
S1.1	UNIT WEIGHT
S1.2	TARE WEIGHT
S1.3	LABEL FORMAT
S1.4	PART NAME
S1.5	PART NUMBER
S1.6	LOT NUMBER
S1.7	LOCATION
S1.8	INVENTORY
S1.9	THRESHOLD
S1.10	SELECT SET POINT TYPE
S1.11	SET POINT 1
S1.12	SET POINT 2
S1.13	ADDRESS NUMBER (if Address exists)

Table 3-2. PLU PROGRAMS

3.2.1 Program Item File

Item data is programmed by the following procedure.





















Operation	Function
From <i>Weigh mode</i> press  three times	Enter <i>S mode</i>
Press 	Enter <i>PLU Program mode</i>
Enter ID Code, press 	Enter ID code then press  to store
Enter weight	Enter weight
Enter tare value then 	Place a tare weight on scale. If tare value is known, enter the tare value by numeric keys
Press  or 	Select label format from options displayed
Press 	Set label format
Enter part name, press 	Enter part name then press  to store
Enter part number press 	Enter part number
Enter lot number press 	Enter lot number
Enter inventory press 	Enter Inventory
Enter threshold press 	Enter Threshold
Press  or 	Scroll through Set Point type (%/Qty, %/Weight, Qty/Qty, Weight/Weight)
Press 	Select Set Point type
Enter Set Point 1 press 	Enter Set Point 1
Enter Set Point 2 press 	Enter Set Point 2
Enter Address number press 	Return to <i>S mode</i>

Table 3-3. Item Function Data



Unit Weight value can be entered by Numeric Key or Weight Sampling.

1. Numeric Key can be a maximum 5 digits and 1 decimal point for Unit Weight.

2. Weight Sampling:

Place the product on scale when Insufficient indicator is ON.

Place the 10 pieces of product on scale (Insufficient indicator lighted up) and then press Pieces to do sampling. After a few seconds, a message ADD 3 will appear on the display. If the samples are heavy enough the insufficient indicator light will be off.




Add three pieces of product on scale and press Pieces. After a few seconds, the Unit Weight value will appear on Unit Weight column and Unit weight entering column.

Place the product on scale when Insufficient indicator is OFF

Insufficient Indicator light will be OFF, if the weight exceeded the insufficient weight setting. Place the product on scale (Ex. 1kg =100pcs).

Enter the known quantity (Ex. 100) and press Pieces key (If the quantity is 10 pieces, press Pieces key to sample without entering the quantity). Wait for Unit Weight computation to be completed. The Unit Weight value will appear on Unit Weight column and the Unit Weight entering column.

3.2.2 Delete Item Code

1. Enter *Item Code Program* mode.
2. Enter ID Code.
3. Press .
4. Press  to delete,  to cancel.

3.2.3 Label Format List

Label Format No.	Label Standard	Label Size (mm)
0	DEFAULT	Label size set in specification setting
1	T1	60 x 28
2	T2	60 x 31
3	T3	60 x 34
4	T4	60 x 40
5	T5	60 x 43
6	T6	60 x 46
7	T7	60 x 49
8	T8	60 x 55
9	T9	60 x 37
10	T10	60 x 40
11	T11	60 x 43
12	T12	60 x 49
13	S	40 x 28
14	A	40 x 46
15	B	40 x 46
16	C	40 x 62.5
17	F1	*
18	F2	*
19	F3	*
20	F4	*
21	F5	*
22	F6	*
23	F7	*
24	F8	*
25-115	F9-F99	*

Table 3-4. Label Formats



Note *F1-F99 are available only when Free Format is programmed.

3.2.4 Factory Name File

Factory name is used for programming a short text describing the name of a factory. A maximum of 32 factory names can be programmed. The default factory name label can be set in SPEC 56, print centering of factory name on label can be selected at SPEC 57.



Note

Factory Name will not print on the label if the selected label format without print area for Factory Name or SPEC 55 is set to 0: NO PRINT.










Operation	Function
From Weigh mode press  three times	Enter S mode
Press  or 	Select Program Factory mode
Press 	Enter Program Factory mode
Enter Factory #, press 	Enter Factory number (1-32)
Enter Factory name	Font choices display
Press  or  then press 	Change font size (S1-S5; M1-M5)
Press 	Store data, return to S mode

Table 3-5. Program Factory Name

3.2.5 Print Factory Name Report

The Factory Name report can be printed on receipt paper. A full report includes all programmed factory data and a single report includes one factory data only.









Operation	Function
From Weigh mode press  three times	Enter S mode
Press  or 	Select Program Factory mode
Press 	Enter Program Factory mode
Press 	Enter Factory name report print mode
Press 	Enter start number
Press 	Enter end number
Enter Factory number	Factory number for printed report
Press 	Print report, return to factory name mode

Table 3-6. Factory Report

3.2.6 Delete Factory Name File








Operation	Function
From Weigh mode press  three times	Enter S mode
Press  or 	Select Program Factory mode
Press 	Enter Program Factory mode
Enter factory number	Factory number will display
Press 	DEL? Y-C N-T displays
Press  to delete,  to cancel	Return to S mode

Table 3-7. Delete Factory File

3.3 Program Date and Time

The built-in clock system automatically works once set.







Operation	Function
From Weigh mode press  three times	Enter S mode
Press  or 	Select Date and Time Program mode
Press 	Enter Date and Time Program mode
Enter date (MM/DD/YY) press 	Enter Month, Day and Year
Enter Time (HH:MM) press 	Store time and date, return to S mode

Table 3-8. Time and Date

3.4 Address File

Address file is used to program factory address, which can be assigned in each item to be printed on the label. Standard format does not have a print area for address, the address cannot be printed when using these formats. To print an address on the label, a Free Format with an address print area programmed must be used. Maximum 16 Address (No. 1-16) can be programmed with up to eight programmable lines. The number of lines depend on the size of the print area or character size entry.

3.4.1 Program Address File










Operation	Function
From Weigh mode press  three times	Enter S mode
Press  or 	Select Address Program mode
Press 	Enter Address Program mode
Enter Address number press 	Enter Address number
Enter Address line 2	Enter address
Press  or  then press 	Change font size (S1-S5; M1-M5)
Press 	Store data and return to S mode

Table 3-9. Program Address

3.4.2 Print Address File









Operation	Function
From Weigh mode press  three times	Enter S mode
Press  or 	Select Address Program mode
Press 	Enter Address Program mode
Press 	Enter Address report print mode
Press 	Enter start number
Press 	Enter end number, print address full report
Enter Address number	Enter address number (Ex. 1) print single report
Press 	Return to Address Program mode

Table 3-10. Print Address

3.4.3 Delete Address File













Operation	Function
From Weigh mode press  three times	Select Address Program mode
Press  or 	Enter Address Program mode
Press 	Select Address Program mode
Enter Address number	Address number 1-16
Press 	DEL? Y-C N-T displays
Press  to delete,  to cancel	Return to S mode

Table 3-11. Delete Address File

3.5 Memory Status

This functions if used for checking the number of existing PLU and remaining programmable PLU

1. From **Weigh mode** press  three times, press  and then  to select **Memory Status Program** mode.
2. Enter the **Free Format** file to be deleted.
3. Press .
4. Press  to return to **S mode**.

3.6 Programming Multi Barcode Files














Operation	Function
From Weigh mode press  three times	Enter S mode
Press  and then  , or 	Select Multi Barcode Program mode
Press 	Enter Multi Barcode Program mode
Enter Multi Barcode number, press 	Enter Multi Barcode number, press  to store data
Press 	Scroll through Multi Barcode data type
Press 	Select type
Enter barcode data, press 	Enter barcode data, press  to store data
Press 	Select Multi Barcode type
Press 	Store data, return to S mode

Table 3-12. Programming Multi-Barcode Files

3.7 2D Barcode Text File

Maximum 999999 2D barcode texts are available for 2D barcode.



















Operation	Function
From Weigh mode press  three times	Enter S mode
Press  and then  , or 	Select 2D Barcode Text Program mode
Press 	Enter 2D Barcode Text Program mode
Enter 2D Barcode Text number, press 	Enter 2D Barcode Text number to be used,
Enter text data	press  to store data
Press  or  then press 	Change font size if needed (S1-S5; M1-M5)
Press 	Store data, return to S mode

Table 3-13. Program 2D Barcode Text File

3.7.1 Deleting 2D Barcode Text Files


1. From **Weigh mode** press  three times, press  and then , or  to select **2D Barcode Text Program mode**.
2. Enter 2D barcode text number to be deleted.
3. Press .

Press  for yes,  to cancel. Record is deleted and display returns to **S mode**.

4.0 Registration Mode



4.1 Rezero and Weighing Check

All weighing operation will be performed based on the procedure below.

1. Press . The screen will display 8's across the display.
2. Place an item on the scale.
3. Remove the item from the scale and check to ensure scale goes back to 0.0000 kg.

4.2 Tare Subtraction

One Touch Tare Subtraction


1. Confirm scale is at zero. See [Section 4.1 on page 18](#)
2. Place the tare weight on the scale.
3. Press  to subtract tare weight.
4. Remove tare weight from scale.
5. Press  to clear tare weight.

Digital Tare Subtraction



1. Confirm scale is at zero. See [Section 4.1 on page 18](#)
2. Key in tare weight using the keypad.



Note *Tare weight must be entered with leading and trailing zeros (i.e.0.0000)*




3. Press  to clear tare weight.

4.3 Item Call Up

1. Confirm scale is at zero. See [Section 4.1 on page 18](#)
2. Enter the ID Code.
3. Press .
4. Press  to return to standby mode.

4.4 Set New Item Code in Registration Mode

This function is used to program a new item in Operation mode and update item files. To enable this function, SPEC 4 must be set to 0 in advance.







1. Confirm scale is at zero. See [Section 4.1 on page 18](#)
2. Enter new ID code.
3. Press  to store the new item in item files.
4. Enter unit weight with keypad.
5. Press  to update weight to new item.
6. Press  to return to standby status.

4.5 Accumulation and Subtraction

There are two ways to issue a label or receipt for individual products:

1. Place the product on the scale.
2. Enter the known quantity of the product.

4.5.1 Accumulation and Subtraction

1. Confirm scale is at zero. See [Section 4.1 on page 18](#)
2. Enter item number and press  to call up item.
3. Enter the known quantity for the product for accumulation. (Max. 9999999)
4. Press  to exit Total mode.
5. Place product on the scale.
6. Press  to accumulate total.
7. Press  to exit Total mode.
8. Enter the known quantity for the product for subtraction.
9. Press  to issue label or receipt.
10. Remove product from scale and press .



Note *Auto exit from Total mode can be selected using SPEC 14.*

4.6 Unit Weight Operation

User can set new weight by sampling the product or enter the known unit weight by numeric keys.

4.6.1 Sampling

1. Confirm scale is at zero. See [Section 4.1 on page 18](#)
2. Place the product on the scale.



Note

*When placing samples on the scale if **INSUFF** has an arrow above it add more samples until it disappears. Then enter quantity using keypad and press Pieces.*

3. Enter the product quantity.


4. Press  to sample.



Note



Display Accuracy Unit Weight calculation during recomputing can be set at SPEC 9.

4.6.2 Numeric Key

1. Confirm scale is at zero. See [Section 4.1 on page 18](#)
2. Place product on the scale.
3. Enter the known unit weight using the keypad.
4. Press  to store.

4.6.3 Recomputing Unit Weight in Memory

This function is used to set new unit weight by sampling and updating item file in Counting mode.

1. Confirm scale is at zero. See [Section 4.1 on page 18](#)
2. Enter item number and press  to call up item.
3. Place the product on the scale until the indicator **RECOMP** has an arrow above it.
4. Press  to recompute.



Note

Display Accuracy Unit Weight calculation during recomputing can be set at SPEC 9.

5. Press  to update new weight to item file.







Note

SPEC 4, SET TO NEW ITEM, must be set to 0:yes, to be able to save unit weight.




6. Remove product from scale, press  to clear the item.






4.7 Inventory Operation


This function is used to store the product quantity in or out in item file. Inventory operation is only available after calling up an

item and then pressing  +  or  +  for IN or OUT inventory respectively. There are two ways to store the quantity data to inventory field of the item, manual transaction and total transaction of the individual item only. Inventory operation is not available for multiple items.


4.7.1 Manual Transaction

1. Confirm scale is at zero. See [Section 4.1 on page 18](#)
2. Enter item number and press  to call up item.
3. Press  +  to select Inventory IN.




 **Note** Press  +  for Inventory IN, press  +  to clear Inventory operation.






4. Place the product on the scale.
5. Press  to store the quantity into the item Inventory IN.






 **Note** In order to save the quantity into the item inventory SPEC 4, SET TO NEW ITEM must be set to 0:Yes.

6. Remove the product from the scale and press  to clear item.

4.7.2 Total Transaction



1. Confirm scale is at zero. See [Section 4.1 on page 18](#)
2. Enter item number and press  to call up item.
3. Press  +  to select Inventory OUT.






 **Note** Press  +  for Inventory IN, press  +  to clear Inventory operation.

4. Place the product on the scale.
5. Press  to accumulate.
6. Press  to exit from Total mode.
7. Enter known quantity using keypad, press .
8. Press  to store the quantity to Inventory OUT.
9. Remove the product from the scale and press  to clear the item.


4.8 Function Key



4.8.1 Net/Gross Key

Gross weight displays are available in Registration mode by pressing  +  to enter Gross mode.

1. Confirm scale is at zero. See [Section 4.1 on page 18](#)
2. Place weight on scale.
3. Press  to subtract tare weight.
4. Add more weight on scale.
5. Press  +  to enter Gross mode.
6. Press  +  to return to Net mode.
7. Remove all weight from scale and clear tare value.



4.8.2 Switch Platform Key

Switching platform is available in Operation mode by pressing  to switch between Scale 1 and Scale 2.

1. Confirm scale is at zero. See [Section 4.1 on page 18](#)
2. Enter item number and press  to call up item.
3. Press  to switch between scale 1 and 2.

4.8.3 Switch Weight Unit Key

This function is used to change the weight unit between kg and lb in Operation mode. The default weight unit is set using SPEC 600. To enable this function SPEC 642, KG/LB Inhibit, must be set to 0:No in advance.

1. Confirm scale is at zero. See [Section 4.1 on page 18](#)
2. Put weight on scale.
3. Press  +  to change weight unit from kg to lb. Press again to change back.

4.8.4 View Item Key

The following view keys list enables user to view the items data in operation mode.






















Key Combination	Function
 + 	View Id Code
 + 	View Part Name
 + 	View Part Number
 + 	View Location
 + 	View Inventory
 + 	View Threshold
 + 	View Set-Point Data (Set point 1 and 2)







Table 4-1. View Item Key

1. Confirm scale is at zero. See [Section 4.1 on page 18](#)
2. Enter item number and press  to call up item.
3. Enter  and View Key  through .

 **Note** Use  or  to view Set Point 1 and 2.



4. Information will be displayed.

4.8.5 Address No Key

1. Confirm scale is at zero. See [Section 4.1 on page 18](#)
2. Enter item number and press  to call up item.
3. Press  +  to temporarily change the address number to print on label.
4. Enter new address and press  to store.
5. Place the product on the scale and press .
6. Remove the product from the scale and press .



4.8.6 Lot Number Key

This function is used to set and save new lot number in Registration mode. To use this function the SPEC 12, Keep lot number in Registration mode, must be set to 0:Allow in advance.

1. Confirm scale is at zero. See [Section 4.1 on page 18](#)
2. Enter item number and press  to call up item.
3. Press .






Note To print original item and lot number on label, place the product on scale and press .

4. Enter new lot number using keypad.
5. Place the product on scale and press .
6. Remove the product from the scale and press .

4.8.7 Sequence Number Key

This function is used to allow the user to set and save new sequence number in Registration mode.





1. Confirm scale is at zero. See [Section 4.1 on page 18](#)
2. Press  + .
3. Enter new Sequence number. Press  twice to exit.

5.0 Report Mode

The DC-400 has report function to print out various kinds of transaction reports for analysis and checking. The types of reports are below:

- **Item Report** - Print item data programmed
- **Inventory Report** - Print item inventory data and item in/out count
- **Shelf Location Print** - Print shelf location label.









5.1 Report Mode Entry

1. From **Weigh mode** press  twice to enter **X mode**.
2. Press  or  to scroll through report types
3. Press  to select report type.








5.2 Item Report

Item Report can be printed on receipt paper. **All Item Report** or **One Item Report** can be selected to print.

5.2.1 One Item Print

1. From **Weigh mode** press  twice to enter **X mode**.
2. Press  or  to scroll through options to **Item Report**.
3. Press  to select **Item Report**.
4. Press  or  to scroll through options to **One Item Print**.
5. Press  to select **Item Report**.
6. Enter existing Item Code for One Item Report printing.
7. Press  to print report.

5.2.2 All Item Print

1. From **Weigh Mode** press  twice to enter **X mode**.
2. Press  or  to scroll through options to **Item Report**.
3. Press  to select **Item Report**.
4. Press  or  to scroll through options, find **All Item Print**.
5. Press  to print **All Item Print**.

5.3 Inventory Report









Inventory Report has three possible report print options, **Threshold Print**, **In and Out Count Print**, and **Clear In and Out Count File**. The reports print on receipt paper.

5.3.1 Threshold Report







Threshold report shows under stocked or over stocked items at various levels by presetting the optimal stock levels. This prevents out of stocks and keeps an optimum inventory balance. Threshold report can be printed by entering the stock level percentage. Only items stock level or below the entering percentage will print on the report.

The formula for stock level is: $Stock\ Level\% = [(Inventory - Threshold) / Threshold] \times 100$







5.3.1.1 Print Threshold Report

1. From **Weigh mode** press  twice to enter **X mode**.
2. Press  or  to scroll through options to **Inventory Report**.
3. Press  to select **Inventory Report**.
4. Press  to scroll through options to **Threshold**.
5. Press  to select **Threshold**.
6. Press  to select **Stock%**.
7. Enter the percentage of stock level.
8. Press  to print Threshold report. To stop printing press **FEED**.

5.3.2 In/Out Count Report

1. From **Weigh mode** press  twice to enter **X mode**.
2. Press  or  to scroll through options to **Inventory Report**.
3. Press  to select **Inventory Report**.
4. Press  to scroll through options to **In/Out Report**.
5. Press  to print In/Out report. To stop printing press **FEED**.









5.3.2.1 Clear In/Out Report

1. From **Weigh mode** press  twice to enter **X mode**.
2. Press  or  to scroll through options to **Inventory Report**.
3. Press  to select **Inventory Report**.
4. Press  to scroll through options (**Clear Daily**, **Clear Term**, **Clear All**).
5. Press  to select option.

5.4 Shelf Location

Shelf location is used to select shipping label format of the item for shipment. If standard format does not have the print area for programmed shipping data it is required to use a free format with the print area for programmed shipping data.

5.4.1 Shelf Location Print

1. From **Weigh mode** press  twice to enter **X mode**.
2. Press  or  to scroll through options to **Shelf Location Print**.
3. Press  to select.
4. Enter ID Code then press .
5. Press  or  to select label format.
6. Press  to print Shelf Location label.

6.0 Specification Settings

Span Switch must be enabled to use this function.

Enter **Z mode** before setting.













Operation	Function
Press and hold  and enter  ,  ,  .	Specification options will display.
Press  or 	Increase or decrease Specification count.
Enter SPEC #, press 	Enter desired Specification number.
Press  or 	Moves cursor right or left.
Enter specification option, press 	Enter option according to table, press  to move to next Specification.
Press 	Store the updated information and return to Z mode .

Table 6-1. Specification Entry



Note Press  to return to Z mode without saving.

6.1 Customer Specification Settings

SPEC	Option	Description
00		Auto power saving when no weight change & no key press
	0	Inhibit
	1	3 minutes
	2	10 minutes
	3	30 minutes
	4	1 hour
	5	3 hours
01		Power saving mode
	0	Back Light off
	1	Power off
02		Negative Counting
	0	No
	1	Yes
03		Extent of insufficient samples
	0	0.1%
	1	0.2%
	2	0.0%
04		Set new item during registration mode
	0	Yes
	1	No
05		Date order
	0	Month/Day/Year
	1	Day/Month/Year
	2	Year/Month/Day

Table 6-1. Customer Specification Settings

SPEC	Option	Description
06	Time format	
	0	24 Hour
	1	12 Hour (am/pm)
07	Unit weight auto recomputing	
	0	No
	1	Yes
08	Sampling times for unite weight calculation	
	0	15 Times
	1	20 Times
09	Display accuracy unit weight calculation during recomputing	
	0	No
	1	Yes
10	Set point buzzer	
	0	On
	1	Off
11	Clear all input keys in one touch	
	0	Yes
	1	No
12	Keep lot number in registration mode	
	0	Allow
	1	Inhibit
13	Job Sequence	
	0	Disable
	1	Enable
14	Auto exit from add more	
	0	No
	1	Yes
15	SIO Select Job	
	0	No operation
	1	Track N Print (TNP)
	2	Force Balance (FB)
	3	PC Connection
	4	Printer Connection
	5	Barcode Scanner
16	RS-232C Baud Rate (SIO)	
	0	1200
	1	2400
	2	4800
	3	9600
	4	19200
	5	38400
17	RS-232C Data length (SIO)	
	0	7 bits
	1	8 bits
18	RS-232C Parity bit (SIO)	
	0	None
	1	Odd
	2	Even

Table 6-1. Customer Specification Settings (Continued)

SPEC	Option	Description
19	RS-232C Stop bit (SIO)	
	0	1 bit
	1	2 bits
20	RS-232 Option card with 8 PIN DIN2 and 8 PIN DIN1	
	0	Not connected
	1	Printer/Force balance
	2	Force balance/Printer
	3	Printer/PC
	4	PC/Printer
	5	PC/Force balance
21	RS-232 Baud Rate for 8 PIN DIN1 connector (optional card)	
	0	4800
	1	9600
	2	19200
	3	38400
22	RS-232 Data length for 8 PIN DIN1 connector (optional card)	
	0	7 bits
23	RS-232 Stop bit for 8 PIN DIN1 connector (optional card)	
	0	1 bit
24	RS-232 Parity bit for 8 PIN DIN1 connector (optional card)	
	0	None
	1	Odd
25	RS-232 Baud rate for 8 PIN DIN2 connector (optional card)	
	0	4800
	1	9600
	2	19200
26	RS-232 Data length for 8 PIN DIN2 connector (optional card)	
	0	7 bits
27	RS-232 Stop bit for 8 PIN DIN2 connector (optional card)	
	0	1 bit
28	RS-232 Parity bit for 8 PIN DIN2 connector (optional card)	
	0	None
	1	Odd
29	RS-232 Connection to Force Balance	
	0	Disable
30	Type of Force Balance	
	0	Export
	1	HR-60 (JAPAN)
	2	SHG-200 (JAPAN)
	3	SHG-300 (JAPAN)

Table 6-1. Customer Specification Settings (Continued)

SPEC	Option	Description
31	PC/PRN Output data method	
	0	No operation
	1	Count condition (PC only)
	2	By <input type="checkbox"/> / <input type="checkbox"/> /Print Key (PC/PRN)
	0	For both cases 1 & 2
32	Select external printer type	
	0	Eltron LP2622/LP2722 or TVP1000
	1	SE250
	2	DP122 (JAPAN)
33	External Eltron/TVP printer download label format	
	0	Enable
	1	Disable
34	Print when press <input type="checkbox"/> / <input type="checkbox"/> key	
	0	Disable
	1	Enable
35	PC data with header	
	0	Yes
	1	No
36	PC data header type	
	0	Code
	1	Title
37	Barcode scanner (BCS) connection	
	0	Disable
	1	Enable
38	Barcode scanner (BCS) with header	
	0	Yes
	1	No
39	Track N Print (TNP) Timeout	
	0	2 seconds
	1	8 seconds
	2	32 seconds
40	Selection of Track N Print network interface	
	0	No interface (RS-232)
	1	Ethernet - coaxial cable
	2	Ethernet - twisted cable
41	Port number (IP address)	
	Range	1-254
42	Set scale number	
	Range	0-999999
43	Select receipt or label paper printing	
	0	Print receipt paper
	1	Print label paper
44	Printing speed for receipt	
	0	Slow
	1	Normal
	2	High

Table 6-1. Customer Specification Settings (Continued)

SPEC	Option	Description
45	Printing speed for label	
	0	Slow
	1	Normal
	2	High
46	Label printing density	
	0	Low
	1	Medium
	2	Medium high
	3	High
48	Peel sensor function	
	0	Disable
	1	Enable
49	Number of reprint labels	
	0	No label
	1	1 label
	2	2 labels
50	Selection of label and receipt printing operation	
	0	All operation (In/out/non-add)
	1	Out (shipping operations)
	2	In (receiving operations)
	3	In & Out (receiving and shipping)
	4	No printing
51	Human readable barcode printing format	
	0	Do not print
	1	Print
52	Item data (such as ID code, part name, part no. & lot no.) printing format	
	0	Center
	1	Left aligned
53	Date title print	
	0	No
	1	Yes
54	Weigh data and quantity print	
	0	Do not print
	1	Print
55	Print factory name on label	
	0	Do not print
	1	Print
56	Default printing label factory number	
	Range	0-32
57	Format of printing factory name	
	0	Centered
	1	Left aligned
58	Selection of logo to print on label	
	0	Do not print
	1	Logo 1
	2	Logo 2
	3	Logo 3
	4	Logo 4

Table 6-1. Customer Specification Settings (Continued)

SPEC	Option	Description
59	Selection of Barcode Type	
	0	Code128
	1	Ean128
	2	Code39
60	Auto Print Function	
	0	Between setpoint 1 and 2
	1	Disable
61	Ethernet Functions	
	0	No operation
	1	Scale genie
	2	Data transfer mode
62	RS-232C Software handshaking	
	0	Disable
	1	Enable
63	Sample Quantity	
	0	10 pieces
	1	25 pieces
	2	50 pieces
	3	100 pieces
64	Scale A or B	
	0	Manual
	1	Auto
65	Unit of pieces weight	
	0	1000 pieces
	1	1 piece
66	RESERVED	
67	IMS	
	0	Disable
	1	Enable
68	Epson II	
	0	Disable
	1	Enable
70	UPD lot & part number	
	0	Disable
	1	Enable
71	Text 11-16 in TTL	
	0	Disable
	1	Enable
72	Comma in quantity	
	0	Disable
	1	Enable
73	Print barcode	
	0	With header
	1	All without header
	2	Quantity without header
74	Overwrite unit WT	
	0	No
	1	Yes (if unit WT =0)

Table 6-1. Customer Specification Settings (Continued)

SPEC	Option	Description
75	Reset sequence number	
	0	No
	1	Yes (when print)
76	Selectable printer	
	0	Disable
	1	Enable
77	Selectable prints	
	0	Disable
	1	Enable
78	Transaction ABC	
	0	Disable
	1	Enable
79	ID Manager	
	0	Disable
	1	Enable
80	DHCP	
	0	Disable
	1	Enable
81	2D Item-TTL SEQ#	
	0	Disable
	1	Enable
82	TTL SEQ NUM INC	
	0	Yes
	1	No
83	Wireless Comm	
	0	Disable
	1	Enable
84	Select UW/scale	
	0	Disable
	1	Enable
85	Scale 1 per pcs	
	0	Disable
	1	Enable
86	Scale 2 per pcs	
	0	Disable
	1	Enable
87	Scale 3 per pcs	
	0	Disable
	1	Enable
88	Scale 4 per pcs	
	0	Disable
	1	Enable
89	Auto print condition	
	0	No condition
	1	WT=below
90	Print condition	
	0	No condition
	1	Lot number

Table 6-1. Customer Specification Settings (Continued)


SPEC	Option	Description																																																																																																								
91	SP buzzer condition																																																																																																									
	0	Standard																																																																																																								
	1	Inside set point																																																																																																								
	2	Outside set point																																																																																																								
100	Server IP address																																																																																																									
	Range	1-255																																																																																																								
101	 Key																																																																																																									
	0	Enable																																																																																																								
	1	Disable																																																																																																								
102	Black bar sensing label																																																																																																									
	0	Normal																																																																																																								
	1	Black bar sensing																																																																																																								
103	Transparent film label																																																																																																									
	0	No																																																																																																								
	1	Yes																																																																																																								
104	Print checking line																																																																																																									
	0	Print																																																																																																								
	1	Do not print																																																																																																								
105	Print label orientation																																																																																																									
	0	From bottom																																																																																																								
	1	From top																																																																																																								
106	Default label format for item printing																																																																																																									
	<table border="1"> <tbody> <tr> <td>0</td><td>T1</td><td>NA</td><td>A</td> <td>13</td><td>A</td><td>T7</td><td>T8</td> </tr> <tr> <td>1</td><td>T2</td><td>A</td><td>B</td> <td>14</td><td>B</td><td>T8</td><td>T9</td> </tr> <tr> <td>2</td><td>T3</td><td>B</td><td>C</td> <td>15</td><td>C</td><td>T9</td><td>T10</td> </tr> <tr> <td>3</td><td>T4</td><td>C</td><td>U2</td> <td>16</td><td>F1</td><td>T10</td><td>F1</td> </tr> <tr> <td>4</td><td>T5</td><td>U2</td><td>U3</td> <td>17</td><td>F2</td><td>F1</td><td>F2</td> </tr> <tr> <td>5</td><td>T6</td><td>U3</td><td>U4</td> <td>18</td><td>F3</td><td>F2</td><td>F3</td> </tr> <tr> <td>6</td><td>T7</td><td>U4</td><td>U5</td> <td>19</td><td>F4</td><td>F3</td><td>F4</td> </tr> <tr> <td>7</td><td>T8</td><td>U5</td><td>U6</td> <td>20</td><td>F5</td><td>F4</td><td>F5</td> </tr> <tr> <td>8</td><td>T9</td><td>U6</td><td>U7</td> <td>21</td><td>F6</td><td>F5</td><td>F6</td> </tr> <tr> <td>9</td><td>T10</td><td>U7</td><td>U8</td> <td>22</td><td>F7</td><td>F6</td><td>F7</td> </tr> <tr> <td>10</td><td>T11</td><td>U8</td><td>T5</td> <td>23</td><td>F8</td><td>F7</td><td>F8</td> </tr> <tr> <td>11</td><td>T12</td><td>T5</td><td>T6</td> <td>24</td><td>-</td><td>F8</td><td>-</td> </tr> <tr> <td>12</td><td>S</td><td>T6</td><td>T7</td> <td></td><td></td><td></td><td></td> </tr> </tbody> </table>		0	T1	NA	A	13	A	T7	T8	1	T2	A	B	14	B	T8	T9	2	T3	B	C	15	C	T9	T10	3	T4	C	U2	16	F1	T10	F1	4	T5	U2	U3	17	F2	F1	F2	5	T6	U3	U4	18	F3	F2	F3	6	T7	U4	U5	19	F4	F3	F4	7	T8	U5	U6	20	F5	F4	F5	8	T9	U6	U7	21	F6	F5	F6	9	T10	U7	U8	22	F7	F6	F7	10	T11	U8	T5	23	F8	F7	F8	11	T12	T5	T6	24	-	F8	-	12	S	T6	T7				
	0	T1	NA	A	13	A	T7	T8																																																																																																		
	1	T2	A	B	14	B	T8	T9																																																																																																		
	2	T3	B	C	15	C	T9	T10																																																																																																		
	3	T4	C	U2	16	F1	T10	F1																																																																																																		
	4	T5	U2	U3	17	F2	F1	F2																																																																																																		
	5	T6	U3	U4	18	F3	F2	F3																																																																																																		
	6	T7	U4	U5	19	F4	F3	F4																																																																																																		
	7	T8	U5	U6	20	F5	F4	F5																																																																																																		
	8	T9	U6	U7	21	F6	F5	F6																																																																																																		
	9	T10	U7	U8	22	F7	F6	F7																																																																																																		
	10	T11	U8	T5	23	F8	F7	F8																																																																																																		
	11	T12	T5	T6	24	-	F8	-																																																																																																		
12	S	T6	T7																																																																																																							

Table 6-1. Customer Specification Settings (Continued)

SPEC	Option	Description
107	Default label format for total printing	
	0	T1 NA A
	1	T2 A B
	2	T3 B C
	3	T4 C U2
	4	T5 U2 U3
	5	T6 U3 U4
	6	T7 U4 U5
	7	T8 U5 U6
	8	T9 U6 U7
	9	T10 U7 U8
	10	T11 U8 T5
	11	T12 T5 T6
	12	S T6 T7
13	A T7 T8	
14	B T8 T9	
15	C T9 T10	
16	F1 T10 F1	
17	F2 F1 F2	
18	F3 F2 F3	
19	F4 F3 F4	
20	F5 F4 F5	
21	F6 F5 F6	
22	F7 F6 F7	
23	F8 F7 F8	
24	- F8 -	
108	Print manual weight signature on item label	
	0	Inhibit
	1	Allow
109	Left alignment of price and weight on label	
	0	NO
	1	Price
	2	Weight
	3	Price and Weight
110	Print \$ and weight unit of label	
	0	Do not print
	1	Print
111	Print checksum for item barcode	
	0	Disable
	1	Enable
112	Zero suppress for date and time	
	0	Disable
	1	Enable
113	Enlarge line spacing for G3 font on item label	
	0	Inhibit
	1	Allow
114	Alignment of commodity name on label	
	0	Center
	1	Left
115	Continuous label	
	0	Disable
	1	User programmable

Table 6-1. Customer Specification Settings (Continued)

SPEC	Option	Description
116	Multi barcode type	
	0	EAN128
	1	RSS
	2	CODE128
	3	PDF417#
	4	GS1 QR Code#
	5	GS1 DataMatrix #
	6	GS1 Databar Composite
	7	Codabar
	8	Code39
9	GM Code #	
117	Enable password mode	
	0	Allow
	1	Inhibit
118	Year format	
	0	YY
	1	YYYY
120	Character size for barcode data	
	0	Large
	1	Small
121	Print format of month	
	0	Number
	1	2 Alphabetic
	2	3 Alphabetic
122	Numeric key entry reset	
	0	3 sec
	1	5 sec
	2	Disable
123	Total label printing	
	0	Do not print
	1	Print
124	Tare Override	
	0	Allow
	1	Inhibit
125	Setting of Client/Server	
	0	Client
	1	Server/Workstation
126	Mask barcode last human readable check digit	
	0	No
	1	Yes
127	Wireless communication	
	0	No
	1	Yes
128	Print control for image	
	0	Disable
	1	Enable

Table 6-1. Customer Specification Settings (Continued)


SPEC	Option	Description
129	Gratuitous ARP	
	0	Disable
	1	Enable
130	RTS/CTS handshaking of RS-232C	
	0	On
	1	Off
131	Symbol format for date print	
	0	Dash
	1	Period
	2	Null
132	Width of stacked symbol in segments for RSS barcode	
	0	2
	1	4
	2	6
	3	8
133	Print quality of 2D barcode	
	0	Mid
	1	High-mid
	2	High
	3	Highest (for QR code only)
134	RSS and 2D barcode human readable interpretation print	
	0	All
	1	GTIN only
	2	No print
135	Barcode check line	
	0	Print
	1	Do not print
136	Feed for continuous label	
	0	No
	1	Yes
137	Gap value in-feed operation	
	0	Re-adjustable
	1	No change
138	Weight data synchronization function	
	0	Allow
	1	Inhibit
	2	Enforce
140	Recalculate label and gap value by  and FEED key	
	0	Allow
	1	Inhibit
141	FTP Client auto connection interval (minute)	
	Value	0-9999
142	FTP Client data connection mode	
	0	Port
	1	PASV
143	Ethernet IC reset interval (minute)	
	Value	5-999

Table 6-1. Customer Specification Settings (Continued)

SPEC	Option	Description
144		Offset position for printing receipt
	0	0mm
	1	1mm
	2	2mm
	3	3mm
	4	4mm
	5	-1mm
	6	-2mm
	7	-3mm
	8	-4mm

Table 6-1. Customer Specification Settings (Continued)

6.2 Weight and Measurement Specification Settings



Note Span Switch must be enabled when accessing this mode.

SPEC	Option	Description
600		Scale unit specification
	0	gram
	1	kilogram
601		Display resolution
	0	1/10,000
	1	1/5,000
	2	1/2,500
602		Internal Count
	0	500,000
	1	1,000,000
603		Minimum display (increment) for Scale A
	0	2
	1	1
	2	5
	3	10
604		Weight decimal point for Scale A
	0	0
	1	0.0
	2	0.00
	3	0.000
	4	0.0000
605		Load cell sensitivity selection (mV/V) for Scale A
	0	4.00 mV/V
	1	3.76 mV/V
	2	3.52 mV/V
	3	3.28 mV/V
	4	3.04 mV/V
	5	2.80 mV/V
	6	2.56 mV/V
	7	2.32 mV/V
	8	2.08 mV/V
	9	1.84 mV/V
	10	1.60 mV/V
	11	1.36 mV/V
	12	1.12 mV/V
	13	0.88 mV/V
	14	0.64 mV/V
15	0.40 mV/V	
606		Load cell type for Scale-1
	0	500g/5kg twin load cell
	1	2.5g/25 kg twin load cell

Table 6-2. Weight and Measurement Specification Settings

SPEC	Option	Description
607	A/D Board type for Scale-1	
	0	Normal
	1	Prevent from small vibration/fast change in display
	2	Prevent from medium vibration
	3	Prevent from large vibration/slow change in display
608	External Scale B connection	
	0	Disable
	1	Enable
609	Minimum display (increment) for Scale B	
	0	2
	1	1
	2	5
	3	10
610	Weight decimal point position for Scale B	
	0	0
	1	0.0
	2	0.00
	3	0.000
	4	0.0000
611	Load cell sensitivity selection (mV/V) for Scale B	
	0	4.00 mV/V
	1	3.76 mV/V
	2	3.52 mV/V
	3	3.28 mV/V
	4	3.04 mV/V
	5	2.80 mV/V
	6	2.56 mV/V
	7	2.32 mV/V
	8	2.08 mV/V
	9	1.84 mV/V
	10	1.60 mV/V
	11	1.36 mV/V
	12	1.12 mV/V
	13	0.88 mV/V
	14	0.64 mV/V
15	0.40 mV/V	
612	Load cell type for Scale B	
	0	Standard/Normal load cell
	1	Abnormal load cell with large offset
613	A/D Board type for Scale B	
	0	Normal
	1	Prevent from small vibration/fast change in display
	2	Prevent from medium vibration
	3	Prevent from large vibration/slow change in display
614	External Scale C connection	
	0	Disable
	1	Enable

Table 6-2. Weight and Measurement Specification Settings (Continued)

SPEC	Option	Description
615	Minimum display (increment) for Scale C	
	0	2
	1	1
	2	5
	3	10
616	Weight decimal point position for Scale C	
	0	0
	1	0.0
	2	0.00
	3	0.000
617	Load cell sensitivity selection (mV/V) for Scale C	
	0	4.00 mV/V
	1	3.76 mV/V
	2	3.52 mV/V
	3	3.28 mV/V
	4	3.04 mV/V
	5	2.80 mV/V
	6	2.56 mV/V
	7	2.32 mV/V
	8	2.08 mV/V
	9	1.84 mV/V
	10	1.60 mV/V
	11	1.36 mV/V
	12	1.12 mV/V
	13	0.88 mV/V
	14	0.64 mV/V
15	0.40 mV/V	
618	Load cell type for Scale C	
	0	Standard/Normal load cell
	1	Abnormal load cell with large offset
619	A/D Board type for Scale B	
	0	Normal
	1	Prevent from small vibration/fast change in display
	2	Prevent from medium vibration
	3	Prevent from large vibration/slow change in display
620	Tare range settings	
	0	100% Full Scale
	1	<50% Full Scale
	2	<5% Full Scale
621	Digital tare setting	
	0	Disable
	1	Enable
622	Digital tare accumulation	
	0	No
	1	Yes
623	Priority of tare operation	
	0	One touch tare priority
	1	Digit tare priority

Table 6-2. Weight and Measurement Specification Settings (Continued)

SPEC	Option	Description
624	Tare subtraction	
	0	Yes
	1	No
625	Tare addition	
	0	Yes
	1	No
626	Tare value exchange	
	0	Yes
	1	No
627	Zero tracking when tare	
	0	Yes
	1	No
628	Tare when scale swap	
	0	Old tare
	1	Clear tare
629	Weight reset when tare	
	0	Yes
	1	No
630	Auto clear tare when rezero	
	0	No
	1	Yes
631	Initial start range settings	
	0	+Unlimited-10% full scale
	1	± 2% Full scale
	2	+/- 10% Full scale
632	Zero range settings	
	0	+Unlimited-10% full scale
	1	+/- 2% Full scale
	2	+/- 10% Full scale
633	Zero lamp lighting method	
	0	Gross weight
	1	Net weight
634	Rezero when changing scale	
	0	No Rezero
	1	Rezero
635	Stability check when changing scale	
	0	Stability check
	1	No stability check
636	Internal count protected by Span Switch	
	0	No
	1	Span Switch protect
637	Calibration/default SPEC/SPEC142 mode protected by Span Switch	
	0	Span Switch protection
	1	No protection
638	Display at minus weight	
	0	Minus gross <= 9e
	1	Minus gross weight mask

Table 6-2. Weight and Measurement Specification Settings (Continued)

SPEC	Option	Description
639		Masked display at minus weight
	0	Gross weight
	1	Net weight
640		Over weight masked
	0	At + 1D
	1	At + 9D
641		Selection of scale starting method
	0	Auto start
	1	Manual start
642		Kg/lb lamp inhibit
	0	No
	1	Yes
643		Gross mode display
	0	Yes
	1	No
644		Selection of decimal point type
	0	Period display
	1	Comma display
646		Automatic unit weight clear conditions
	0	Disable
	1	Over Net 5D & Gross 21D & weight stable
	2	>= Net 1D & weight stable
	3	>= Net 1D & quantity >0 & weight stable
700		Version display when power on
	0	Allow
	1	Inhibit
702		Angle rotation for certain items printing
	0	Counter clockwise
	1	Clockwise
703		Net/gross multi interval
	0	Gross multi-interval
	1	Net multi-interval
704		Manual clear of tare
	0	Allow
	1	Inhibit
705		Password setting
	0	Allow
	1	Inhibit

Table 6-2. Weight and Measurement Specification Settings (Continued)



© Rice Lake Weighing Systems Specifications subject to change without notice.
Rice Lake Weighing Systems is an ISO 9001 registered company.

230 W. Coleman St. • Rice Lake, WI 54868 • USA

U.S. 800-472-6703 • Canada/Mexico 800-321-6703 • International 715-234-9171 • Europe +31 (0)26 472 1319