




Operating Instructions

# Sartorius Combics 3

Models CAISL3 | CAIS3  
Indicators



# Contents

<b>Contents</b> .....	2
<b>Notes on Using this Manual</b> .....	3
Symbols and Signs .....	3
<b>Warning and Safety Instructions</b> .....	4
Safety .....	4
Installation .....	4
IP Protection Rating .....	4
Use in Legal Metrology .....	4
<b>Device Description</b> .....	5
Description .....	5
Intended Use .....	5
<b>General View of the Equipment</b> .....	6
<b>Getting Started</b> .....	7
Storage and Shipping Conditions .....	7
Installation Location .....	7
Unpacking .....	7
Checking Package Contents .....	7
Acclimatizing the Device .....	7
Equipment Downtime .....	7
Connecting a Weighing Platform .....	7
Connecting a Weighing Platform to WP 1 .....	8
Connecting a Weighing Platform to WP 2 .....	9
Interface Pin Assignments COM1, COM2 and PS2 with Options .....	10
Interface Pin Assignment Chart COM1 .....	11
Connecting a PC via Interface COM1 .....	12
Interface Pin Assignment Chart COM2 .....	13
Connecting a PC via Interface COM2 .....	14
Pin Assignments .....	14
Interface Pin Assignment Chart PS2 .....	15
Connecting a Barcode Scanner via the PS2 Interface .....	15
Closing the Combs Indicator .....	16
Power Connection .....	16
Safety Precautions .....	16
Warm-up Time .....	16
Using a Verified Device in Legal Metrology .....	16
<b>Configuring Weighing Platforms</b> .....	17
Service Mode .....	17
Overview of the Setup Menu in Service Mode .....	18
Setup Menu for ADC Configuration .....	20
Analog/Digital Converter .....	21
Setting Parameters for ADC Configuration .....	21
Analog/Digital Converter (ADC) Configuration .....	23
Entering Geographical Data for Use in Legal Metrology .....	27
Entering Adjustment and Linearization Weights .....	32
Function Allocation of the  Key for Calibration/Adjustment .....	33
External Calibration/Adjustment with Factory-Defined Weight (Default Weight) .....	34
External Calibration/Adjustment with a User-Defined Weight .....	36
Internal Calibration/Adjustment .....	37
Adjustment Without Weights .....	38
Function Allocation of the  Key for Linearization and Setting/Deleting the Preload .....	40
External Linearization with Factory-Defined Weights (Default Weights) .....	41
External Linearization with User-Defined Weights .....	42
Setting the Preload .....	44
Deleting the Preload .....	45
<b>Operating Design</b> .....	46
Weighing Mode Operating Design .....	46
Saving Settings in Weighing Mode .....	48
Applying the Tare Weight .....	48
Input Through the Digital Control Port .....	48
Display in Weighing Mode .....	49
LEDs .....	50
Error Codes .....	50
Menu Operating Design .....	51
Menu Display .....	51
Saving Menu Settings .....	51
Configuration .....	52
Setup Overview (Parameters) .....	56
<b>Operation</b> .....	69
Weighing .....	69
Adjustment/Configuration Counter for Standard Scales .....	72
Device Parameters .....	73
Calibration and Adjustment .....	79
Configuration for Use in Legal Metrology .....	79
External Calibration and Manual Adjustment with Default Weights (Weighing Parameters: Factory Settings) .....	81
SQmin Function .....	83
SQmin Operation .....	84
Data ID Codes .....	86
Using individual ID codes .....	87
<b>Data Interfaces</b> .....	88
Specifications .....	89
Connection Options .....	90
Configuring the Data Interface as a COM Port .....	91
Setting the SBI Data Output .....	92
Data Input Format .....	92
Data Output Format .....	94
External Keyboard Functions (PC Keyboard) .....	97
Configuring the Data Interface as a Printer Port .....	98
Printout Configuration .....	99
GMP-compliant Printouts .....	100
Sample Printouts .....	101
<b>Error Codes</b> .....	104
<b>Care and Maintenance</b> .....	105
Service .....	105
Repairs .....	105
Cleaning .....	105
Cleaning Stainless Steel Surfaces .....	106
Replacing the Dust Cover .....	106
Safety Inspection .....	106
<b>Disposal</b> .....	107
<b>Specifications</b> .....	108
ADC Scale Interface 2*3000e (Option A8) .....	108
ADC Scale Interface 10,000e (Option A10) .....	109
<b>Device Dimensions</b> .....	110
<b>Accessories</b> .....	111
<b>Documents and Services</b> .....	114
Documents List .....	114
Sartorius Services .....	114
<b>Declaration of Conformities</b> .....	115
<b>EC type-approval Certificate</b> .....	118
<b>Test Certificate</b> .....	119
<b>Plates and Markings</b> .....	120
<b>Appendix: Guide to Verification of Weighing Instruments</b> ..	124
<b>Appendix: General Password</b> .....	127

# Notes on Using this Manual

- ▶ Please read this entire manual carefully and completely before using the device.
- ▶ Read the safety precautions carefully.
- ▶ This manual is part of the product. Keep it in a safe and easily accessible location.
- ▶ If the manual should be lost or misplaced, please contact Sartorius for a replacement or download the latest manual from our website: [www.sartorius.com](http://www.sartorius.com)

## Symbols and Signs

The following symbols are used in this manual:



### Warning symbol for various types of dangers.

These symbols are explained in more detail in the “Safety Instructions” section.

---



This symbol indicates useful information and tips.

---



This symbol indicates notes on use in legal metrology within the scope of validity of Council Directive No. 90/384/EEC, replaced by 2009/23/EC (models MS...-CE...).

---



This and similar symbols mean that the respective key should be pressed.



This means that this key must be pressed more than once.

- ▶ Indicates a required action
- ▷ Describes the result of an action
- 1. If a procedure has multiple steps...
- 2. ... the steps are numbered consecutively.
- Indicates an item in a list



### Technical advice/hotline:

Phone: +49.551.308.4440  
Fax: +49.551.308.4440

# Warnings and Safety Instructions

## Safety

Combics indicators comply with the European Council Directives as well as international regulations and standards for electrical equipment, electromagnetic compatibility, and the stipulated safety requirements. Improper use or handling can, however, result in damage and/or injury.

- ▶ Read these operating instructions carefully before use. This will prevent damage to the equipment.
- ⚠ Do not use this device in hazardous areas.
- ⚠ The device may only be opened by trained service technicians.
- ⚠ Disconnect the device from power before connecting or disconnecting peripheral devices.
- ⚠ If you operate the device under ambient conditions subject to higher safety standards, you must comply with any applicable installation regulations.

## Installation

- ⚠ Caution when using pre-wired RS-232 connecting cables: RS-232 cables purchased from other manufacturers often have pin assignments that are incompatible with Sartorius products. Be sure to check the pin assignments against the chart in this manual before connecting the cable, and disconnect any lines identified differently from those specified by Sartorius.
- ⚠ Use only standard cables that have protective grounding conductors. The protective conductor must not be disconnected for any reason.
- ⚠ If there is visible damage to the device or power cord: unplug the device and secure it against further use.
- ⚠ Connect only Sartorius accessories and options, as these are optimally designed for use with your device. Therefore, do not use any proprietary solutions. The operator shall be solely responsible for installation and testing of any modifications to Sartorius equipment, including connection of cables or equipment not supplied by Sartorius. Information on operational quality (in line with norms pertaining to immunity) is available on request.
- ▶ If you have any problems with your device, contact your local Sartorius office, dealer or service center.

## IP Protection Rating

- CAISL models are rated to IP44 (with option L1: IP65)
- CAIS models are rated to IP69K.
- The IP65/IP69K protection rating is ensured only if the rubber gasket is installed and all connections are fastened securely (including the caps on unused sockets). Weighing platforms must be installed and tested by a certified technician.
- If you install an interface port or battery connection after setting up your indicator, keep the protective cap in a safe place for future use. The cap protects the interface connector from vapors, moisture and dust or dirt.

## **M** Use in Legal Metrology

- When the indicator is connected to a weighing platform and this equipment is to be verified, ensure that the applicable regulations regarding verification are observed. Please read and observe the "Guide to Verification" on the enclosed CD.
- When connecting Sartorius platforms, observe the permitted weighing range as listed in the "Guide to Verification of Weighing Instruments" and the Declaration of Conformity.
- A sticker with the "Sartorius" logo was affixed to the indicator as a control seal following verification. This seal will be irreparably damaged if you attempt to remove it. This will nullify the verification's validity. In this case, re-verification would be required in compliance with all relevant national regulations and laws.

## Description

Combics 3:

- Is robust and durable, thanks to its stainless steel housing.
- Is easy to clean and disinfect.
- Is easy to operate, thanks to the following features:
  - Large, backlit, fully graphical dot-matrix display
  - Large keys with positive click action
  - Alphanumeric character entry
  - Plain-text user guidance
- Can be operated independently of the weighing platform location.
- Has a range of interfaces for flexible use.
- Has optional password protection for operating parameters.

Combics 3 speeds up your routine procedures with:

- Automatic initialization when the scale is switched on.
- Fast response times.
- Automatic taring when a load is placed on the weighing platform.
- Independence from location of platform installation.
- Designation of weight values with up to 4 lines of alphanumeric text.
- Flexibility afforded by diversity of interfaces.
- Security through password protection.
- Can be controlled via two external computers using various protocols.
- Barcode scanner connection option for entering tare value or IDs (6 units).
- Ability to input tare values via the number keys.
- LED for measurement range identification.
- Connection option for a second weighing platform.
- Alibi memory.
- Configurable printout.
- Flex print

## Intended Use

The Combics 3 indicator is a robust indicator for daily quality control in industrial applications. It was designed for suitable scales or weighing platforms that correspond to the described technical specifications. Any other use beyond this is considered improper.



# Installation

When an indicator is ordered with special equipment, the desired options come pre-installed from the factory.

## Storage and Shipping Conditions



Unpacked devices can lose their precision if subject to extreme vibrations. Excessive vibrations may compromise the safety of the equipment.

- 
- Do not expose the equipment to unnecessarily extreme temperatures, moisture, shocks, blows or vibration.
  - Permissible storage temperature: -10 ... +40 °C

## Installation Location

Avoid adverse influences at the place of installation:

- Extreme temperatures (operating temperature: -10 ... +40 °C)
- Aggressive chemical vapors
- Extreme moisture (according to IP protection class)

## Unpacking

- ▶ After unpacking the device, check it for any visible damage as a result of rough handling during shipment.
- ▷ If you detect any damage, proceed as directed in the chapter entitled “Care and Maintenance” under “Safety Inspection.”
- ▶ Save the original packaging for any future transport. Unplug all connected cables before packing the equipment.

## Checking Package Contents

- Indicator
- Operating instructions
- Options (special accessories) as listed on the bill of delivery

## Acclimatizing the Device

Condensation can form on the surfaces of a cold device when it is brought into a substantially warmer area.

- ▶ Allow the device to acclimatize for about 2 hours at room temperature, leaving it unplugged from AC power.

## Equipment Downtime

Switch off the equipment when not in use.

## Connecting a Weighing Platform

See the chapter entitled “Getting Started.”



Make absolutely sure that the device is unplugged from the power supply before connecting/disconnecting any peripheral device (e.g. printer, PC) to or from the data interface.

---

# Getting Started

## Steps

- 1.) Connect weighing platform to the indicator.
- 2.) Configure the analog/digital converter (ADC): see chapter “Configuring Weighing Platforms, section “Setting Parameters for ADC Configuration.”
- 3.) Carry out a calibration/adjustment: Adjustment/Calibration, see chapter “Configuring Weighing Platforms”, section “Eternal Calibration/Adjustment” and linearization, see chapter “Configuring Weighing Platforms”, section “External Linearization”.
- 4.) Connect peripheral devices, e.g. printer to the COM1 or UNICOM interface: see the chapter entitled “Data Interfaces.”

## Connecting Weighing Platforms to WP1

An analog Sartorius platform (CAPP, CAPS, IU or IF) or a commercially-available DMS load cell can be connected to the Combics indicator WP1 input.




The load cell should be connected by a certified technician who has received specialized training from Sartorius. Any installation work that does not conform to the instructions in this manual results in forfeiture of all claims under the manufacturer’s warranty.



Peripheral devices should be connected by a certified technician who has received specialized training from Sartorius. Any installation work that does not conform to the instructions in this manual results in forfeiture of all claims under the manufacturer’s warranty.



Disconnect the equipment from the power supply before starting connection work.



- ▶ Set up the weighing platform (see Operating instructions for the weighing platform).
- ▶ Place the cable from the weighing platform next to the indicator.
- ▶ Open the Combics indicator:  
Loosen the 10 cap nuts on the front panel. Remove the front panel.

## Installing Connection and Interface Cables



The cable gland (IP69K protection) is pre-mounted on the indicator. Please use extreme caution when performing any work on the equipment that affects this cable gland. You must use a torque wrench. The torque for this cable gland is 5 Nm.



## Preparing the Cable

- ▶ Strip approx. 14 cm from the end of the cable.
- ▶ Shorten the shielding to approx. 2 cm and pull back over the insulation.
- ▶ Strip approximately 5 mm of the insulation from the wires of the connecting cable and affix ferrules to the wire ends.




# Getting Started


## Attaching the Cable Entry



Please use extreme caution when performing any work on the equipment that affects this cable gland. You must use a torque wrench. The torque for this cable gland is 5 Nm.



- ▶ Remove the protective cap from the bore hole on the indicator.
- ▶ Insert the included cable gland through the bore hole and secure from the inside using the locknut (1).



- ▶ Insert the cable through the cable gland until the shielding (2) comes into contact with the clamps (3). Tighten the screw-down nut (4) until the gasket (5) inserted between the screw-down nut and cable forms a small beaded rim.
- ▶ Check the shielding and clamps.


- ▶ Securely connect the wires of the connecting cable in accordance with the terminal assignments.
- ▶ After you close the housing again, use a pressure gauge to check the integrity of the IP69K protection. For details, contact the Sartorius Service Center.

## Connecting Cables

- ▶ Insert all cable wires through the ferrite case, wind them around the ferrite case and then reinsert back through the ferrite case.
- ▶ Screw the wires tightly into the clamps.

## See the following pages for pin assignment

- ▶ Refer to the data sheet or operating instructions of the weighing platform for details on the assignment of wire colors/signals. Ensure any lines that are not assigned are insulated correctly.
- ▶ When connecting a load receptor that uses 4-conductor technology (the cable of the weighing platform to be connected only has 4 lines), connect clamp pairs 1 and 2 (EXC+ und SENSE+), and 5 and 6 (SENSE- und EXC-) with a wire jumper.



## Connecting Weighing Platforms to WP2

An IS platform can be connected to the WP2 connection of the Combics indicator.

### Features

- IS weighing platforms process weighing data independently of the indicator.
- Internal calibration/adjustment option
- IS...-OCE models: have a separate approval number, printed on a tag that is affixed to the cable.
- Please observe the conditions described in the manual for the weighing platform you connect.

# Getting Started

## Interface Pin Assignments COM1, COM2 and PS2 with Options

### Digital PCB CAIS3 (IP69K)

COM1, COM2 and PS2 terminal assignments (applies to all PCBs)

1 LOAD_PRINTER	11 Clear to Send (CTS)	<b>PS2</b>
2 RESET_OUT	12 Data Terminal Ready (DTR)	21 5 V switched
3 GND	13 Data Input (RXD)	22 PS2_Daten
4 GND	14 Data Output (TXD)	23 PS2_Timer
5 5V_OUT	15 GND	24 GND
6 5V switched	16 Universal In	<b>COM2</b>
7 GND	17 Control Output: "lighter"	31 CTS_COM2
8 GND	18 Control Output: "equal"	32 DTR_COM2
9 Schirm	19 Control Output: "heavier"	33 RXD_COM2
10 LINE_OUT	20 Control Output: "set"	34 TXD_COM2
		35 GND
		36 GND

A8 terminal assignments

1 EXC+	Bridge supply voltage (+)
2 SENSE+	Sense (+) for bridge supply voltage
3 OUT+	Measuring voltage positive
4 OUT-	Measuring voltage negative
5 SENSE-	Sense (-) for bridge supply voltage
6 EXC-	Bridge supply voltage (-)

Keypad

LED + Display

### Interface PCB for RS-232/RS-485 for IS platforms (option A6/A7)

A6/A7 terminal assignments

1 CTS	11 TxD/RxD+
2 DTR	12 TxD/RxD-
3 RxD	13 LINE_OUT
4 TxD	14 LINE_OUT
5 GND	15 GND
6 Calibration Lock	16 GND

Keypad

LED + Display




### Interface PCB for ADC 10.000e (option A20)

A20 terminal assignments


1 EXC+
2 SENSE+
3 OUT+
4 OUT-
5 SENSE-
6 EXC-

Keypad

LED + Display



# Getting Started



## Interface PCB for RS-232/RS-485 for IS platforms (option A62/A72)

### A62/A72 terminal assignments

1 CTS	11 TxD/RxD+
2 DTR	12 TxD/RxD-
3 RxD	13 LINE_OUT
4 TxD	14 LINE_OUT
5 GND	15 GND
6 Calibration Lock	16 GND

Keypad  
LED + Display

## Interface Pin Assignment Chart COM1

### Model type CAISL (IP44 protection)

COM1 female connectors:


25-pin D-Submini female connector (DB25S) with screw lock hardware for cable gland

Recommended interface connector:

25-pin D-Submini (DB25) with shielded cable clamp assembly and shield plate (Amp type 826 985-1C) and fastening screws (Amp type 164868-1)

Pin assignment:

Pin 1	Shield
Pin 2	Data output (TxD)
Pin 3	Data input (RxD)
Pin 4	Internal ground (GND)
Pin 5	Clear to Send (CTS)
Pin 6	Not assigned
Pin 7	Internal ground (GND)
Pin 8	Internal ground (GND)
Pin 9	Not assigned
Pin 10	Not assigned
Pin 11	+12 V for printer
Pin 12	\RES_OUT
Pin 13	+5 V Switch
Pin 14	Internal ground (GND)
Pin 15	Universal switch
Pin 16	Control output: "lighter"
Pin 17	Control output: "equal"
Pin 18	Control output: "heavier"
Pin 19	Control output: "set"
Pin 20	Data Terminal Ready (DTR)
Pin 21	Ground power supply (GND)
Pin 22	Not assigned
Pin 23	Not assigned
Pin 24	Power supply +15...25 V (peripherals)
Pin 25	+5 V




# Getting Started

## Connecting a PC via Interface COM1


Use the following cables to connect a PC to the indicator in accordance with the RS-232C/V24 standard (max. cable length 15 m):


- Model type CAISL: connecting cable 7357312
- Model type CAIS: connecting cable YCC02-D9F6



## Pin Assignment

Pin assignments for the cable from the indicator to an RS-232 PC interface (COM1).





## Interface Pin Assignment Chart COM2

### Model type CAISL (IP-44 protection)

COM2 female connectors:

9-pin D-Submini female connector (DB9S) with screw lock hardware for cable gland

Recommended interface connector:

9-pin D-Submini (DB9) with shielded cable clamp assembly and shield plate and fastening screws (Amp type 164868-1)

Pin assignment:


Pin 1	+5 V out
Pin 2	Data output (TxD)
Pin 3	Data input (RxD)
Pin 4	Clear to Send (CTS)
Pin 5	Internal ground (GND)
Pin 6	Reset
Pin 7	Not assigned
Pin 8	Data Terminal Ready (DTR)
Pin 9	Load Printer

# Getting Started

## Connecting a PC via Interface COM2

Use the following cables to connect a PC to the indicator in accordance with the RS-232C/V24 standard (max. cable length 15 m):

- Model type CAISL: connecting cable 7357312
- Model type CAIS: connecting cable YCC02-D9F6




## Pin Assignment

Pin assignments for the cable from the indicator to an RS-232 PC interface (COM2).


### Indicator side

Model type CAISL  
9-pin D-Sub male connector




### PC side


D-Sub plug 9-pin or D-Sub socket 25-pin




Model type CAIS  
Open cable end



D-Sub plug 9-pin or D-Sub socket 25-pin





## Interface Pin Assignment Chart PS2

### Model type CAISL (IP-44 protection)

PS2 female connector:

6-pin miniature socket PS2 (Mini-DIN)

Recommended interface connector:

6-pin miniature socket PS2 with integrated shielded cable clamp assembly

Pin Assignments:

Pin 1	Keyboard data (data interface cable)
Pin 2	Not assigned
Pin 3	Internal ground (GND)
Pin 4	+5 V switched
Pin 5	Keyboard clock
Pin 6	Not assigned

## Connecting a Barcode Scanner via the PS2 Interface

Accessory YBR02CISL



- ▶ Disconnect the indicator from AC power (unplug the AC adapter).

For model type CAISL:

- ▶ Connect the barcode scanner via PS/2.


For model type CAIS:

- ▶ Pin assignment, see “Interface Connection Assignments COM1, COM2 and PS2” (implemented via the YCC02-BR02 connecting cable or as option M8).

# Getting Started

## Closing the Combics Indicator

- ▶ Re-attach the front panel and secure it with the 10 cap nuts.



## Connecting the Device to AC Power

The indicator is powered through the pre-installed power cord. The power supply is integrated into the indicator. The device can be operated with a supply voltage of 100 to 240 V.



The power connection must be made in accordance with the regulations applicable in your country.

Make sure that the voltage rating printed on the manufacturer's ID label is identical to that of your local line voltage. If the voltage specified on the label or the plug design of the AC adapter do not match the rating or standard you use, please contact your Sartorius office or dealer.



- ▶ Check the voltage rating and plug design.
- ▶ The device must be plugged into a properly installed wall outlet.



### Protection Class 1 Device

- ▶ The device must be plugged into a properly installed wall outlet which has a protective grounding conductor (PE).


## Safety Precautions



If you use an electrical outlet that does not have a protective grounding conductor, ensure that an equivalent protective conductor is installed by a certified electrician (as specified in the applicable regulations for installation in your country). The protective effect must not be negated by using an extension cord without a protective grounding conductor.

Before using for the first time, any superstructure parts must be completely installed. Avoid connecting the equipment to lines that have a heavy electrical load, e.g. compressors, large machinery, etc.

## Warm-up Time



To deliver exact results, the device must warm up for at least 30 minutes after connection to AC power. Only after this time will the device have reached the required operating temperature.

## Using a Verified Device in Legal Metrology



Ensure that there is a warm-up time of at least 24 hours after connection to the power supply.



# Configuring Weighing Platforms

## Service Mode


### Purpose

The Service mode enables access to additional menu items in the Setup menu which are not displayed when the Service mode is not active. The most important calibration and adjustment work for the indicator and for the connected weighing platform can be carried out in the Service menu, e.g. ADC configuration.


When the Service mode is active, an “S” is shown in the top right-hand corner of the display. To deactivate the Service mode, restart the indicator (turn the indicator off and back on again).

### Activating the Service Mode


- ▶ Press **[ON]** to turn on the device.
- ▶ When turned on the scale is in an application program.
- ▶ Enter the service password (see Appendix General User Password) and press **[SETUP]** to confirm.



- ▶ The device is now in Service mode. An “S” appears in the top right-hand corner of the display.
- ▶ Press the “v” soft key several times to select the “Device parameters” line.



- ▶ Press the “>” soft key.
- ▶ The “Device” submenu will open.



- ▶ Select and open the corresponding submenu. Repeat this procedure until the desired menu item in the lowest menu level can be opened.
- ▶ View or change the menu item (confirm with “↓”) and use “<” to return to the previous menu.
- ▶ Press **[SETUP]** or “<<” to exit the Setup menu.

### Exiting Service Mode

Turn the device off and then on again to return to the normal application mode. If you exit the Setup menu without changing settings by confirming with **[SETUP]** or the “<<” soft key, the Service mode will remain active. Press the **[SETUP]** key to re-open the Setup menu.

# Configuring Weighing Platforms

## Overview of the Setup Menu in Service Mode

o = Factory setting  
x = User-defined setting

Service password entry                      Setup      Application parameters, please refer to the “Basic Application Programs” manual  
Fn key “Setup Overview (Parameters)”  
Device parameters  
Info, see the “Setup Overview (Parameters)” section  
Language, see the “Setup Overview (Parameters)” section

Setup access with service password

Device parameters

WP1

RS-232 <sup>1)</sup>

SBI standard  
SBI verifiable  
o IS-232  
ADC-232

RS-485 <sup>1)</sup>

o IS-485  
ADC-485

Internal

ADC configuration (see the “Setup Menu for ADC Configuration” section)  
Calibration/Adjustment

CAL key function

o Ext. cal./adj.; factory-def. wt.  
Ext. cal./adjust.; user-defined weight  
Ext. lineariz.; factory-def. wts  
Ext. lineariz.; user-def. wts  
Set preload  
Delete preload  
Key blocked

Cal./adj. sequence

Cal. then auto adjust  
o Cal. then manual adjust

isoCAL function <sup>3)</sup>

o Off  
Adjustment prompt

Activate external adjustment <sup>2)</sup>

o Activated  
Deactivated

Parameter for external weight

Cal./adj. weight:  
Lin. weight 1...4:

Adjust without weights <sup>2)</sup>

Input parameters

Nominal load:  
Resolution:  
Sensitivity 1...4:

Save parameters

Yes  
o No

Geographical data <sup>2)</sup>

Input parameters

Geographical latitude  
Altitude  
Gravitational  
acceleration

Save parameters

Yes  
o No

<sup>1)</sup> Equipment version: – then blocked internally  
<sup>2)</sup> = Not available on devices verified for use in legal metrology  
<sup>3)</sup> only when operated with Sartorius IS weighing platforms or an external ADC

# Configuring Weighing Platforms

## Device Parameters

### WP1

#### Internal

Calibration/Adjustment unit

- Grams /g
- Kilograms /kg
- Tons /t
- Pounds /lb

Menu items "Adapt filter" - "Factory settings: only bal. func," see the "Setup Overview (Parameters)" section

Off

COM-1 (when the WP is assigned to this interface)

COM-2 (when the WP is assigned to this interface)

UNICOM (only if available)

WP2, see the "Setup Overview (Parameters)" section

RS-232 <sup>1)</sup> similar to "Internal" menu for WP1

RS-485 <sup>1)</sup> similar to "Internal" menu for WP1

Off

COM-1 similar to WP 1

COM-2 similar to WP 1

COM-1, see the "Setup Overview (Parameters)" section

COM-2, see the "Setup Overview (Parameters)" section

"Control I/O ports" - "Terminal data," see the "Setup Overview (Parameters)" section

### SQmin

#### SQmin input

SQmin WP1

SQmin WP1

0.000 kg

SQmin WP2

SQmin WP2

0.000 kg

SQmin WP3

SQmin WP3

0.000 kg

#### Display

No

Yes

#### GMP print

No

Yes

### Alibi memory <sup>2)</sup>

#### Clear alibi memory

Yes

No

#### Alibi memory period

In days

90

<sup>1)</sup> Equipment version: - then saved internally

<sup>2)</sup> Only if alibi memory is available (option)

# Configuring Weighing Platforms

## Setup Menu for A/D Converter Configuration

Setup access in Service mode

WP1 - Internal - ADC configuration	Standard configuration	Ranges	Single-range mode	Scale interval d Max. cap.
			Multi-interval mode	Scale interval d Range 1 Range 2 Range 3 Max. cap.
			Multiple-range mode	Scale interval d Range 1 Range 2 Range 3 Max. cap.
		Available units	User-definable /o Grams /g Kilograms /kg Carats /ct ...	
		Save parameters	Yes oNo	
oVerifiable configuration	Accuracy class	Class III/III		
	Ranges	Single-range mode		D: E: Min. capacity: Max. cap.:
		Multi-interval mode		D: E: Min. capacity: Range 1: Range 2: Range 3: Max. cap.:
		Multi-interval mode		D: E: Min. capacity: Range 1: Range 2: Range 3: Max. cap.:
	Available units	User-definable /o oGrams /g oKilograms /kg ...		
	Save parameters	Yes oNo		

# Configuring Weighing Platforms

## Analog/Digital Converter (ADC)

### Purpose

Adjust the parameters of the analog/digital converter to the connected load cell or weighing platform. After ADC configuration, the ADC in connection with the load sensor is defined as a scale.



Once the ADC configuration has been locked, the indicator can no longer be used to influence weighing results. The scope of functions available in the weighing instrument is defined by the A/D converter. Weighing functions that can be activated include reading weight values, taring, adjustment, reading the tare value, saving/deleting the tare entry.

### Setup information

- ADC configuration is only possible when the menu access switch is open. Re-close the menu access switch after ADC configuration.
- Before ADC configuration, you must first set whether or not the weighing platform will be used as a standard or verifiable weighing platform.
- ADC configuration is carried out in the Service mode in the Setup menu under “**WP 1**” for the first weighing platform and “**WP 2**” for the second.
- Entries made in ADC configuration will not be affected by a menu reset (returning the setup parameters to their factory settings).

See also the overview in the “Setup Menu for A/D Converter Configuration” section.

## Setting Parameters for ADC Configuration

### Standard or Verifiable Configurations

In ADC configuration, you must first select whether the weighing platform should be configured as a standard or verifiable (for use in legal metrology) weighing platform.

- Standard configuration “**Standard**”
- Verifiable configuration “**Verifiable**”

Select using the “**∧**” or “**∨**” soft key. Press the “**➤**” soft key to confirm the setting and open the Configuration menu.

### Accuracy class

This menu item is not shown when the Standard configuration is active. When the Verifiable configuration is active (for weighing platforms verified or verifiable for use in legal metrology), only Class **III/III** can be selected. Activate the “**Accuracy class**” menu item, select “**Class III/III**” and confirm your selection using the “**↓**” soft key.

### Ranges

The capacity of the weighing platform can be divided into multiple ranges:

- “**Single-range mode**”:  
The entire weighing range is divided into scale intervals on the basis of the lowest interval d and the maximum load.
- “**Multi-interval mode**”:  
The “Multi-interval mode” function divides the weighing capacity into as many as four ranges, each with a different readability. Corresponding changes take place automatically. Once the scale has been tared, the highest possible resolution is available even if the weighing platform is loaded with a higher weight. This is only permitted in the accuracy classes **III/III** for the verifiable configuration.
- “**Multiple-range mode**”:  
Multiple-range mode has two or three weighing ranges. When the range limit is exceeded, the scale switches into the next highest weighing range (lower resolution) and remains there. The scale can be returned to the lower weighing range (higher resolution) only by pressing the **↔0←** key and then unloading the scale.

Select the desired configuration using the “**∧**” or “**∨**” soft key. Confirm your selection using the “**➤**” key. Make additional settings in the submenu: scale interval d/verification scale interval e, minimum load (Verifiable configuration only), range limits (Multi-interval or Multiple range mode only) and maximum capacity. Confirm using the “**↓**” soft key or cancel using “**Esc.**”

# Configuring Weighing Platforms

## Scale interval d

Scale interval d indicates the resolution of the weighing instrument.

The scale interval d can be entered only in increments of 1, 2, 5, 10, 20, etc.

When using verifiable or verified weighing platforms, the scale interval d is the same as the verification scale interval e.

## Verification scale interval e

The verification scale interval e indicates the resolution of the weighing instrument in legal metrology. The verification scale interval e can be entered only in increments of 1, 2, 5, 10, 20, etc. For weighing instruments of accuracy class (III) or (IIII),  $e = d$ . This is why the scale interval d does not need to be entered separately.

When "Standard configuration" is used, this menu item is not displayed.

## Minimum capacity (min. cap.)

When "Standard configuration" is used, this menu item is not displayed. The minimum load of the connected weighing platform is entered under this menu item.

The minimum load for scales of accuracy class (III) is  $20e$  and  $10e$  for class (IIII).

**Important Note:** The function of the minimum load setting is to warn operators that below this limit, the summation of tolerances might lead to significant measurement errors. In Germany, for example, initial weights below the minimum load are not allowed.

## Maximum capacity (Max. cap.)

The maximum capacity is the maximum load that may be placed on the weighing instrument. When heavier weights are used the weighing instrument displays overload "H." The scale intervals of the weighing instrument are calculated using the maximum load and the scale interval d (e.g. max. capacity = 15.000 kg, smallest scale interval  $d = 0.005$  kg yields 3000 scale intervals).

In legal metrology the total number of intervals must be no more than 3000 e, and when using multi-interval scales there must not be more than 3000 e intervals per range.

In standard operation, as opposed to legal metrology, you can define a "Super Range" weighing instrument of over 3000 intervals. These parameters, however, may be influenced by physical restrictions.

## Range 1, Range 2, Range 3

The range limits are entered for the individual ranges. The accuracy changes when these limits are exceeded. The following applies when entering limits: range 1  $\leq$  range 2  $\leq$  range 3  $\leq$  maximum capacity.

This means that the weighing range can be divided into a maximum of 4 ranges. The resolution changes at intervals of 1, 2, 5, 10, 20 etc., where the lowest resolution is the smallest scale interval entered. Set ranges that are not required for use to zero.

## Available units

With this function, you can make particular weight units (weight unit x,  $x=1, 2$ ) inaccessible during weighing. Available units are indicated by a \* on the display (more than one can be selected).

To enable or disable a unit, select the unit by pressing the "∧" or "∨" soft key, and then press the "↕" soft key (toggle function).

## Saving parameters

To save the ADC configuration, use the "➤" soft key to select "YES" and confirm with the "↕" soft key. The device software is reset, and the scale returns to the normal weighing mode. To exit the menu without saving configuration changes, press the "◀" soft key.

Once these parameters have been configured, the A/D converter in conjunction with the load cell(s) is defined as a weighing instrument. The A/D converter, in conjunction with the weighing platform, can now be used like any standard weighing platform. In addition, the weight unit must be defined and the weighing platform adjusted (calibration, adjustment and linearization must be performed). For a detailed description of these procedures, see the "Adjustment in Service Mode" section.

# Configuring Weighing Platforms

## Analog/Digital Converter (ADC) Configuration

The weighing platform must already be connected.

### Open the menu access switch

The menu access switch is located on the back of the indicator right next to the weighing platform connection.







- ▶ Remove the cap.
- ▶ Slide the switch to the left (= "open" position).

### Activating the Service Mode

- ▶ See "Service Mode" on page 17.

### Configuration

- ▶ Select weighing platform "WP 1."
- ▶ If the "Internal" setting is not already activated (marked by "o"), select the setting using the "∧" or "∨" soft key and confirm with ">."
- ▶ The message "Function active" appears briefly. The "WP 1 internal" menu will then open.



- ▶ Open the ADC Configuration menu.
- ▶ Select the desired configuration data record using the "∧" or "∨" soft key: "Standard" or "Verifiable" (verifiable configuration). The default setting depends on the data record.

- ▶ Open the menu for configuring A/D converter parameters. In this example, the menu for ADC configuration of a weighing platform for use in legal metrology is opened. If "Standard" was selected previously, then the "Accuracy class" is not displayed.

- ▶ Open the first menu item. For a standard configuration, the "Ranges" menu item, for a verifiable configuration, the "Accuracy class" menu item.

When the "Verifiable" configuration is active, always select the "Accuracy class" menu item first.

- ▶ Set accuracy class III/IIII. The "o" symbol should mark the setting, if required confirm using the "∨" soft key.
- ▶ Press the "<" soft key to exit the menu item. Open the "Ranges" menu item.

In the example shown here, "Single range mode" has been selected (marked by "o").

- ▶ To select a different weighing range configuration, use the "∧" or "∨" soft key to select the corresponding line and open the selected menu using the ">" soft key.
- ▶ The selected weighing range configuration is now active. When you return from the input menu for entering the weighing range parameters, the new range configuration is marked by a "o."

For more information about range configuration, please see "Setting Parameters for ADC Configuration."

# Configuring Weighing Platforms

The default values displayed depend on the data record loaded and might have to be changed. In the example shown here, the A/D configuration is set with a "Verifiable" data record in single-range mode.

LEGAL	RANGES	SINGLE RG	S
E:		0.001 kg	
Min cap:		0.010 kg	
Max. cap:		6.000 kg	

## Single-range mode

- ▶ Select the individual input fields using the "↵" or "⏏" soft key.
- ▶ For numeric input: use the [0] ... [9] keys and the [.] key (decimal point). Make corrections using [CF].
- ▶ Confirm using the "↓" soft key.  
If other parameters follow the one just entered, the highlight bar is automatically positioned on the next input field.  
To cancel numbers entered: press the "ESC" soft key.
- ▶ Use the "<" soft key to go to the next menu level.
- ▷ This will apply all parameters.
- ▶ Press [SETUP] or "<<" to exit the Setup menu.

[0] [.] [0] [0] [2]

In the example shown here, a single-range scale in "Verifiable" configuration with a maximum capacity of 6.000 kg is modified; the verification scale interval e is changed from 0.001 kg to 0.002 kg, in accordance with the maximum permitted value of 3000 verification scale intervals. Press the "↓" soft key to confirm the changed value. The highlight bar is automatically positioned on the "Min. cap." field.

The following values apply for the minimum load for verifiable scales:

- For class (III): Min. cap. = 20 e
- For class (II): Min. cap. = 10 e

A verification scale interval that is changed, therefore, also affects the minimum load. Changing the verification scale interval "e" is automatically applied to the "Min. cap." You can also change this value manually:

In the example, the minimum capacity must be increased to 0.04 kg for class (III).

- ▶ Press the following keys in sequence: [0] [.] [0] [4] [0] and confirm using the "↓".
- ▷ The highlight bar is automatically positioned on the "Max. cap." field.
- ▶ The value for the maximum capacity is not changed. For this example, the input of parameters for single-range mode in the "Verifiable" configuration is now concluded.
- ▶ Use the "<" soft key to go to the next menu level.

LEGAL	RANGES	SINGLE RG	S
E:		0.002 kg	
Min cap:		0.020 kg	
Max. cap:		6.000 kg	



# Configuring Weighing Platforms

LEGAL	RANGES	MULTI-INT.	S
E:		0.001 kg	
Min cap:		0.010 kg	
Range 1:		3.000 kg	
Range 2:		0.000 kg	
Range 3:		0.000 kg	
Max. cap:		6.000 kg	
<<	<	v	

INTERNAL	ADC CONF.	LEGAL	S
Accuracy class			
Ranges			
Available units			
Save configuration data			
<<	<	v	>

ADC CONF.	LEGAL	UNITS	S
User-definable /o			
Grams /g		*	
Kilograms /kg		*	
Carats /ct			
Pounds /lb			
Ounces /oz			
Troy ounces /ozt			
Hong Kong taels /tlh			
Singapore taels /tls			
Taiwanese taels /tit			
<<	<	^	v

DEVICE	WP 1	INTERNAL	S
ADC configuration			
Calibration/adjustment			
Adapt filter			
Application filter			
Stability range			
Stability delay			
Taring			
Autozero			
Weight unit 1			
Display accuracy 1			
<<	<	v	>

WP 1	INTERNAL	CAL./ADJ.	S
CAL key function			
Cal/adj. sequence			
Parameter for external weight			
Geographical data			
Calibration/adjustment unit			
<	^	>	

INTERNAL	CAL./ADJ.	CAL UNIT	S
Grams /g			
Kilograms /kg			
Tons /t			
Pounds /lb			

INTERNAL	ADC CONF.	LEGAL	S
Accuracy class			
Ranges			
Available units			
Save configuration data			
<	^	>	

## Multi-interval mode

The illustration shows an example of the input menu opened for multi-interval mode range configuration. This example shows the parameters for a scale in “Verifiable” configuration, with 2 weighing ranges and a maximum capacity of 6.000 kg.

- Range 1: 0...3.000 kg with e1 = 0.001 kg
- Range 2: 3.002...6.000 kg with e2 = 0.002 kg
- ▶ Enter the verification scale interval for Range 1 in the “E” input field. The minimum capacity for a class  $\text{III}$  scale must be set to 0.02 kg.
- ▶ Use the “<” soft key to go to the next menu level.
- ▶ The active range configuration is marked with “o.”
- ▶ Use the “<” soft key to go back to the “Verifiable” menu.

## Selecting units

- ▶ Use the “v” and “>” soft key to open the “Available units” menu item. This menu lets you enable or disable the weight units available under “Weight unit 1,” “Weight unit 2” and “Weight unit 3.”
- ▶ Select the respective unit using the “^” or “v” soft key and confirm using the “↓” soft key.




In most cases, you will not need to change defined values. Available weight units are marked by a \*.

The weight unit used for configuration of weighing ranges cannot be blocked.

- ▶ Use the “<” soft key to go back to the “Internal” menu.
- ▶ Use the “v” and “>” soft key to open the “Calibration/adjustment” menu.
- ▶ Use the “v” and “>” soft key to open the “Calibration/adjustment unit” menu item to define the weight unit for calibration and adjustment. In most cases, you will not need to change defined values.
- ▶ All units are displayed in the menu that are activated in “Available units.” The current setting is marked by a “o.”

- ▶ To change the calibration/adjustment unit, select the unit using the “^” or “v” soft key and confirm using the “↓” soft key.
- ▶ Use the “<” soft key to go back to the “Internal” menu.
- ▶ Use the “^” soft key to select the “ADC configuration” menu item.
- ▶ Use the “>” and “v” soft key to select the “Save configuration data” menu item.


# Configuring Weighing Platforms



- ▶ To save the configuration, use the “ $\wedge$ ” soft key to select “Yes” and confirm using the “ $\downarrow$ ” soft key.
- ▷ The message “Function activated” appears briefly. The program then returns automatically to the regular weighing mode.
  - To not save the configuration:
    - ▶ Press the “ $\leftarrow$ ” soft key to exit the menu.
    - ▷ The program returns to the next higher menu level.
      - To not save data: Press the “ $\leftarrow$ ” soft key. The program returns to the **WP1: Internal**.
    - ▶ Slide the menu access switch to the right (= “closed” position) and reattach the cap.
    - ▷ The device is now in normal weighing mode.



Once ADC configuration has been completed, an adjustment of the weighing platform (calibration/adjustment and linearization) must be carried out (see “Calibration/Adjustment without Weights” and “External Linearization”).



The displays depicted in the next two illustrations on the left show data from a multi-interval scale configured as described above, or a similarly configured multiple-range scale.

If the A/D converter was configured with a “Verifiable” data record, the lines for display of metrological data (lines 1 and 2) show the data valid for use in legal metrology.

The current range (e.g. **R 1**) is displayed top left under the weighing point for multiple-range scales.

## ADC Configuration with Load Cell(s) Connected

Procedure:

1. Open the menu access switch, see “Analog/Digital Converter (ADC) Configuration.”
2. Activate the Service mode, see “Service Mode.”
3. Configure WP 1, see “Analog/Digital Converter (ADC) Configuration.”
4. Set single-range mode, for example, see “Analog/Digital Converter (ADC) Configuration.”
5. Select the units, see “Analog/Digital Converter (ADC) Configuration.”
6. Adjust without weights, see “Adjust without weights.”
7. Set/Delete the preload, see “Setting the Preload” and “Deleting the Preload.”

## Entering Geographical Data for Use in Legal Metrology

### Purpose

Entering geographical data allows the external adjustment of weighing equipment at a place (e.g. at the manufacturer or vendor's place of business) that is not the same as the place of installation. If the weighing equipment is adjusted at the place of installation, it is not necessary to enter geographical data.

The sensitivity of weighing equipment changes depending on the place of installation as it is dependent on the on-site gravitational force – or, more precisely, on gravitational acceleration. Saving geographical data makes it possible to change the place of installation of the weighing equipment after external adjustment has been carried out.

The adjustment of weighing equipment is valid at the place of installation and within a specific tolerance zone. At 3000 e this zone extends  $\pm 100$  km from the set geographical latitude and  $\pm 200$  m from the set elevation above sea level.

### Installation Location in Germany

An exception to this is the setting for “Germany (Zone D):” If during external adjustment of weighing equipment within Germany the geographical data

- Geographical latitude: 51.00 degrees
- 513 m elevation above sea level

are entered, the weighing equipment can be used throughout Germany. Gravitational acceleration for “Germany (Zone D)” is  $9.810 \text{ m/s}^2$ . On delivery the geographical data for “Germany (Zone D)” are entered in the output device.

It is recommended to use the geographical data settings for “Germany (Zone D)” when adjusting and delivering the weighing equipment within Germany.

Entering exact geographical data will lead to a higher level of accuracy but will also restrict the tolerance zone.

### Setup information

- It is only possible to enter geographical data when the menu access switch is open.
- When the Service mode is active, geographical data can be entered in the Setup menu under “WP 1” for the first weighing platform and “WP 2” for the second. Settings are made in the “Calibration/adjustment: Geographical data: Input parameters” menu.
- You can enter either the “latitude” (geographical latitude in degrees) and “altitude” (elevation in m above sea level) or the value for gravitational acceleration “gravity”

Gravitational acceleration takes precedence over the geographical latitude and elevation of the location: If it has been entered, input fields for latitude and elevation show the values “99999.99” and “9999999” respectively. If only elevation and latitude have been entered, “0000000” is displayed for gravitational acceleration.



Then make sure that the geographical data for the adjustment location has been entered correctly. If no external adjustment is carried out, enter the data for the installation location. The data can be obtained from the relevant land registry or Ordnance Survey.

---

# Configuring Weighing Platforms

SETUP	DEVICE	S	
WP 1			
WP 2			
COM 1			
COM 2			
Control I/O ports			
Bar code			
Config. printout			
Operating parameters			
Clock			
Test I/O ports			
<<	<	v	>

DEVICE	WP 1	INTERNAL	S
ADC configuration			
Calibration/adjustment			
Adapt filter			
Application filter			
Stability range			
Stability delay			
Taring			
Autozero			
Weight unit 1			
Display accuracy 1			
<<	<	v	>

WP 1	INTERNAL	CAL./ADJ.	S
CAL key function			
Cal/adj. sequence			
Parameter for external weight			
Geographical data			
Calibration/adjustment unit			
<	^	v	>

INTERNAL	CAL./ADJ.	GEOGR.DATA	S
Input parameters			
Save parameters			

CAL./ADJ.	GEOGR.DATA	PARAMETER	S
Latitude:	51.53		
Altitude:	151		
Gravit.acc.:	0.000000		

CAL./ADJ.	GEOGR.DATA	PARAMETER	S
Latitude:	99999.99		
Altitude:	9999999		
Gravit.acc.:	0.000000		

## Procedure

- ▶ Remove the cap.
- ▶ Slide the menu access switch to the left (= "open" position).  
If the device is part of a verified weighing facility, this will only be possible if the verification seal is broken. The weighing equipment must then be verified again.
- ▶ Activate the Service mode, see "Service Mode."
- ▶ Select weighing platform "WP 1" in the "Device Parameters" menu item.
- ▶ If the "Internal" setting is not already activated (marked by "o"), select the setting using the "v" or "v" soft key and confirm with ">."
- ▷ The menu for the "WP-1 INTERNAL" device parameters is displayed.

- ▶ Use the "v" or "v" soft key to select and open the "Calibration/adjustment" menu using ">."

- ▶ Use the "v" or "v" soft key to select and use ">" to open the "Geographical data" menu.

- ▶ Use the ">" soft key to confirm "Input parameters."




## Entering Geographical Latitude and Elevation

- ▶ Use the "v" or "v" soft key to select the corresponding input field.
- ▶ Enter the number via the keypad and confirm using the "↓" soft key.
- ▷ The next input field is selected.

In this example, the geographical data are entered for the respective platform as a value pair "Latitude" and "Altitude." After this data was saved and the scale returned to weighing mode, this pair of values is displayed again the next time the display menu is opened. The input field for gravitational acceleration is empty.

In this example, the value for gravitational acceleration is entered for the place of installation. The fields "Latitude" and "Altitude" are invalid. The set value is then re-displayed after it is saved and the input menu is re-opened. If you exit the Setup menu and then open the Service mode, the set value for gravity is no longer displayed.

# Configuring Weighing Platforms



## Entering Gravity


- ▶ Use the “^” or “v” soft key to select the corresponding input field.
- ▶ Enter gravity in m/s<sup>2</sup> via the keypad and confirm using the “↵” soft key.  
Permissible value range:  
9.700000 d < gravity 2 d < 9.900000  
In the example shown here, the value for gravity has been changed.  
The new value, 9.810000 m/s<sup>2</sup> applies to the setting “Germany (Zone D).”
- ▶ Press the “<” soft key to exit the Input menu.
- ▶ Use the “^” soft key to select the “Save parameters” menu item.
  
- ▶ Use the “^” soft key to select “Yes” and use the “↵” soft key to confirm.
- ▶ The message “Data stored” appears briefly.  
The program then returns to the “No” display status.
- ▶ Press **SETUP** or “<<” to exit the Setup menu.
- ▶ Slide the menu access switch to the right (= “closed” position) and reattach the cap.
- ▶ The display goes out and the device restarts. Then weighing mode is active.

## Adjusting Scales in Operating Mode


- See also “Calibration and Adjustment” in the chapter called “Operation”
- ▶ Open the Device parameters menu for the respective weighing platform, (e.g. “WP 1: INTERNAL”).
    - Open the “Calibration/adjustment” submenu.
    - “CAL key function” menu item:  
Setting “Ext. cal./adj.: factory-def. wt.” (factory setting).
    - “Cal/adj. sequence” menu item:  
Setting “Cal. then manual adj.” (factory setting).
    - “Activate ext. adj.” menu item  
(not for a verifiable configuration):  
Setting “Activated” (factory setting).

To display geographical data in the Device parameters menu, open the “Operating parameters” submenu.  
Menu item “Display geogr. data > On”.
  - ▶ Press **⇐0⇐** to unload the scale.


# Configuring Weighing Platforms



- ▶ Press **ISO-Test** to start an external adjustment.




- ▶ The display “C.EXT.D” appears briefly. In the example, the altitude and latitude of the installation location are being entered.




- ▶ The display “Altitud” appears briefly.



- ▶ The altitude at the place of installation is displayed in meters above sea level - here, the altitude for “Germany (Zone D).”
- ▶ Press **ISO-Test** to confirm the displayed value or press **→0←** to cancel the adjustment.



- ▶ The display “Latitud” appears briefly.




- ▶ The geographical latitude of the place of installation is shown in degrees north or degrees south - here the latitude setting for “Germany (Zone D).”
- ▶ Press **ISO-Test** to confirm the displayed value or press **→0←** to cancel the adjustment.




- ▶ You are prompted to place the required weight on the platform (e.g.: 5.0 kg). The subsequent steps for completing the calibration/adjustment are described in the chapter entitled “Operation” under “Calibration and Adjustment.”

# Configuring Weighing Platforms



If gravity is being entered instead of altitude and latitude, then “Gravity” is displayed for a brief time after “CAL.”



The entered value appears in  $m/s^2$ , here for the “Germany (Zone D)” setting.

- ▶ Press  $\boxed{\text{ISO-Test}}$  to confirm the displayed value or press  $\boxed{\rightarrow 0 \leftarrow}$  to cancel the adjustment.




- ▶ You are prompted to place the required weight on the platform (e.g.: 5.0 kg). The subsequent steps for completing the calibration/adjustment are described in the chapter entitled “Operation” under “Calibration and Adjustment.”

- ▶ Slide the menu access switch to the right (= “closed” position) and reattach the cap.



- ▶ The display goes out and the device restarts. Then weighing mode is active.



If adjustment is carried out using a verifiable configuration data record, the lines for display of metrological data (lines 1 and 2) show the data valid for use in legal metrology, if the menu access switch is closed. See also the chapter “Operation”, “Configuration for Use in Legal Metrology.”

# Configuring Weighing Platforms

## Entering Adjustment and Linearization Weights

### Purpose

Entering adjustment and linearization weights.

### Procedure

See also “Calibration and Adjustment” in the chapter called “Operation”.

- ▶ Remove the cap.
- ▶ Slide the menu access switch to the left (= “open” position).
- ▶ Activate the Service mode, see “Service Mode.”
- ▶ Select weighing platform “WP 1” in the “Device Parameters” menu item.
- ▶ If the “Internal” setting is not already activated (marked by “o”), select the setting using the “^” or “v” soft key and confirm with “>.”
- ▷ The menu for the “WP-1 INTERNAL” device parameters is displayed.

- ▶ Use the “^” or “v” soft key to select and open the “Calibration/adjustment” menu using “>.”

- ▶ Use the “^” or “v” soft key to select and use “>” to open the “Parameter for external weight” menu.

- ▶ The first menu item “Cal/adj. wt. :” (for selecting the user-defined calibration weight), is also accessible without activating the Service mode. The values for the linearization weights “Lin.-wt. 1” to “Lin.-wt. 4” can, however, only be changed in the Service mode.
- ▷ The current values for the user-defined calibration weight and the 4 linearization weights are displayed.

In this example, the value for the external, user-defined adjustment weight is changed to 6.000 kg.

- ▶ Press      and confirm with the “↓” soft key.

- ▷ The “Lin.-wt. 1” input field is selected.

In this example, the value for linearization weight 1 is changed to 1.500 kg.

- ▶ Press      and confirm with the “↓” soft key.

- ▷ The “Lin.-wt. 2” input field is selected.

- ▶ Enter or change all linearization weights in sequence as needed.

If you do not require all linearization positions, enter “0.000” in the unused fields to hide these lines in the display. Confirm with the “↓” soft key after each entry to move to the next input field.

In the example shown here, four linearization weights have been entered (1.5 kg, 3.0 kg, 4.5 kg and 6.0 kg).

When you close the input menu by pressing the “<” soft key, the input values are directly applied.

- ▶ Slide the menu access switch to the right (= “closed” position) and reattach the cap.

SETUP	DEVICE	S
WP 1		
WP 2		
COM 1		
COM 2		
Control I/O ports		
Bar code		
Config. printout		
Operating parameters		

DEVICE	WP 1	INTERNAL	S
ADC configuration			
Calibration/adjustment			
Adapt filter			
Application filter			
Stability range			
Stability delay			
Taring			
Outzero			

WP 1	INTERNAL	CAL./ADJ.	S
CAL key function			
Cal/adj. sequence			
Parameter for external weight			
Geographical data			
Calibration/adjustment unit			

INTERNAL	CAL./ADJ.	EXT.WEIGHT	S
Cal/adj. wt. :	5.000	kg	
Lin. wt.1:	2.000	kg	
Lin. wt.2:	4.000	kg	
Lin. wt.3:	0.000	kg	
Lin. wt.4:	6.000	kg	

INTERNAL	CAL./ADJ.	EXT.WEIGHT	S
Cal/adj. wt. :	5.000	kg	
Lin. wt.1:	1.500	kg	
Lin. wt.2:	4.000	kg	
Lin. wt.3:	0.000	kg	
Lin. wt.4:	6.000	kg	

INTERNAL	CAL./ADJ.	EXT.WEIGHT	S
Cal/adj. wt. :	5.000	kg	
Lin. wt.1:	1.500	kg	
Lin. wt.2:	0.000	kg	
Lin. wt.3:	6.000	kg	
Lin. wt.4:	2.000	kg	


INTERNAL	CAL./ADJ.	EXT.WEIGHT	S
Cal/adj. wt. :	5.000	kg	
Lin. wt.1:	1.500	kg	
Lin. wt.2:	3.000	kg	
Lin. wt.3:	4.500	kg	
Lin. wt.4:	6.000	kg	



# Configuring Weighing Platforms

## Function Allocation of the allocation for the Key for Calibration/Adjustment

### Purpose

The  key is used for the calibration/adjustment function. Key settings can be changed when the Service mode is activated:

### Procedure

- ▶ Remove the cap.
- ▶ Slide the menu access switch to the left (= "open" position).
- ▶ Activate the Service mode, see "Service Mode."
- ▶ Select weighing platform "WP 1" in the "Device Parameters" menu item.
- ▶ If the "Internal" setting is not already activated (marked by "o"), select the setting using the "▲" or "▼" soft key and confirm with ">."
- ▶ The menu for the "WP-1 INTERNAL" device parameters is displayed.

```

SETUP      DEVICE      S
-----
WP 1
WP 2
COM 1
COM 2
Control I/O ports
Bar code
Config. printout
Operating parameters
    
```

```

DEVICE    WP 1      INTERNAL  S
-----
ADC configuration
Calibration/adjustment
Adapt filter
Application filter
Stability range
Stability delay
Autozero
Weight unit 1
    
```

```

WP 1      INTERNAL  CAL./ADJ.  S
-----
CAL key function
Cal/adj. sequence
Activate ext. adj.
Parameter for external weight
Adjust without weights
Geographical data
Calibration/adjustment unit
    
```

```


INTERNAL  CAL./ADJ.  C/A SEQ  S
-----
Cal. then auto adj.
oCal. then manual adj.
    
```

```

INTERNAL  CAL./ADJ.  EXT.ADJ.  S
-----
oActivated
Deactivated
    
```

- ▶ Use the "▲" or "▼" soft key to select and open the "Calibration/adjustment" menu using ">."
- ▶ Use the ">" soft key to open the "Cal/adj. sequence" menu.
- ▶ Use the "▲" or "▼" soft key to select the "Cal. then manual adj." menu (factory setting) and confirm with the "↓" soft key.
- ▶ Use the "<" soft key to go to the next menu level.
- ▶ Use the ">" soft key to open the "Activate ext. adj." menu.
- ▶ Use the "▲" or "▼" soft key to select the "Activated" menu item (factory setting). Not for a verifiable configuration.
- ▶ Geographical data is not displayed during calibration/adjustment (factory setting).  
To display geographical data in the Device parameters menu, open the "Operating parameters" submenu.  
Menu item "Display geogr. data > On".

# Configuring Weighing Platforms



- ▶ Use the “>” soft key to open the **CAL key function** menu.
- ▷ The “**CAL key function**” submenu is displayed.
- ▶ Use the “^” or “v” soft key to select the corresponding menu item and confirm with “↓.”
- ▷ The menu item is marked by a circle “o.”


### Note

The functions that can be configured in the “**CAL key function**” submenu depends on the selected weighing platform and its configuration data. Functions that cannot be accessed are not displayed in the selection screen.

### Important Note!

The function set in the “**CAL key function**” menu is carried out in the normal weighing mode because when you exit the Setup menu the Service mode is deactivated. To perform the function on a digital weighing platform (such as an IS platform), however, it must be carried out in Service mode.

- ▶ The procedure is as follows: after selecting the desired function and exiting the Setup menu, reactivate Service mode again and then exit the Setup menu immediately by pressing the **SETUP** key or the “<<” soft key.
- ▷ The scale is now in Service mode without this being displayed.
- ▶ Trigger the previously set function using the **ISO-Test** key.
- ▷ The display shows “**S-CAL:**” indicating that the scale is in Service mode.
- ▶ The corresponding menu item can be selected using the “**Select**” soft key and carried out using the **ISO-Test** key.
- ▶ If you cancel the function using the **→0←** key or by restarting the scale using the **I/O** key, you will exit the Service mode.



## External Calibration/Adjustment with Factory-Defined Weight (Default Weight)

### Configuration

If not already selected (factory setting, marked by “o” when active), select the “**CAL key function:Ext. cal./adj.: factory-def. wt.**” menu item (external adjustment with a factory-defined, standard weight).

- ▶ Use the “^” or “v” soft key to select this menu item and confirm with “↓.”
- ▷ The menu item is marked by a circle “o.”

### Note:


The menu items “**Ext. cal./adj.: factory-def. wt.**” (external adjustment with a factory-defined, standard weight), “**Ext. cal./adj.: user-defined wt.**” (external adjustment with a user-defined weight) and “**Key blocked**” can also be accessed without activating the Service mode.

- ▶ Press **I/O** to turn off the device.
- ▶ Press **I/O** turn the device back on.
- ▷ The Sartorius logo is displayed briefly, after which the device is in normal weighing mode.
- ▶ Press **→0←** to unload and zero the scale.
- ▶ Press **ISO-Test** to start the external adjustment.

- ▷ The display “**C-EXT-D**” appears briefly.

### Note

If the display of geographical data (elevation and latitude or gravity) is activated, this data is displayed and confirmed each with a press of the **ISO-Test** key (you can cancel the calibration/adjustment process using the **→0←** key). See also “Entering Geographical Data for Use in Legal Metrology” in this chapter.




# Configuring Weighing Platforms



## Procedure

- ▷ The target value of the required adjustment weight (5.000 kg in the example) is displayed as a negative value.
- ▷ Place the required adjustment weight on the platform.

## Note

If the calibration/adjustment sequence is set to automatic ("Calibration/adjustment:Cal./adj. sequence:Cal., then auto adjust" menu, see "Function Allocation of the allocation of the  Key for Calibration/Adjustment") and the adjustment weight consists of several pieces, then they should be placed on the platform in series at short intervals.


When the weighing instrument has stabilized, the weight on the scale is accepted as the calibration weight after a predefined interval, and the weighing instrument is calibrated/adjusted with this weight.


The difference since the most recent span adjustment is not displayed; this value is output only on GMP-compliant printouts.


- ▷ After a brief pause, the difference since the last span adjustment is displayed (calibration).

## Note

This display only appears for the "Cal. then manual adj." setting (see previous note). If "Cal. then auto adj." is active, the calibration/adjustment procedure cannot be cancelled.

To stop the procedure after calibration and before adjustment takes place, press the  key (only if "Cal. then manual adj." is active).

- ▷ Press  to adjust the scale (only if "Cal. then manual adj." is active).
- ▷ At the conclusion of the calibration procedure, the calibration weight is displayed as a positive value.





```
-----
14.01.2010    13:50
Type CAW3P1-6DC-LCE
Ser.no.      12345678
Vers.no.     1.02.101110
BVers.       01-63-02
-----
```

```
External calibration
Nom. +      5.000 kg
Diff. +     0.010 kg
External adjustment
Diff. +     0.000 kg
-----
```

```
14.01.2010    13:52
Name:
```

When calibration/adjustment is complete, the GMP-compliant printout shown on the left is generated. If the adjustment procedure is canceled (only calibration is performed), the last two lines, "External calibration" and "Diff. + 0.000 kg" are not printed.

- ▷ Unload the scale.
- ▷ Press  to turn off the device.
- ▷ Press  turn the device back on.
- ▷ The Sartorius logo is displayed briefly, after which the device is in normal weighing mode.



If a serious operator error should occur during calibration (for example, if the menu setting "Cal. then auto adj." is active and the wrong calibration weight is placed on the scale), the scale might completely fail to stabilize, which means it cannot show a zero point.

In this case, select the "Adjust without weights" menu and set the mean sensitivity of the strain-gauge weighing beam to 2.0 mV/V.

Then re-adjust the scale.

See also "Adjust without weights."

The zero point is only displayed for a verified scale with d=e.

# Configuring Weighing Platforms

## External Calibration/Adjustment with a User-Defined Weight

### Configuration

Select the "CAL key function:Ext. cal./adj.; user-def. wt." menu item (external adjustment using a user-defined weight).

### Note:

The menu items "Ext. cal./adj.; factory-def. wt." (external adjustment with a factory-defined, standard weight), "Ext. cal./adj.; user-defined wt." (external adjustment with a user-defined weight) and "Key blocked" can also be accessed without activating the Service mode.





- ▶ Use the "▲" or "▼" soft key to select this menu item and confirm with "↵."
- ▷ The menu item is marked as set by a circle "o."
- ▶ Enter the target value of the adjustment weight in the "Calibration/adjustment" menu under "Parameter for external weight" in the "Cal/adj. wt" input field.
- ▶ Press to turn off the device.
- ▶ Press turn the device back on.
- ▷ The Sartorius logo is displayed briefly, after which the device is in normal weighing mode.
- ▶ Press to unload and zero the scale.
- ▶ Press to start the external adjustment.
- ▷ The display "C·EXT·U" appears briefly.

### Note

If the display of geographical data (elevation and latitude or gravity) is activated, this data is displayed and confirmed each with a press of the key (you can cancel the calibration/adjustment process using the key). See also "Entering Geographical Data for Use in Legal Metrology" in this chapter.

### Procedure



- ▶ Press to confirm the displayed value or press to cancel the adjustment.
- ▷ The target value of the required adjustment weight (6.000 kg in the example) is displayed as a negative value.
- ▶ Place the required adjustment weight on the platform.  
If the calibration/adjustment sequence is set to "Cal. then auto adjust", refer to the note under "External Calibration/Adjustment with Factory-Defined Weight (Default Weight)."
- ▷ After a brief pause, the difference since the last span adjustment is displayed (calibration).
- ▶ If you only want to perform a calibration, press the key to cancel the calibration/adjustment procedure.
- ▶ Press to adjust the scale.
- ▷ At the conclusion of the calibration procedure, the calibration weight is displayed as a positive value.



# Configuring Weighing Platforms

```
-----  
14.01.2010    13:50  
Type CAW3P1-6DC-LCE  
Ser.no.    12345678  
Vers.no. 1.02.101110  
BVers.    01-63-02  
-----  
External calibration  
Nom. +    6.000 kg  
Diff. +    0.010 kg  
External adjustment  
Diff. +    0.000 kg  
-----  
14.01.2010    13:52  
Name:
```

When calibration/adjustment is complete, the GMP-compliant printout shown on the left is generated. If the adjustment procedure is canceled (only calibration is performed), the last two lines, "External calibration" and "Diff. + 0.000 kg" are not printed.

- ▶ Unload the scale.
- ▶ Press  to turn off the device.
- ▶ Press  turn the device back on.
- ▶ The Sartorius logo is displayed briefly, after which the device is in normal weighing mode.



If a serious operator error should occur during calibration (for example, if the menu setting "Cal. then auto adj." is active and the wrong calibration weight is placed on the scale), the scale might completely fail to stabilize, which means it cannot show a zero point.

In this case, select the "Adjust without weights" menu and set the mean sensitivity of the strain-gauge weighing beam to 2.0 mV/V.

Then re-adjust the scale.

See also "Adjust without weights."

## Internal Calibration/Adjustment

This function is available only if a digital weighing platform (for example, an IS platform) is connected to WP 1, either as a second weighing platform or as the only weighing platform without using the built-in A/D converter WP 1. The connection can be made both via the COM1, COM2 or UNICOM interface with a corresponding configuration as well as via the expansion PCBs for WP 1 or WP 2.

This function is also accessible without activating the Service mode.

# Configuring Weighing Platforms

## Adjustment Without Weights

### Purpose

In the Service menu, adjustment without weights can be carried out by entering the characteristic data of the load cells.



Adjustment without weights may not be carried out on weighing equipment used in legal metrology.

### Setup information

- Adjustment without weights is only possible when the menu access switch is open in the Service mode.
- The “Nominal load” parameter must be entered in the “kg” unit.
- The “Resolution” parameter must be entered in the “kg” unit and must correspond to the scale interval “d” entered for the ADC configuration.
- The “Sensitivity” parameter is entered in “mV/V” (see the data sheet for the value).



These values are converted to internal quantities. Once the ADC configuration data have been stored (by selecting the “Save parameters” menu item), these parameters can no longer be read.

### Procedure

- ▶ Remove the cap.
- ▶ Slide the menu access switch to the left (= “open” position).
- ▶ Activate the Service mode, see “Service Mode.”
- ▶ Select weighing platform “WP 1” in the “Device Parameters” menu item.
- ▶ If the “Internal” setting is not already activated (marked by “o”), select the setting using the “^” or “v” soft key and confirm with “>.”

```
SETUP      DEVICE      S
WP 1
WP 2
COM 1
COM 2
Control I/O ports
Bar code
Config. printout
Operating parameters
```

- ▶ The menu for the “WP-1 INTERNAL” device parameters is displayed.
- ▶ Use the “^” or “v” soft key to select and open the “Calibration/adjustment” menu using “>.”

```
DEVICE    WP 1      INTERNAL  S
ADC configuration
Calibration/adjustment
Adapt filter
Application filter
Stability range
Stability delay
Autozero
Weight unit 1
```


- ▶ Use the “^” or “v” soft key to select and use “>” to open the “Adjust without weights” menu.

```
WP 1      INTERNAL  CAL./ADJ.  S
CAL key function
Cal/adj. sequence
Activate ext. adj.
Parameter for external weight
Adjust without weights
Geographical data
Calibration/adjustment unit
```

- ▶ Use the “>” soft key to open the “Input parameters” menu.

```
INTERNAL  CAL./ADJ.  ADJ.W/O WT  S
Input parameters
Save parameters
```

# Configuring Weighing Platforms



- ▶ The Input menu is displayed.

Enter the nominal capacity and resolution of the load cells in kg and the sensitivity of the load cells in mV/V in the corresponding input fields. The maximum capacity is usually less than the value to be entered in the “Adjust without weights” menu for the nominal capacity of the load cell, as load cells carry additional weight (e.g., a weighing platform).

If the weighing platform has multiple load cells, multiply the nominal capacity accordingly.

Example:

The weighing platform has 4 load cells each at 50 kg.

The nominal capacity is  $4 \times 50 \text{ kg} = 200 \text{ kg}$ .

In the example shown here, the weighing platform consists of one load cell with a maximum capacity of 10 kg.

- ▶ Press **100.000** and confirm with the “↓” soft key.

- ▶ The “Resolution” input field is selected.

The smallest digit “d” is entered in this field in “kg”. The value must correspond to the “D” entry in “ADC configuration: Standard: Ranges: Single-range mode.”

In the example, this should be  $d = 0.002 \text{ kg}$ .

- ▶ Press **0.002** and confirm with the “↓” soft key.

- ▶ The “Sensitivity 1” input field is selected.

If the weighing platform has multiple load cells, enter the sensitivity either

- under “Sensitivity 1” ... “Sensitivity 4” as an individual value or
- under “Sensitivity 1” as an average value.

If an average value is entered for all cells, or if fewer than 4 load cells are present, enter “0” in the remaining fields. Range of permitted values: 0.01...5 mV/V.

- ▶ Press **1.944**, e.g. to enter a sensitivity of 1.944 mV/V.


- ▶ Confirm using the “↓” soft key.

- ▶ The “Sensitivity 2” input field is selected.



- ▶ Either enter a value or set all remaining input fields to “0.”

- ▶ Confirm each using the “↓” soft key.

- ▶ Press the “<” soft key to exit the menu.



- ▶ Use the “v” soft key to select the “Save parameters” submenu.



- ▶ To save the configuration, select “Yes” and confirm using the ↓ soft key.

In the first line of the display, the message “Data stored” is shown briefly. Then the program then returns to the “No” display status.

- ▶ Use the “<” to return to the next menu level.

- ▶ Press **SETUP** or “<<” to exit the Setup menu.


- ▶ Slide the menu access switch to the right (= “closed” position) and reattach the cap.

- ▶ The display goes out and the device restarts. Then weighing mode is active.

# Configuring Weighing Platforms


## Function Allocation of the Key for Linearization and Setting/Deleting the Preload

### Purpose

The  key is normally used for the calibration/adjustment function. The following additional functions can be allocated to the key when the Service mode is activated:

- External linearization with default weights
- External linearization with entered linearization weights
- Internal linearization (for external IS platforms only)
- Set preload
- Delete preload



Once linearization has been completed, or after a preload has been set or deleted the function of the  key must be reallocated back to its original function in the Setup menu, e.g. external calibration/adjustment with default weights.

### Procedure






- ▶ Remove the cap.
- ▶ Slide the menu access switch to the left (= "open" position).
- ▶ Activate the Service mode, see "Service Mode."
- ▶ Select weighing platform "WP 1" in the "Device Parameters" menu item.
- ▶ If the "Internal" setting is not already activated (marked by "o"), select the setting using the "▲" or "▼" soft key and confirm with "→."
- ▷ The menu for the "WP-1 INTERNAL" device parameters is displayed.
- ▶ Use the "▲" or "▼" soft key to select and open the "Calibration/adjustment" menu using "→."
- ▷ The "CAL key function" submenu is displayed.
- ▶ Use the "▲" or "▼" soft key to select the corresponding menu item and confirm with "↓."
- ▷ The menu item is marked by a circle "o."


### Note

The functions that can be configured in the "CAL key function" submenu depends on the selected weighing platform and its configuration data. Functions that cannot be accessed are not displayed in the selection screen.

### Note

The function set in the "CAL key function" menu is carried out in the normal weighing mode because when you exit the Setup menu the Service mode is deactivated. To perform the function on a digital weighing platform (such as an IS platform), however, it must be carried out in Service mode.

- ▶ The procedure is as follows: after selecting the desired function and exiting the Setup menu, reactivate Service mode again and then exit the Setup menu immediately by pressing the  key or the "←←" soft key.
- ▷ The scale is now in Service mode without this being displayed.
- ▶ Trigger the previously set function using the  key.
- ▷ The display shows "S\_CAL:" indicating that the scale is in Service mode.
- ▶ The corresponding menu item can be selected using the "Select" soft key and carried out using the  key.
- ▶ If you cancel the function using the  key or by restarting the scale using the  key, you will exit the Service mode.







# Configuring Weighing Platforms

## External Linearization with the Factory-Defined Weight (Default Weights)



### Setup information

- This function is accessible only if the software and the functionality of the connected weighing platform permit this operation.
- External linearization when weighing in legal metrology is only possible when the menu access switch is open.
- The  key must be assigned the “External linearization” function, see “Function Allocation of the  Key for Linearization and Setting/Deleting the Preload.”
- Activating the display of geographical data has no effect on this function.




Once linearization has been completed, the  key must be reallocated back to its original function in the Setup menu, e.g. external calibration/adjustment with default weights.

### Procedure

- ▶ For scales used in legal metrology, slide the menu access switch to the left (= “open” position).
- ▷ The display goes out and the device restarts. Then weighing mode is active.
- ▶ Press  to unload and zero the scale.
- ▶ Press  to start the external linearization.
- ▷ The display “L . EXT . D” appears briefly.



Additional steps are explained in “External Linearization with User-Defined Weights.”



# Configuring Weighing Platforms

## External Linearization with User-Defined Weights

### Setup information

- This function is accessible only if the software and the functionality of the connected weighing platform permit this operation.
- External linearization when weighing in legal metrology is only possible when the menu access switch is open.
- The  key must be assigned the “External linearization” function, see “Function Allocation of the  Key for Linearization and Setting/Deleting the Preload.”
- Activating the display of geographical data has no effect on this function.






Once linearization has been completed, the  key must be reallocated back to its original function in the Setup menu, e.g. external calibration/adjustment with default weights.



### Configuration

- ▶ Set the linearization weights, see “Entering Adjustment and Linearization Weights.”

### Procedure

- ▶ For scales used in legal metrology, slide the menu access switch to the left (= “open” position).
- ▶ The display goes out and the device restarts. Then weighing mode is active.
- ▶ Press  to unload and zero the scale.
- ▶ Press  to start the external linearization.
- ▶ The display “L .EXT .U” appears briefly.





- ▶ After approx. 2 seconds, the target value for linearization weight 1 is shown as a negative value on the display (in example shown here, 1.500 kg) .
- ▶ Place the required linearization weight 1 on the platform.
- ▶ Press  to apply linearization weight 1 or press  to cancel the linearization function.



- ▶ After a short time the difference between the measured value and the true weight of the sample will be displayed.



# Configuring Weighing Platforms



- ▶ Press  to apply linearization weight 1 or press  to cancel the linearization function.
  - ▷ After the linearization weight 1 has been saved you will be prompted to place the second linearization weight on the weighing pan.
  - ▶ Repeat the procedure for all required linearization weights.
  - ▷ After the last linearization weight has been saved you will be prompted to remove any load from the weighing pan.
  - ▶ Remove all linearization weights from the weighing platform.
  - ▷ The zero point is applied automatically after a brief time. The indicator automatically switches to weighing operation.
- When linearization is complete, the GMP-compliant printout shown on the left is generated.
- ▶ Slide the menu access switch to the right (= "closed" position).

```
-----  
14.01.2010      13:00  
Type  CAW3P1-6DC-LCE  
Ser.no.      12345678  
Vers.no.  1.02.101110  
BVers.      01-63-02  
-----  
Linearization  
Wt.1  +      1.500 kg  
Wt.2  +      3.000 kg  
Wt.3  +      4.000 kg  
Wt.4  +      6.000 kg  
           completed  
-----  
14.01.2010      13:02  
Name :
```


# Configuring Weighing Platforms

## Set preload



### Setup information


- Setting the preload when weighing in legal metrology is only possible when the menu access switch is open.
- The  key must be assigned the “Set preload” function, see “Function Allocation of the  Key for Linearization and Setting/Deleting the Preload.”
- Activating the display of geographical data has no effect on this function.




Once the preload has been set, the  key must be reallocated back to its original function in the Setup menu, e.g. external calibration/adjustment with default weights.

### Procedure

- ▶ For scales used in legal metrology, slide the menu access switch to the left (= “open” position).
- ▶ Press  turn the device back on.
- ▶ The Sartorius logo is displayed briefly, after which the device is in normal weighing mode.
- ▶ Press  to unload and zero the scale.
- ▶ Display after the scale has been zeroed.



- ▶ Place the preload weight on the weighing platform.
- ▶ Press  to start “Set preload.”

- ▶ The display “SET PREL” appears briefly. After a short period of time the preload will be applied and the indicator will automatically switch back to weighing mode. After the “Set Preload” operation has been completed, the scale is zeroed.

When the “Set preload” function is complete, the GMP-compliant printout shown on the left is generated.

- ▶ Slide the menu access switch to the right (= “closed” position).

```
-----  
14.01.2010    13:50  
Type CAW3P1-6ED-LCE  
Ser.no.     12345678  
Vers.no.    1.02.101110  
BVers.      01-63-02  
-----
```



```
Set preload  
                completed
```

```
-----  
14.01.2010    13:52  
Name:  
-----
```

# Configuring Weighing Platforms

## Delete preload



### Setup information

- Deleting the preload when weighing in legal metrology is only possible when the menu access switch is open.
- The  key must be assigned the “Delete preload” function, see “Function Allocation of the  Key for Linearization and Setting/Deleting the Preload.”
- Activating the display of geographical data has no effect on this function.




Once the preload has been deleted, the  key must be reallocated back to its original function in the Setup menu, e.g. external calibration/adjustment with default weights.

### Procedure

- ▶ For scales used in legal metrology, slide the menu access switch to the left (= “open” position).
- ▶ Press  turn the device back on.
- ▶ The Sartorius logo is displayed briefly, after which the device is in normal weighing mode.
- ▶ Remove the preload weight from the weighing platform.
- ▶ The display shows the removed preload weight as a negative value.
- ▶ Press  to start “Delete preload.”



- ▶ The display “CLR PREL” appears briefly. After a short period of time the preload will be deleted and the indicator will automatically switch back to weighing mode.



After the “Delete Preload” operation has been completed, the scale is zeroed.

```

-----
14.01.2010    13:50
Type  CAW3P1-6DC-LCE
Ser.no.    12345678
Vers.no.   1.02.101110
BVers.     01-63-02
-----

```

```

Delete preload
      completed
-----

```

```

14.01.2010    13:52
Name:
-----

```


- ▶ When deleting the preload is complete, the GMP-compliant printout shown on the left is generated.
- ▶ Slide the menu access switch to the right (= “closed” position).

# Operating Design

You can use the Combics 3 to record weight values from 1 to 3 weighing platforms, calculate and display weight values through application programs, and assign IDs to the samples weighed.

Configure the indicator first, using the Setup menu for the desired application program (printer settings, etc.). Then you can begin weighing.
















When a key is pressed that does not have an active operating mode function, an acoustical signal (double beep) sounds and the message “-----” is displayed for 2 seconds. The display then returns to the previous screen content.





## Weighing Mode Operating Design

### Labeled Keys

Some keys have a second function, activated by pressing and holding the key for over 2 seconds. Whether a function is available depends on the indicator operating state and operating menu settings.

-  On/Off key
  - ▶ STANDBY is displayed in Standby mode.
-  If a second weighing platform is connected, this key toggles the display between the two readouts.
-  – Press briefly: Zero
  - Press briefly: cancels calibration/adjustment
  - Press longer than 2 seconds: displays the adjustment/configuration counter
-  Tare the scale: press briefly.
-  Displays the second weight unit or SQmin (depending on the settings, see “Operation,” “SQmin Function”).
-  Starts calibration or adjustment.
-  – For printing:
  - Press briefly.
  - Prints GMP footer:
    - Press longer than 2 seconds.
-  Toggles unit between normal and 10-fold higher resolution.
-  Toggles the display between gross value (net value plus tare) and net value (gross value minus tare).
-  – Zum Beenden der Programme oder Löschen einzelner Zeichen:
  - Taste kürzer als 2 Sek. drücken.
  - Zum Löschen der Eingaben:
    - Taste länger als 2 Sek. drücken.
-  Toggles to the Info mode:
  - Press longer than 2 seconds.
-  Product data memory:
  - Saves initialization and user data (product and tare values).
  - The product data memory can store over 400 product and tare values.
-  Opens/Exits the Setup program
-  0, 1, 2 ... 9, .
  - Enters numbers, letters and other characters.
-  Toggles between numeric and alphabetic input.



## Soft keys

The functions of active soft keys are indicated by symbols and abbreviations in the last line on the display.

Abbreviation examples:

**ID**: ID list

**DELETE**: Delete entry

Symbols used for soft key functions:

- <<: Return to initial state
- <: Next higher menu level
- >: Show items under selected entry
- ∧: Scroll up in the input/output window
- ∨: Scroll down in the input/output window
- ↵: Set the selected menu parameter

## Numeric Input via the Keypad

- ▶ To enter numbers (one digit at a time):  
Press , ,  ...
- ▶ To save input:  
press the corresponding key.  
For example, press  to save manual tare input.

## Text Input via the Keypad

- ▶ Press the  key.
- ▷ "ABC" is displayed.
- ▶ For example, press the  key.
- ▷ The corresponding letter is displayed. The flashing cursor marks the first letter.
- ▶ Press the key as many times needed to select the desired letter.
- ▶ Press the F1 soft key () or wait 2 seconds.
- ▷ The selected letter appears on the display.

## Entering Spaces via the Keypad

- ▶ Press the  key.
- ▷ "ABC" is displayed.
- ▶ Press the  key.
- ▷ The corresponding selection is displayed. The flashing cursor marks the space.
- ▶ Press the F1 soft key () or wait 2 seconds.
- ▷ The space appears on the display.

## Special Character Input via the Keypad

- ▶ Press the **ABC** key.
- ▷ “ABC” is displayed.
- ▶ Press the **1** key.
- ▷ The corresponding character selection is displayed. The flashing cursor marks the first character.
- ▶ Press the F1 soft key (**↵**) or wait 2 seconds.
- ▷ The special character appears on the display.

## Deleting characters


- ▶ Press **CF**.

## Deleting entire input string

- ▶ Press the F4 soft key (**ESC**).

## Saving Input

- ▶ Enter a value.
- ▶ Press the corresponding soft key (e.g. **1 . ID** to define an identifier).



## Saving Settings in Weighing Mode

You can specify the save type used in the **Application Parameters Setup** menu.

By default, all application parameters saved (e. g., reference values) remain in memory and are available when

- the device has been switched off and then on again
- you return to the originally selected application from a second one (e. g., when you switch from Averaging back to Counting all parameters saved for Counting are available).

## Applying the Tare Weight

To save the weight on the weighing platform as a tare weight:


- ▶ Place the tare object on the weighing platform.
- ▶ Press **↵T**.
- ▷ The value is applied as the tare value.

## Input Through the Digital Control Port

You can connect a remote hand switch or foot switch to the input control line, for use with all application programs. The following functions can be assigned in the Setup menu **Device Parameters:Control I/O Ports:Universal Switch Key**:

- Off
- Print key
- Print key 2 sec
- Tare key
- ISO test key
- Fn key function
- WP toggle key
- Combined zero/tare function
- Zeroing key
- On key
- CF key
- F1 function key
- Appl. toggle key
- 10x higher resolution key
- Net/gross value key





## Display in Weighing Mode

### Weighing Mode: Display of Measured and Calculated Values

The display is divided into several sections.

#### Lines for metrological data

The following parameters are shown here:

- Max** Maximum capacity (upper weighing range limit) of the active weighing platform
- Min** Minimum capacity (lower weighing range limit) of the active weighing platform (verified models only)
- e** Verification scale interval of the active weighing platform (verified models only)
- d** Smallest display digit of the active weighing platform
- R1 R2** Display of the current weighing range of the active weighing platform (with multiple range scale connected)

#### Symbols and Their Meaning

- The Busy symbol appears when the scale is processing a function activated by pressing a key.
- + -** The plus or minus sign of the weight or other measured value
- Verified models only:  
Identifies “zero” as a weight value (after the scale or the active weighing platform has been zeroed)

#### Measured Value Line/Calculated Values

- 5.234** The current weight value (on verified scales or platforms with  $e = d$ , the last digit is bordered for identification)
- 20** A calculated value when using an application program, such as Counting or Weighing in Percent

#### Unit and Stability

- The current weight unit (e.g. “g”)
- PCS** Identifies additional characteristics (e.g. “pieces” for the “Counting” application)




When the weighing system reaches stability, the weight unit or calculation unit is displayed here.

#### Data in Tare Memory, Calculated Value, Identification of the Active Weighing Platform when More Than One Platform is Used

- Identification of calculated values (values not used in legal metrology)
- B/G NET** Indicates gross value or net value (data in tare memory)
- PT** Indicates manual tare input (using a barcode scanner) when viewing tare information.
- WP 1** Display of the active weighing platform when 2 platforms are connected. The display flashes for a ISO Cal adjustment prompt if WP 1 is an IS-weighing platform.
- WP** When the timer is active (**Setup:Device Parameters:Operating Parameters:Timer**), the symbol flashes to indicate that the set time has halfway expired.





## Application, printing and battery symbols





-  Printing in progress
-  GMP-compliant printout active
-  Battery status: 'Battery fully charged' or 'Battery empty'

## Bar graph




The bar graph shows the percentage of the weighing platform's capacity that is "used up" by the load on the scale (gross value).

-  0% Lower load limit
-  100% Upper load limit

The following symbols indicate tolerance levels for checkweighing:

-  Bar graph showing 10% intervals
-  Minimum for "checkweighing"
-  Target value for "checkweighing"
-  Maximum for "checkweighing"

## Application symbols

-  Symbol for the Counting application
  -  Symbol for "checkweigher" counting down to "zero"
  -  Symbols for the Totalizing, Checkweighing, Classification, Net-total Formulation, Weighing in Percent, Counting (with or without reference sample updating) and Neutral Measurement application programs.
- For details on the symbols, please see the chapters for the respective application programs in the manual.

## Text Lines

The text lines show operator support information, such as IDs and user guidance prompts.

## Soft key line

This line shows the abbreviations or symbols that indicate soft key functions.

## LEDs



LEDs indicate

- whether the weight exceeds tolerance limits for checkweighing
- the weight value classification for the Classification application

## Error Codes

- If a key is inactive, "-----" and/or "No function" is displayed (2 sec.) and an acoustic signal (double-beep) is emitted
- Temporary errors are displayed for 2 seconds in the measured value/result line via an error code (e.g., **INF 09**); fatal errors (e.g., **ERR 101**) are displayed continuously until cleared via a restart.

Error codes are described in detail in "Data Interfaces" in "Error Codes."



## Menu Operating Design

Operating example: Setup:Device parameters:  
WP 1:Internal:Adapt filter

- Marks the current menu setting
- Configuring parameters:
  - ▶ Soft key “^” or “v”: Parameter settings
  - ▶ Soft key “↓”: Confirm parameter
  - ▶ **SETUP** or “<<”: Exit Setup menu

## Menu display

### Display Mode for Configuration and Information (Setup)

The display is divided into three sections.

#### Status Line

Indicates the function of the current screen page. In the Setup program, this line shows the “path” to the data displayed.

#### Input and Output Window

For input and display of detailed information; e.g., for the selected application. Selected items are displayed inversely (white letters on a black background).

#### Soft key labels

See the description in this section.

## Saving Menu Settings

The parameters selected in the menu remain saved when you switch to weighing mode or turn off the device.

You can block access to the Device parameters menu by requiring a password to prevent unauthorized or accidental setting changes (see also “Setting up Password Protection”).

## Configuration

You can configure the indicator by selecting parameters in the Setup menu. These are divided into the following groups (menu level 1), menu structure see section the “Setup Overview (Parameters)” section

- Application parameters
- Fn key function
- Device parameters
- Info (device-specific information)
- Language

When used in legal metrology, not all parameters can be accessed. The indicator only displays parameters that can be selected.

Factory-set parameters are identified by an “o” in the list starting on the next page.

### Setting the Language

You can choose from the following languages for displaying information:

- Deutsch
- English (factory setting)
- U.S. mode
- Français
- Italiano
- Español

Example: Selecting “U.S. Mode” for the language


- ▶ Press **(ON)** to turn on the device.
- ▶ Press **(SETUP)**.
- ▷ The menu appears on the display.
- ▶ Press the “v” soft key several times to select the “Language” line.




- ▶ Press the “>” soft key.





- ▷ The language selection appears on the display.
- ▶ Press the “^” soft key to select the “U.S. mode” line.



- ▶ Press the “↓” soft key to save the setting.
- ▷ The setting selection “o” moves to “U.S. mode.”
- ▶ Press **(SETUP)** or **<<** to exit the Setup menu.








# Operating Design



## Setting up Password Protection

- ▶ Press **[I/O]** to turn on the device.
- ▶ Press **[SETUP]**.
- ▶ The menu appears on the display.
- ▶ Press the “v” soft key several times to select the “Device parameters” line.
- ▶ Press the “>” soft key.
- ▶ Press the “v” soft key several times to select the “Password” line.
- ▶ The input line appears on the display.
- ▶ Enter numbers and/or letters via the keypad, see “Numeric Input via the Keypad” and “Letter Input via the Keypad.”
- ▶ Press the “↓” soft key to save the setting.
- ▶ Press **[SETUP]** or “<<” to exit the Setup menu.

# Operating Design



## Setting up Password Protection

- ▶ Press **[I/O]** to turn on the device.
- ▶ Press **[SETUP]**.
- ▷ The menu appears on the display.
- ▶ Press the “v” soft key several times to select the “Device parameters” line.
- ▶ Press the “>” soft key.
- ▷ The Access window appears on the display.
- ▶ Enter the password via the keypad, see “Numeric Input via the Keypad” and “Letter Input via the Keypad.”
- ▶ Press the “↓” soft key.
- ▷ The device selection appears on the display.
- ▶ Press the “v” soft key several times to select the “Password” line.
- ▷ The input line appears on the display.
- ▶ Press **[CF]** several times to delete the password.
- ▶ Press the “↓” soft key to save the delete.  
If not yet saved, the process can be canceled using the “ESC” soft key.
- ▶ Press **[SETUP]** or “<<” to exit the Setup menu.

# Operating Design

## Printing Parameter Settings

Example: Maximum 20 characters per line.

```
-----  
12.01.2010      09:46  
Type           CAIS3  
Ser.no         12345678  
Vers.          1.02.101110  
BVers.         01-63-02  
-----
```

### SETUP

#### DEVICE

```
-----  
WP 1  
  Internal  
WP 2 off  
COM1  
  Data communcations  
  SBI  
  Baud rate  
    1200 Baud  
  Parity  
    Odd  
  Number of Stop bits  
    1 Stop bit  
  Handshake mode  
  Hardware 1-char  
  Number of data bits  
    7 Bit  
  Data output  
Printout printer 1
```

etc.

# Operating Design

## Setup Overview (Parameters)

o = Factory settings  
√ = User-defined setting

### Setup

Application parameters: Please refer to the “Basic Application Programs” manual

#### Fn key function

- o Off
- Unit conversion
- SQMIN (only possible when the display has been turned on in the “Device parameters:SQMin” menu item)

#### Device parameters

##### WP 1

##### RS-232 <sup>1)</sup>

- SBI standard
- SBI verifiable
- o IS-232
- ADC-232

##### RS-485 <sup>1)</sup>

- o IS-485
- ADC-485

##### Internal

##### Calibration/Adjustment

##### CAL key function

- o Ext. cal./adj.; factory-def. wt.
- Ext. cal./adj.; user-defined wt.
- Key blocked

##### Cal./adj. sequence

- Cal. then auto adjust
- o Cal. then manual adjust

##### isoCAL function <sup>3)</sup>

- o Off
- Adjustment prompt

##### Activate external adjustment <sup>2)</sup>

- o Activated
- Deactivated

##### Parameter for external weight

Cal./adj. weight:

##### Calibration/adjustment unit

- Grams /g
- Kilograms /kg
- Tons /t
- Pounds /lb

##### Adapt filter

##### Min. vibration

- o Normal vibration
- Strong vibration
- Extreme vibration

##### Application filter

- o Final readout
- Filling mode
- Low filtering
- Without filtering

##### Stability range

- 1/4 digit
- 1/2 digit
- 1 digit <sup>2)</sup>
- o 2 digits <sup>2)</sup>
- 4 digits <sup>2)</sup>
- 8 digits <sup>2)</sup>

<sup>1)</sup> Equipment version: – then blocked internally

<sup>2)</sup> Not available on devices verified for use in legal metrology

<sup>3)</sup> Only when operated with Sartorius IS weighing platforms or an external ADC



# Operating Design

Device Parameters	WP 1	Internal	
		Stability delay	<ul style="list-style-type: none"> <li>Without delay</li> <li>o Short delay</li> <li>Average delay</li> <li>Long delay</li> </ul>
		Taring <sup>1)</sup>	<ul style="list-style-type: none"> <li>Without stability</li> <li>o After stability</li> </ul>
		Autozero	<ul style="list-style-type: none"> <li>o On</li> <li>Off</li> </ul>
		Weight unit <sup>1 2)</sup>	<ul style="list-style-type: none"> <li>User-definable / o (factory setting: grams) <sup>1)</sup></li> <li>Grams / g</li> <li>o Kilograms / kg</li> <li>Carats / ct <sup>1)</sup></li> <li>Pounds / lb <sup>1)</sup></li> <li>Ounces / oz v)</li> <li>Troy ounces / ozt <sup>1)</sup></li> <li>Hong Kong taels / tlh <sup>1)</sup></li> <li>Singapore taels / tls <sup>1)</sup></li> <li>Taiwan taels / tlt <sup>1)</sup></li> <li>Grains / GN <sup>1)</sup></li> <li>Pennyweights / dwt <sup>1)</sup></li> <li>Milligrams / mg <sup>1)</sup></li> <li>Parts per pound / lb <sup>1)</sup></li> <li>Chinese taels / tlc <sup>1)</sup></li> <li>Mommes / mom <sup>1)</sup></li> <li>Austrian carats / K <sup>1)</sup></li> <li>Tola / tol <sup>1)</sup></li> <li>Baht / bat <sup>1)</sup></li> <li>Mesghal / MS <sup>1)</sup></li> <li>Tons / t</li> <li>lb / oz</li> </ul>
		Display accuracy <sup>1</sup>	<ul style="list-style-type: none"> <li>o All digits</li> <li>One less for wt. change</li> <li>Index +1 <sup>1)</sup></li> <li>Index +2 <sup>1)</sup></li> <li>One less <sup>1)</sup></li> </ul>
		Zero range	<ul style="list-style-type: none"> <li>1 percent/max. cap.</li> <li>o 2 percent/max. cap.</li> </ul>
		Zero at power on	<ul style="list-style-type: none"> <li>2 percent/max. cap.</li> <li>5 percent/max. cap.</li> <li>o 10 percent/max. cap.</li> </ul>
		Tare/zero at power on:	<ul style="list-style-type: none"> <li>o On</li> <li>Off</li> <li>Only zero at power on</li> </ul>

<sup>1)</sup> Not available on devices verified for use in legal metrology

<sup>2)</sup> Depends on weighing platform type

# Operating Design

## Device Parameters

WP 1

Internal

Weight unit 2 <sup>2)</sup>

- User-definable / o (factory setting: grams) <sup>1)</sup>
- o Grams / g
- Kilograms / kg
- Carats / ct <sup>1)</sup>
- Pounds / lb <sup>1)</sup>
- Ounces / oz <sup>1)</sup>
- Troy ounces / ozt <sup>1)</sup>
- Hong Kong taels / tlh <sup>1)</sup>
- Singapore taels / tls <sup>1)</sup>
- Taiwan taels / tlt <sup>1)</sup>
- Grains / GN <sup>1)</sup>
- Pennyweights / dwt <sup>1)</sup>
- Milligrams / mg <sup>1)</sup>
- Parts per pound / / lb <sup>1)</sup>
- Chinese taels / tlc <sup>1)</sup>
- Mommes / mom <sup>1)</sup>
- Austrian carats / K <sup>1)</sup>
- Tola / tol <sup>1)</sup>
- Baht / bat <sup>1)</sup>
- Mesghal / MS <sup>1)</sup>
- Tons / t
- lb / oz

Display accuracy 2

- o All digits
- One less for wt. change
- Index +1 <sup>1)</sup>
- Index +2 <sup>1)</sup>
- One less <sup>1)</sup>

Factory settings: weighing parameters only

- Yes
- o No

<sup>1)</sup> Not available on devices verified for use in legal metrology

<sup>2)</sup> Depends on weighing platform type

# Operating Design

## Device Parameters

WP 1

Internal

Weight unit <sup>3 2)</sup>

- User-definable / o (factory setting: grams) <sup>1)</sup>
- o Grams / g
- Kilograms / kg
- Carats / ct <sup>1)</sup>
- Pounds / lb <sup>1)</sup>
- Ounces / oz <sup>1)</sup>
- Troy ounces / ozt <sup>1)</sup>
- Hong Kong taels / tlh <sup>1)</sup>
- Singapore taels / tls <sup>1)</sup>
- Taiwan taels / tlt <sup>1)</sup>
- Grains / GN <sup>1)</sup>
- Pennyweights / dwt <sup>1)</sup>
- Milligrams / mg <sup>1)</sup>
- Parts per pound / lb <sup>1)</sup>
- Chinese taels / tlc <sup>1)</sup>
- Mommes / mom <sup>1)</sup>
- Austrian carats / K <sup>1)</sup>
- Tola / tol <sup>1)</sup>
- Baht / bat <sup>1)</sup>
- Mesghal / MS <sup>1)</sup>
- Tons / t
- lb / oz

Display accuracy <sup>3</sup>

- o All digits
- One less for wt. change
- Index +1 <sup>1)</sup>
- Index +2 <sup>1)</sup>
- One less <sup>1)</sup>

Factory settings: weighing parameters only

- Yes
- o No

Off

- COM 1 (when the WP is assigned to this interface)
- COM 2 (when the WP is assigned to this interface)
- UNICOM (when the WP is assigned to this interface)

## Device parameters

WP 2

- RS-232 <sup>3)</sup> o ADC-232 similar to "Internal" menu for WP 1
- RS-485 <sup>3)</sup> o ADC-485 similar to "Internal" menu for WP 1

o Off

- COM 1 similar to WP 1
- COM 2 similar to WP 1
- UNICOM similar to WP 1

<sup>1)</sup> Not available on devices verified for use in legal metrology

<sup>2)</sup> Depends on weighing platform type

<sup>3)</sup> Equipment version

# Operating Design

## Device Parameters

COM 1

- o Off  
WP 3

o RS-232

- SBI standard (9600 baud)
- SBI verifiable (9600 baud)
- o IS-232 <sup>1)</sup>
- ADC-232 <sup>1)</sup>

Data communications

o SBI

Baud rate

- 150 baud
- 300 baud
- 600 baud
- o 1200 baud
- 2400 baud
- 4800 baud
- 9600 baud
- 19200 baud

Parity

- Space <sup>1)</sup>
- o Odd
- Even
- None <sup>2)</sup>

Number of stop bits

- o 1 stop bit
- 2 stop bits

Handshake mode

- Software handshake
- o Hardware 1-char

Number of data bits

- o 7 bits
- 8 bits

Data output

- On request, without stability
- o On request, after stability
- Automatic, without stability
  - o 1 display update
  - 2 display updates
  - 10 display updates
  - 100 display updates
- On request, without stability
  - o 1 display update
  - 2 display updates
  - 10 display updates
  - 100 display updates

Printout printer 1  
Printout printer 2

<sup>1)</sup> Not with 8 data bits

<sup>2)</sup> Not with 7 data bits

# Operating Design

## Device Parameters

COM 1

### Data communications

SBI

#### Line format

For raw data (16 characters)  
 For other apps. (22 characters)

#### Sign format

Do not output + sign  
 Output + sign

#### Factory setting

Yes  
 No

### XBPI RS-232

#### SMA

#### Baud rate

150 baud  
 300 baud  
 600 baud  
 1200 baud  
 2400 baud  
 4800 baud  
 9600 baud  
 19200 baud

#### Parity

Space <sup>1)</sup>  
 Odd  
 Even  
 None <sup>2)</sup>

#### Number of stop bits

1 stop bit  
 2 stop bits

#### Handshake mode

Software handshake  
 Hardware 1-char

#### Number of data bits

8 bits

<sup>1)</sup> Not with 8 data bits

<sup>2)</sup> Not with 7 data bits

# Operating Design

## Device Parameters

COM 1

Printer 1 <sup>1)</sup>

YDP20

Baud rate

- o 1200 baud
- o 2400 baud
- o 4800 baud
- o 9600 baud
- o 19200 baud

Parity

- o Space
- o Odd
- o Even

Number of stop bits

- o 1 stop bit
- o 2 stop bits

Handshake mode

- o Software handshake
- o Hardware 1-char

YDP14IS

o Strip  
Label

Universal

Baud rate

- o 150 baud
- o 300 baud
- o 600 baud
- o 1200 baud
- o 2400 baud
- o 4800 baud
- o 9600 baud
- o 19200 baud

Parity

- o Odd
- o Even
- o None

Number of stop bits

- o 1 stop bit
- o 2 stop bits

Handshake mode

- o Software handshake
- o Hardware, 1-char

Number of data bits

- o 8 bits

o YDP14IS

o Strip  
Label

Label, manual form feed

Printer 2 <sup>1)</sup> Similar to printer 1

<sup>1)</sup> Max. 2 printers can be configured

# Operating Design

## Device Parameters

COM 2 similar to COM 1

UNICOM (optional interface)

o Off

WP 3

o RS-232

SBI standard (9600 baud)  
SBI verifiable (9600 baud)

o IS-232 <sup>1)</sup>  
ADC-232 <sup>1)</sup>

RS-485

o IS-485 <sup>1)</sup>  
ADC-485 <sup>1)</sup>

Data communications

o SBI similar to COM 1

xBPI-232 similar to COM 1

xBPI-485 address 0 to 31 can be selected

SMA similar to COM 1

Profibus address: 0 to 126 can be selected,

factory setting: 126

Ethernet

Printer 1 <sup>1)</sup> Similar to COM 1

Printer 2 <sup>1)</sup> Similar to COM 1

Analog output

Analog output: value

o Net value  
Gross value

Analog Out: Error Signal

o High level (20 mA)

Low level (0/4 mA).

When menu is open or during  
calibration

(0/4 mA) on this interface.

Analog output: mode

o Zero to maximum capacity  
Minimum/Maximum values

Analog Out: Data Output Min./Max.

o Min. (0/4 mA) input in kg

Max. (20 mA) input in kg

<sup>1)</sup> Not with 8 data bits

# Operating Design

## Device Parameters


I/O control

Input ports


Universal switch key


Off


 Print key

 Print key - long

 Tare key

 ISO-Test key

 Fn key

 WP toggle key


Comb. tare/zero function

(zero if possible, otherwise tare.)


 Zero key


 On key

 CF key

 F1 function key

 Toggle between applications

 10x higher resolution key

 Net/gross value key

Level internal output ports

All active low

All active high

Bar code

Reference

Tare

ID1

Input

Input without activating function

External keyboard

Config. printout

Headers

Line 1:

Line 2:

ID codes

ID1:

ID2:

ID3:

ID4:

ID5:

ID6:

ISO/GLP/GMP printout

Off

For several application results

Date/time

Date with time

Date only

Once at stability

Off

On

FlexPrint

Off

On



# Operating Design

## Device Parameters

### Config. printout

#### Printer 1

##### Number of printouts

- 1 printout
- 2 printouts

##### Indiv.: Printout f. app./weighing

List	<->	Selection
Gross (G#)		Space line
Tare		-----
Net (N)		Form feed
Space line		Date/time
		Time
		GMP header
		GLP footer
		Transaction no.
		ID1...ID6
		Tare 2 (T2/PT2)
		Header line 1
		Header line 2
		Scale ser. no.
		Product no.
		Product name
		Product ID1...ID4
		(application-dependent values)

Comp.: Printout after saving val. <sup>2)</sup> Similar to individual

Total: Printout after pressing CF <sup>2)</sup> Similar to individual

#### Printer 2 <sup>1)</sup> Similar to printer 1

##### Decimal separator

- Period
- Comma

##### Data records (e.g. alibi memory, product data memory)

- All data records
- Specified quantity

##### Printout factory setting

- Yes
- No

<sup>1)</sup> Max. 2 printers can be configured

<sup>2)</sup> Only when "Totalizing" and/or "Net total" has been selected under "Application parameters:Application 3"

# Operating Design

## Device Parameters


### Operating parameters

#### Acoustic signal

- o On
- o Off
- o Linked to the green LED

#### Keypad

##### Block key functions

- o All keys unblocked
- o All blocked except 
- o Alphanumeric keys blocked
- o Weighing platform switch disabled
- o Zero key blocked
- o Tare key blocked
- o Fn key blocked
- o ISO-Test key blocked
- o Print key blocked
- o 10X higher resolution key blocked
- o Net/gross value key blocked
- o CF key blocked
- o Softkey 5 key blocked
- o Softkey 4 key blocked
- o Softkey 3 key blocked
- o Softkey 2 key blocked
- o Softkey 1 key blocked
- o Application switch disabled
- o Setup key blocked
- o Mem key blocked

#### Display

##### Contrast

- o 0
- o 1
- o 2
- o 3
- o 4
- o 5
- o 6
- o 7

##### Backlighting

- o On
- o Auto shutoff acc. to. timer

##### Model

- o 2
- o 1

#### Automatic shutdown

- o Auto-off acc. to. timer
- o No automatic shutoff

#### Timer

- o 1 + 1 minute
- o 2 + 2 minutes
- o 5 + 5 minutes

#### Main scale

- o WP 1
- o WP 2
- o WP 3

#### Display geogr. data

- o Off
- o On

#### Factory settings: operat. param.

- o Yes
- o No

# Operating Design

## Device Parameters

### Clock

Time:  
Date:

### Test I/O ports

#### Set internal outputs

Int. output 1 (Lighter) 0  
Int. output 2 (Equal) 0  
Int. output 3 (Heavier) 0  
Int. output 4 (Set) 0

#### Read internal inputs

Int. input 1: 0

### Passwords

Password:

### SQmin

#### Display

No  
 Yes

#### GMP print

No  
 Yes

### Alibi memory

#### Alibi memory period

In days 90

# Operating Design

## Setup

### Info

#### Service

Service date:

#### Terminal

Model:  
Serial no.  
Basic ID:  
Version no.: (application software version)

#### 1. WP 1

Model <sup>2)</sup>:  
Version no.: (software version)  
Serial no. <sup>2)</sup>:  
Latitude: <sup>1)</sup>  
Altitude: <sup>1)</sup>  
Grav. acc.: <sup>1)</sup>  
Access switch

#### 2. WP 2, see WP 1

#### 3. WP 3, see WP 1

#### FlexInfo

ID---  
V---

#### Alibi memory

Date  
Time  
Transaction no.

### Language

Deutsch  
o English  
U.S. mode  
Français  
Italiano  
Español

<sup>1)</sup> Depending on configuration prior to verification: either latitude/altitude or gravitational acceleration

<sup>2)</sup> Not displayed for internal ADC

## Weighing

This application is always available during operation.

### Features

- Zeroing by pressing  $\rightarrow 0 \leftarrow$
- Storing the weight on the platform as a tare by pressing  $\rightarrow T \leftarrow$
- Tare container weight automatically
- Use a barcode scanner to enter tare weight
- Use the numeric keys  $\boxed{0}$  to enter a tare weight and press  $\rightarrow T \leftarrow$  to save
- Delete tare values using the  $\boxed{CF}$  key and save using the  $\rightarrow T \leftarrow$  key
- Toggle the display using the  $\boxed{Fn}$  key between:
  - 1st and 2nd weight unit
  - SQmin
- You can configure the  $\boxed{Fn}$  key function in the "Fn key" Setup menu
- 10-fold increased resolution using the  $\boxed{x10}$  key
- Weighing using up to three weighing platforms
- Individual numeric ID codes for weight values
- Print weight values:
  - Manually, by pressing  $\boxed{F7}$
  - GMP printout (see "Data Interfaces")
  - Automatic printout
  - Automatic data output (see "Data Interfaces")
- Restore factory settings in the Setup menu:  
"Application parameters: Factory settings: only application: Yes"

### Soft Key Functions

- ID** Enter up to six ID codes for identifying results on the printout
- 1st ID** Save the value entered as the first ID code.

### Preparation

- ▶ Select Setup: Press  $\boxed{SETUP}$ .
- ▶ Select Application parameters: Press the ">" soft key.
- ▶ Select "Application 1 (basic settings)": Press the ">" soft key.
- ▶ Confirm the "Weighing" application: Press the " $\downarrow$ " and "<" soft keys.
- ▶ Select the "Min. load f. auto. taring/printout" function: Press the ">" soft key.
- ▶ Confirm the "0 10 digits" setting: Press the " $\downarrow$ " and "<" soft keys.
- ▶ Select the "Factory settings" menu item: Press the ">" soft key.
- ▶ Confirm the "0 No" setting: Press the " $\downarrow$ " and "<" soft keys.
- ▶ To save settings and exit the Setup menu: Press the  $\boxed{SETUP}$  key or the "<<" soft key.

### Automatic Taring

The first weight on the scale that exceeds the preset minimum capacity is stored in the tare memory at stability. The values for subsequent loads are stored as weight values.

The scale returns to the initial state when the load on the scale is less than 50% of the minimum load. Operating menu setting: "Application parameters: Autotare 1st weight: Yes"

## Minimum load for automatic taring and automatic printing

To tare container weights automatically, you need to set a minimum load in the Setup menu, under:

```
"Application parameters:Min. load f. auto.
taring/printout:o 10 digits"
```

You can set the following for the minimum load:

- 1 digit (no minimum load)
- 2 digits
- 5 digits
- 10 digits
- 20 digits
- 50 digits
- 100 digits
- 200 digits
- 500 digits
- 1000 digits

The "digits" here refer to the scale intervals for the connected weighing platform. If the interval is 1 g and 1000 digits are required, the minimum load is 1000 g (1000 intervals).

If the weighing platform interval is 5 g and the same number of digits as above are required, the minimum load is 5000 g.


Once the minimum load has been exceeded, the weighing platform is tared automatically and/or an automatic printout is generated.

## Automatic Printing

The first weight value that exceeds the minimum load is printed. If the menu item is also activated for automatic taring, it is only tared when the minimum load is exceeded. In this case, an automatic printout would only be generated when the second weight value exceeds the minimum load. Setting in the Setup menu:

```
"Device parameters:Config. printout:Once at
stability:On"
```

## Weighing using up to three weighing platforms

Press the  key to toggle between three weighing platforms.

## Main scale: first platform displayed on start-up

You can select the weighing platform to be displayed first when the device is turned on in the Setup menu:


```
"Device parameters:Operating parameters:Main
scale:oWP 1"
```

Press  to toggle the readout between platforms.

## Using a barcode scanner to enter tare weight

The tare weight of the container can be entered via a barcode scanner.

Operating menu setting: "Device parameters:Bar code:oTare-value"

The value is applied and saved automatically. The content of the tare memory can be displayed in Info mode by pressing the  key.

## Using a barcode scanner to enter application parameters

Application parameters (reference value) can be entered via a barcode scanner.

Operating menu setting: "Device parameters:Bar code:oReference-value"

The value is applied and saved automatically.

## Using a barcode scanner to enter an identifier

Identifiers can be entered via a barcode scanner.

Operating menu setting: "Device parameters:Bar code:OID"

The value is applied and saved automatically.

## Scanning barcodes directly

You can directly scan a barcode using the barcode scanner.

Operating menu setting: "Device parameters:Bar code:Input"

The barcode can contain the following codes:

- "1" for write identifier
- "T" for save tare memory
- "R" for write reference weight
- "A" for activate product data memory

Examples:

"14Anton" = write the character string to ID 4: Anton

"TC1" = write 1 Kg to the preset tare memory.

"C" = unit: Kilograms

"B" = grams

"D" = carat,

etc.

"RC0.0023" = write 0.0023 kg as the reference weight

"A1" = load product data memory 1

## Adjustment/Configuration counter for standard scales

### Purpose

Automatic recording of changes to adjustment and weighing parameters using two independent counters. The values remain saved for the life of the component.

- ▶ To display both counters, press and hold the  $\rightarrow 0 \leftarrow$  key for longer than 2 seconds.
- ▷ The “Configuration counter” is then shown in the weight display for 3 seconds (identified by a “P”). Then the “Adjustment counter” is displayed for another 3 seconds (identified by a “C”). After 6 seconds, the information display turns off automatically.

### Adjustment counter features:

- Counter limited to 9999
- Counter at “C 0000” for hardware commissioning
- Counter cannot be reset
- Counter is updated automatically when:
  - linearization, calibration/adjustment/preload change is successful
  - user calibration, adjustment or linearization weight is changed
  - When the following parameters are changed:
    - Function  $\text{ISO}_{\text{test}}$  key
    - Zeroing range
    - Initial zero point range
    - The above parameters are reset to factory settings

### Configuration counter features:

- Counter limited to 9999
- Counter at “P 0000” for hardware commissioning
- Counter cannot be reset
- Counter is updated automatically when:
  - When the following parameters are changed:
    - Installation location
    - Application filter
    - Stability range
    - Taring
    - Auto zero
    - Weight unit 1
    - Weight unit 2
    - Weight unit 3
    - The above parameters are reset to factory settings
  - Turning the application automatic taring on/off
  - Restore application parameters to factory settings



## Device Parameters

### Password protection

Access to device and application parameters can be password-protected against unauthorized changes in the Setup menu under “**Device parameters: Password,**” see the “Setting up Password Protection” section in the “Operating Design” chapter.















### Acoustic Signal

An acoustic signal (single beep for active, double beep for inactive keys) is emitted when you press a key.

The acoustic signal can be turned on/off and linked to the green LED in the Setup menu under “**Device parameters: Operating parameters: Acoustic signal.**”

### Keys

Keys can be blocked/unblocked in the Setup menu under “**Device parameters: Operating parameters: Keys.**” The following settings are available:

- All keys unblocked (default setting)
- All blocked except  and 
- Alphanumeric keys blocked
-  blocked
-  blocked
-  blocked
-  blocked
-  blocked
-  blocked
-  blocked
-  blocked
-  blocked
- Soft key 1...5 blocked
-  blocked
-  blocked
-  blocked

### Automatic shutoff of CombiCs

You can specify that the indicator will shut off after a set time has elapsed in the Setup menu under “**Device parameters: Operating parameters: Automatic shutoff,**”

### Display lighting

The following settings can be made for display lighting in the Setup menu under “**Device parameters: Operating parameters: Display:**”





- Contrast
- Backlighting
- Model


### Timer

The timer used to turn the device and/or display lighting on/off can be set to 2, 4, or 10 minutes in the Setup menu under “**Device parameters: Operating parameters: Timer.**”



# Operation

## Tare the scale by placing a container on the weighing platform

- ▶ Press the  key to turn on the indicator.
- ▷ The automatic self-test runs.  
When the weight readout is shown, the scale is ready to operate and automatically set to zero. With no load on the platform, you can zero the weighing platform at any time by pressing .
- ▶ Place empty container on the scale.
- ▷ The container weight is displayed.
- ▶ Press the  key to tare the scale.  
Note: If the automatic tare function is enabled, you do not need to press the  key. The tare weight is saved automatically when you place the container on the platform.





- ▶ Wait until a zero value is displayed together with the “NET” symbol (net weight).



- ▶ Place sample on the platform.
- ▶ Wait until the weight unit symbol is displayed (indicating stability).
- ▶ Read the weight value.

# Operation



## Weighing with numeric entry of tare value and printing the results.


- ▶ Press the  $\text{I/O}$  key to turn on the indicator.
- ▶ The automatic self-test runs.  
When the weight readout is shown, the scale is ready to operate and automatically set to zero. With no load on the platform, you can zero the weighing platform at any time by pressing  $\rightarrow 0 \leftarrow$ .
- ▶ Press the  $\cdot$   $2$   $5$  key to enter a known tare weight via the keypad (in this example, 0.25 kg).
- ▶ Press the  $\rightarrow T \leftarrow$  key to apply the tare weight.

- ▶ Place the container with sample on the platform.

- ▶ Read the results.

- ▶ Press the  $\text{B/G}$  key to toggle the display to the net weight value.
- ▶ The display shows the gross weight (in this example, 0.250 kg for the container plus 2.000 kg for the sample).

# Operation



▶ Press the **[B/G]** key to toggle back to the previous display.

- ▶ Press the **[E]** key to print the results.
- ▷ Start of GMP header (only if GMP-compliant printout is configured).

```
-----  
24.10.2010    10:09  
Type   CAW3P1-12ED-L  
Vers.no. 1.02.101110  
BVers.   01-63-02  
-----  
EISENSCHMIDT  
GOETTINGEN  
Lot no.      123456  
Customer     Schulze  
24.10.2010    10:09  
-----
```

End of GMP header  
Headers

Identifiers

```
-----  
G#    +    2.250 kg  
T     +    0.000 kg  
PT2   +    0.250 kg  
N     +    2.000 kg  
-----
```

Start of GMP footer (only if GMP-compliant printout is configured)


```
-----  
24.10.2010    10:10  
Name :  
-----
```

End of GMP footer


# Operation

## Weighing with variable tare values, printing results, deleting tare values

- ▶ Press the  $\square/\square$  key to turn on the indicator.
- ▶ The automatic self-test runs.  
When the weight readout is shown, the scale is ready to operate and automatically set to zero. With no load on the platform, you can zero the weighing platform at any time by pressing  $\rightarrow 0 \leftarrow$ .
- ▶ Place empty container on the scale.
- ▶ Press the  $\rightarrow T \leftarrow$  key to tare the scale.  
Note: If the automatic tare function is enabled, you do not need to press the  $\rightarrow T \leftarrow$  key. The tare weight is saved automatically when you place the container on the platform.




- ▶ Wait until a zero value is displayed together with the "NET" symbol (net weight).



- ▶ Place a packaged sample in the container.
- ▶ Press the  $\square \cdot \square 2 \square 5$  key to enter the known tare weight of the package via the keypad (in this example, 0.25 kg).
- ▶ Press the  $\rightarrow T \leftarrow$  key to apply the package weight that was entered.  
Both tare weights are added together.

# Operation



► Read the Net weight.

G# + 6.433 kg  
T + 4.183 kg  
PT2 + 0.250 kg  
N + 2.000 kg

-----

► Press the  $\boxed{E}$  key to print the results.

► Press the  $\boxed{0}$  key.

► Press the  $\boxed{\rightarrow T \leftarrow}$  key to apply the entered value.

▷ The tare values are deleted. The gross value appears on the display.



► Press the  $\boxed{E}$  key to print the results.

G# + 6.433 kg  
T + 0.000 kg  
N + 6.433 kg

-----

## Calibration and Adjustment

### Purpose

Perform **calibration** to determine the difference between the value displayed and the actual weight on the platform. Calibration does not entail making any changes within the weighing equipment.

During **adjustment**, the difference between the measured value displayed and the true weight of a sample is corrected, or is reduced to an allowable level within maximum permissible error limits.

## Configuration for Use in Legal Metrology

**M** Configuration of the weighing instrument for use in legal metrology is set by a switch. The switch is located on the back of the weighing platform and covered by a protective cap.

Using a verified scale in legal metrology in the EU:


The Type-Approval Certificate for verified scales is only valid for non-automatic weighing instruments. For automatic operation with or without additional, integrated equipment, please follow the applicable national regulations for the installation location.

### Externally connected IS scales

Before use in legal metrology, the scale should be calibrated via the internal calibration equipment at the installation location: see chapter “Configuring Weighing Platforms, section “Internal Calibration/Adjustment.”



The temperature range (°C) listed on the ID label should not be exceeded during operation.



### For Servicing

External calibration for verified scales of accuracy class  $\text{III}$ :

- External calibration is blocked in legal metrology (switch cover is sealed)
- External calibration is only possible by removing the seal.

If the seal is broken, the validity of verification will become void and you must have your scale re-verified.

Using a verified scale in legal metrology with internal calibration equipment:

- ▶ Before use in legal metrology, the “internal calibration” function should be carried out at the installation location:

### Opening the menu access switch

The menu access switch is located on the back of the indicator right next to the weighing platform connection.

- ▶ Remove the cap.
- ▶ Slide the switch to the left (= “open” position, for use in legal metrology).



You can determine the position of the switch in the Setup menu under “Info:WP.”

## Features

Which of the following features are available depends on the connected weighing platform. These features are configured in the Setup menu:

- External calibration/adjustment blocked in verified weighing instruments
- External calibration/adjustment with the default weight value or user-defined weight (not available on verified instruments) under  
“...Calibration/adjustment:CAL key function”
- Specify the weight for external calibration/adjustment under  
“...Calibration/adjustment:Parameter for external weight”
- Internal calibration/adjustment of IS weighing platforms (configuration in “COM 1:, COM 2: or UNICOM:WP 3 “)
- Block the  $\left(\frac{ISO}{Test}\right)$  key to prevent the use of the two functions described above under  
“...Calibration/adjustment:CAL key function”
- Calibrate first; then adjust automatically or manually (not for verified weighing instruments) under “...Calibration/adjustment:Cal/adj. sequence”
- For Sartorius IS weighing platforms only: Flashing WP symbol as adjustment prompt (If more than one weighing platform is connected, the platform number is also displayed) under  
“...Calibration/adjustment:CAL key function”
- Block/Unblock external calibration/adjustment under  
“...Calibration/adjustment:Activate ext. adj.”
- Altitude and latitude or gravitational acceleration displayed after “Cal” is displayed at the start of the calibration/adjustment process if these values are supported by the weighing platform under “Device parameters:Operating parameters:Display geom. data”

For each of these parameters, the term is displayed first (Altitude, Latitude or Gravity) for 1 second, and then the corresponding value is displayed continuously until you press

$\left(\frac{ISO}{Test}\right)$ .



## External Calibration and Manual Adjustment with Default Weights (weighing parameters: factory settings)

### Preparation

- ▶ Select Setup: Press the **SETUP** key.
- ▶ Select device parameters: Press the “>” soft key.
- ▶ Select weighing platform “WP 1,” “WP 2:” Press the “>” soft key or
- ▶ Select interface “COM 1,” “COM 2” or “UNICOM” (depending on the interface): Press the “>” soft key.
- ▶ Select weighing platform WP 3: Press the “>” soft key.

### Calibration/Adjustment

#### CAL key function

- o Ext. cal./adj.; factory-def. wt.
- o Ext. cal./adj.; user-defined wt.
- o Key blocked

#### Cal./adj. sequence

- o Cal. then auto adj.
- o Cal. then manual adj.

#### isoCAL function (for Sartorius IS weighing platforms only)

- o Off
- o Adjustment prompt

#### Activate ext. adj.

- o Activated
- o Deactivated

#### Parameter for external weight

o = Factory setting


- ▶ To save settings and exit the Setup menu: Press the **SETUP** key or the “<<” soft key.

### Procedure


- ▶ Zeroing the scale by pressing the **→0←** key.




- ▶ Start calibration/adjustment using the **ISO-TEST** key.
- ▶ The display “C·EXT·D” appears for two seconds.



- ▶ You are prompted to place the required weight on the platform (e.g., 10,000 g).




# Operation



- ▶ Place the calibration/adjustment weight on the weighing platform.




- ▷ The difference between the measured value and the true weight of the sample will be displayed with plus/minus signs.



- ▷ A printout will be generated if the adjustment is not carried out and the procedure is stopped by pressing the  $\rightarrow 0 \leftarrow$  key.

```
External calibration
Nom. + 10000 g
Diff. + 1 g
```

- ▶ Start calibration/adjustment via the  $\text{ISO-Test}$  key (cancel via  $\rightarrow 0 \leftarrow$ ).
- ▷ The adjustment weight is displayed once adjustment is finished.



- ▷ A GMP-compliant printout is generated

```
-----
24.10.2010 10:15
Type CAIS3
Vers.no. 1.02.101110
BVers. 01-63-02
-----
```

```
External calibration
Nom. + 10000 g
Diff. + 1 g
External adjustment
Diff. + 0 g
-----
```

```
24.10.2010 10:15
Name:
-----
```

## SQmin Function

### Purpose

To display the allowable minimum sample quantity “SQmin” (sample quantity minimum) in accordance with the United States Pharmacopoeia (USP). According to USP guidelines, the uncertainty of measurement may not exceed 0.1% of the sample quantity when substances are weighed with the highest degree of accuracy for volume determination. This additional function ensures that weighing results lie within defined tolerance limits corresponding to the requirements of your quality assurance system.

### System Requirements

The scale must be set up by a service technician to be able to use the SQmin function. The technician will determine the permitted minimum sample quantity and set this on your balance using your QA system’s guidelines. He will document this setting via a “Weighing module test as per USP” certificate in which the measurements and min. sample quantity are logged. The SQmin function ensures that the weighing results correspond to USP guidelines. These SQmin settings cannot be changed by the user.

### Features




- Displaying the minimum sample quality: The value is displayed in the text line for 4 seconds after pressing the **Fn** key.
- If the minimum sample quantity has not been reached: The **Δ** symbol is displayed and weight values are marked with a “!” in the printout.
- GLP header: The minimum sample quantity entered for SQmin can be included on the printout.

## SQmin Operation


### Configuration in Service Mode

The SQmin value can only be entered in Service mode.

- ▶ Remove the cap.
- ▶ Slide the menu access switch to the left (= "open" position).  
If the device is part of a verified weighing facility, this will only be possible if the verification seal is broken. The weighing equipment must then be verified again.
- ▶ Activate the Service mode, see "Service Mode."
- ▶ In the "Device parameters" menu, select "SQmin" and open using the ">" soft key.
- ▶ Select "SQmin input" using the ">" soft key.



- ▶ Select "SQmin WP1" using the ">" soft key, enter the value via the keypad (in this example 0.100 kg) and save using the "↓" soft key or cancel using "ESC."
- ▶ Then enter the values for WP 2 and WP 3.
- ▶ Press **SETUP** or "<<" to exit the Setup menu.
- ▶ Slide the menu access switch to the right (= "closed" position) and reattach the cap.
- ▶ The device is now in normal weighing mode.





### Configuration in Weighing Mode


- ▶ In the "Device parameters" menu, select "SQmin" and open using the ">" soft key.
- ▶ Select "Display".
- ▶ Open using the ">" soft key.
- ▶ Confirm the factory setting "yes" using the "↓" soft key.
- ▶ Press the "<" soft key several times to switch to the next highest menu.

The SQmin display must be turned on to use the SQmin function.

- ▶ In the "Fn key: SQmin display:" menu, select using the ">" soft key and confirm using the "↓" soft key.
- ▶ Press **SETUP** or "<<" to exit the Setup menu.



# Operation



## Procedure

▶ Place the container for the sample on the scale and press the  $\rightarrow T \leftarrow$  key to tare.

- ▶ Place the sample on the scale.
- ▷ The minimum sample quantity is not reached (symbol  $\Delta$ ).
- ▶ Press the  $\left[ \text{Fn} \right]$  key to generate the printout.

- ▶ Place another sample on the scale.
- ▷ The minimum sample quantity is exceeded (no symbol  $\Delta$ ).
- ▶ Press the  $\left[ \text{Fn} \right]$  key to generate the printout.

- ▶ Briefly press the  $\left[ \text{Fn} \right]$  key to toggle between the measured value and SQmin value.
- ▷ The value for the minimum sample quantity is displayed for four seconds.

## Data ID Codes

You can assign codes (such as product name, batch number, etc.) for identification of measured values in all application programs.

### Features

- Assign up to six ID codes.
- Assign both a name and a value to each ID code.
- Displaying individual IDs: press the “ID” soft key.
- The name is left-justified and the value is right-justified on the printout. If the entire code is too long for one line, additional lines are printed.
- Enter ID code names in Setup under: “**Device parameters:Config. printout:ID codes.**”
- The name can have a max. of 20 characters. When entering the ID value, no more than 11 characters are displayed during input; however, all 20 characters are printed.
- Enter up to 21 characters for the value of the ID code. Press the “ID” soft key to activate the input mode.
- Enter the first ID value directly through the numeric keypad. Press the “1st ID” soft key to save the value.
- Individual characters of the ID can be deleted using the  $\rightarrow 0 \leftarrow$  key. Complete ID code values can be deleted using the “Delete” soft key.
- If both the name and value fields are empty, no ID code is printed.
- In the Setup menu, you can configure when and whether ID codes are printed (see included “Application Programs” instructions, “Configuring Printouts”).

### Settings for individual ID codes

Setup menu: “**Device parameters:Config. printout:ID codes**”

Factory settings for ID code names:

ID1: “ID1”

ID2: “ID2”

ID3: “ID3”

ID4: “ID4”

ID5: “ID5”

ID6: “ID6”

There are no factory settings for ID code values.

# Operation

## Using Individual ID Code

### Example

Enter ID code names. "Batch no." and "Customer" should be entered for ID 1 and ID 2.

- ▶ Press the **SETUP** key and select "Device parameters: Config. printout: ID codes."
- ▶ The first line is selected.

DEVICE	PRINTOUT	ID CODES
ID1:		ID1
ID2:		ID2
ID3:		ID3
ID4:		ID4
ID5:		ID5
ID6:		ID6

DEVICE	PRINTOUT	ID CODES
ID1:	LOT NO.	ID1
ID2:	CUSTOMER	ID2
ID3:		ID3
ID4:		ID4
ID5:		ID5
ID6:		ID6

- ▶ Press the **ABC** key to enter "Batch no." via the keypad, see also chapter "Operating Design," sections "Text Input via the Keypad" and "Special Character Input via the Keypad."
- ▶ Press the "↓" soft key to save the entry.
- ▶ Press the "↵" soft key to select the second line.
- ▶ Press the **ABC** key to enter "Customer" via the keypad, see also "Operating Design," "Text Input via the Keypad."
- ▶ Press the "↓" soft key to save the entry.
- ▶ Press **SETUP** or "◀◀" to exit the Setup menu.

### Example

Enter ID code values. The values "123456" and "Smith" should be entered for ID 1 and ID 2.

- ▶ Press the "ID" soft key.

WP1: Max	6 kg	d=	2 g
0.000 kg			
ID			

ID:	
LOT NO.	
CUSTOMER	
ID3	
TR4	

- ▶ The first line is selected.

ID:	
123	
LOT NO.	
CUSTOMER	123456
ID3	
TR4	

- ▶ Press the key to enter "123456" via the keypad, see also "Operating Design," "Number Input via the Keypad."
- ▶ Press the "↓" soft key to save the entry.

ID:	
LOT NO.	123456
CUSTOMER	SMITH
ID3	
TR4	

- ▶ Press the "↵" soft key to select the second line.
- ▶ Press the **ABC** key to enter "Smith" via the keypad, see also "Operating Design," "Text Input via the Keypad."
- ▶ Press the "↓" soft key to save the entry.
- ▶ Press the "◀◀" soft key to exit the menu.

## Data Interfaces

The indicator is equipped with the following data interfaces:

- COM1: Standard data interface (RS-232)
- COM2: Standard data interface (RS-232)
- UniCOM: Universal data interface (optional)

Interfaces can be configured in the Setup menu for different input and output functions (e.g. printer, 3rd weighing platform, PC, checkweighing).

The optional UniCOM interface can be used as an RS-232, RS-485/RS-422 or analog output (voltage/current interface, galvanically separated digital I/Os, profibus, Ethernet), see also "Accessories."

A barcode scanner or a keyboard can be connected via the PS/2 -socket or the corresponding screw terminals (IP69K).

### Features

- IP44 indicator:  
Connect via a 25-pin D-Sub female connector
- IP69K indicator:  
Route the connecting cable from the peripheral device to the indicator via a cable gland.  
The free cable ends are connected via the screw terminals.



### Warning when using third-party RS-232 connecting cables:

The pin assignments may not be compatible with Sartorius equipment. Check the pin assignment against the cabling diagrams and disconnect any lines that are not assigned. Failure to do so may cause malfunction, damage or even completely ruin your indicator and/or peripheral device(s).

---



# Data Interfaces

## Specifications

<b>Serial interface:</b>	Interface operating mode:	Full duplex
	Level:	COM1: RS-232, COM2: RS-232, UniCOM (optional): RS-232 or RS-422/485 half duplex
	Connection:	IP44 devices: 25-pin D-Sub socket IP69K devices: Connection via screw terminals in the housing, cable routed into the housing via a cable gland.
	Transmission rate:	150, 300, 600, 1200, 2400, 4800, 9600, 19200 baud (depending on the operating mode)
	Number of data bits:	7, 8 bits
	Parity:	Space, odd, even, none (depending on the operating mode)
	Number of stop bits:	1 or 2
	Handshake mode:	Software (XON/XOFF), hardware (1 character after CTS)
	Protocols:	SBI, XBPI-232 <sup>2)</sup> , XBPI-485 <sup>1)2)</sup> , SMA, Profibus (UniCOM only) various printers: – YDP011S – YDP021S label – YDP011S label – Universal – YDP02 – YDP041S – YDP03 – YDP041S label – YDP021S – YAM011S Alibi memory
	Network address <sup>3)</sup> :	0, 1, 2, ..., 31
	SBI: Manual data output:	Without stability, after stability, configurable printout
	SBI: Auto. data output:	Without stability, at stability, at user-defined intervals
	SBI: Output format:	16 or 22 characters
	Printout of application data:	Output of a configurable printout

<b>Factory Settings</b>	Depends on the device configured; for example: "SBI," "Data communication" setting	
	Transmission rate:	1200 baud
	Number of data bits:	7 bits
	Parity:	Odd
	Number of stop bits:	1 stop bit
	Handshake:	Hardware handshake, 1 character after CTS
	Activation of data output:	Individual print out after stability
	Time-dependent autoprint:	1 display update
	Output format:	22 characters

<b>Analog UniCOM interface (optional)</b>	Level:	4...20 mA, 0...20 mA, 0...5 V
	Power supply:	Internal or external
	Factory setting:	4...20 mA, internal power supply
	Connection:	CAISL3 devices (IP44): 25-pin D-Sub socket CAIS3 devices (IP69K): Connection via screw terminals in the housing, cable routed into the housing via a cable gland.

<sup>1)</sup> Optional UniCOM universal data interface

<sup>2)</sup> xBPI operating mode: 9600 baud, 8 data bits, parity: odd, 1 stop bit

<sup>3)</sup> Network address is valid only in xBPI-RS-485 operating mode

## Connection Options



You may need to use an external power supply to operate peripheral devices.

### Preparation

See chapter “Getting Started,” sections “COM1 Pin Assignment Chart,” “COM2 Pin Assignment Chart,” “PS2 Pin Assignment Chart” for pin assignments and cabling diagrams.

### Printer connection options

The following printers can be connected to the standard COM1 and COM2 interfaces or the optional UniCOM universal interface:

- YDP20 (user-defined interface parameters)
- YDP14IS (strip or label printer)
- YDP04IS (strip or label printer)
- Universal printer (user-definable transmission parameters)

### Device connection options

In addition, the following devices can be connected to the standard COM1 and COM2 interfaces:

- Foot / Hand switch, COM1 only
- Second printer
- Remote display
- PC (RS-232 interface)
- Third weighing platform (RS-232 interface)
- External checkweighing display (stop light) via a digital I/O (Sartorius standard), COM1 only
- To PS2: Barcode scanner/External keyboard

The following devices can be connected to the optional UniCOM universal interface:

- WP3 RS-232/RS-485
- PC (RS-232 interface)
- Second printer (external power source required)
- Remote display
- Digital I/O
- Current interface (0/4...20 mA), voltage (0...10 V)
- PLC with Profibus DP
- Ethernet

### Connection options for other weighing platforms

The Combics 3 model enables you to connect a 2nd or 3rd weighing platform. You can use both the COM1, COM2 or the UniCOM port.

The standard COM1 and COM2 port is operated in RS-232 mode. The following modes are available for a 3rd weighing platform:

- SBI
- IS-232 (factory setting)
- ADC-232

### Operating modes

UniCOM interfaces can be operated in either the RS-232 or RS-485 mode.

The third weighing platform can be operated in any of the following modes:

- SBI (RS-232 mode)
- IS-232 (RS-232 mode)
- ADC-232 (RS-232 mode)
- IS-485 (RS-485 mode, xBP1 mode, factory setting)
- ADC-485 (RS-485 mode)

The standard COM1 and COM2 ports or the optional universal UniCOM interface can be used as a printer interface.

## Configuring the Data Interface as a COM Port

For operation as a COM port, you can adapt data records to the following operating modes:

- SBI (factory setting)
- XBPI-232
- XBPI-485
- SMA

In the SBI communication mode, you can control a display unit and a connected weighing platform by sending ESC commands from a PC to the communications port (COM1, COM2 or UniCOM). See also "Data Input Format."

COM1	o Off WP 3	RS-232	SBI standard version SBI trade version (for legal metrology) o IS-232 ADC-232
	Data communication	o SBI XBPI-232 SMA	
	Printer 1 <sup>1)</sup> or Printer 2 <sup>1)</sup>	YDP20 YDP04IS  Universal (printer) YDP04IS	o Strip Label  o Strip Label Label, man. form feed
COM2	o Off WP 3	RS-232 (9600 baud)	SBI standard version SBI trade version (for legal metrology) o IS-232 ADC-232
	Data communication	o SBI XBPI-232 SMA	
	Printer 1 <sup>1)</sup> or Printer 2 <sup>1)</sup>	YDP20 YDP04IS  Universal (printer) YDP04IS	o Strip Label  o Strip Label Label, man. form feed
UNICOM (option)	o Off WP 3	RS232 RS485	
	Data communication	o SBI XBPI-232 XBPI-485 SMA Profibus Ethernet	
	Printer 1 <sup>1)</sup> or Printer 2 <sup>1)</sup> Analog output External Multi-I/O converter	see COM2	

o Factory setting

<sup>1)</sup> Max. 2 printers can be configured

## Setting the SBI Data Output

Data output settings can be made in the Setup menu under “**Data communications:SBI:Data output.**”

The following options are available:

- The displayed value, with or without stability check
- Automatic output of the displayed value, either with or without stability check, or automatically at defined intervals
- Output of a printout as configured in the “**Device parameters: Config. printout:Printer 1**” or “**Printer 2**” (see next page).

You can define the printout content by specifying which blocks of information are to be included (see “Configuring Printouts”).

In general, the current display value is output (weight with unit, calculated value, alphanumeric display) unless you configure a user-definable data record.

Generally, data is output only after the weighing instrument has stabilized (factory setting). Here you can define whether data is output on request or automatically, at stability or without stability check; and configure a user-defined printout. The data output for “without stability” must be set accordingly (SBI: Data output).

If you select time-dependent automatic printout, you need to define the print interval (in display updates) as well.

Each line of a printout can contain up to 20 characters. The first 6 characters, called the “data header”, identify the subsequent value. Only 14 characters are available if you disable the header. This is carried out in the “Line format” menu item (see also “Setup Overview” in “Configuration”).

### Automatic Data Output (SBI)

You can have the weight readout printed automatically<sup>1)</sup>. This printout can be generated after a certain number of display updates<sup>2)</sup>. You can also configure whether or not the auto-print function is dependent on the stability of the scale<sup>3)</sup>.

The display update frequency depends on both the scale model and the operating status.

Examples:

N	+	153.00 g	Net weight
Stat			Display blank
Stat		L	Display underload
Stat		H	Display overload

“Data output” setting:

- <sup>1)</sup> <sup>3)</sup> Automatic, without stability or automatic with stability.  
Factory setting: Manual after stability; i.e., automatic data output function off.
- <sup>2)</sup> Time-dependent automatic data output:  
Interval: 1, 2, 10 or 100 display updates  
Factory setting: 1 display update

## Data Input Format

You can connect a computer to your scale to send commands controlling weighing instrument functions and applications via the interface port.













All commands use the same data input format. They begin with the ESC (ASCII: 27) character and end with a carriage return CR (ASCII: 13) and LF (ASCII: 10). The total length of a command is anywhere from 4 characters (1 command character between the start and end described above) to a max. of 7 characters (4 command characters). This number can also be higher when sending texts.

The commands listed in the following table must each be supplemented with ESC ... CR LF.

## Example

The command character for output is “P” (“output to Port”). To trigger this command, send the string: “ESC P CR LF”.

### Command Meaning

K	Weighing mode 1
L	Weighing mode 2
M	Weighing mode 3
N	Weighing mode 4
O	Block keys
P	Send display value to data interface
Q	Output acoustic signal
R	Unblock keys
D	Tare and zero (combination tare function)
f3_	Zero (see also the “kZE_” command)
f4_	Tare without zeroing (see also the “kT_” command)
i_	Information about the indicator, example of output: “CAI/016302/1” Meaning: Indicator: Combics 3, software version: 016302, Active weighing platform: 1
kF1_	Trigger soft key F1 function
kF2_	Trigger soft key F2 function
kF3_	Trigger soft key F3 function
kF4_	Trigger soft key F4 function
kF5_	Trigger soft key F5 function
kF6_	Trigger  key function
kF7_	Trigger  key function
kF8_	Trigger  key function
kF9_	Trigger  key function
kF10_	Trigger  key function
kF11_	Trigger  key function
kF12_	Trigger  key function
kP_	Trigger  key function (print at printer interface)
kT_	Trigger  key (tare)
kNW_	Trigger  key function (toggle the weighing platform)
kZE_	Trigger  key function (zero the instrument)
kCF_	Trigger  key function
x1_	Output model designation of active weighing platform, example: “LP6200S-0C”
x2_	Output serial number of active weighing platform, example: “0012345678”
x3_	Output software version of active weighing platform, example: “00-43-04”
x4_	Output software version of indicator, example: “01-63-02”
x9_	Output serial number of indicator, example: “0012345678”
x10_	Output model of indicator, example: “CAIS3”
z1_	Input: printout header 1
z2_	Input: printout header 2

The ASCII code for the “underline” character (“\_”) is 95.

Format for entering printout header lines: “ESC z x a ... a \_ CR LF” with x=1 or 2 and a ... a: 1 to 20 characters for header x, followed by the underline, CR and LF characters.

txx...x\_ Write text in display. xx...x is the text to be displayed.

## Data Output Format

You can output the value displayed in the measured value line and the weight unit, with or without a data ID code. Whether the data ID code is included in the output depends on your settings under “Line Format.”

### Examples

```

+          235 p c s   without ID code
Q n t    +          235 p c s   with ID code
    
```

“Line Format” settings:

For raw data (16 characters): without header,

for other apps. (22 characters): with “header” (factory setting).

### Data Output Format with 16 Characters

Display segments that are not activated are output as spaces.

Values with no decimal point are output without a decimal point.

The type of character that can be output depends on the character’s position:

#### Normal Operation

Position	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
	+	*	A	A	A	A	A	A	A	A	*	E	E	E	CR	LF
or	-	*	A	A	A	A	A	A	A	A	*	E	E	E	CR	LF
or	*	*	*	*	*	*	*	*	*	*	*	*	*	*	CR	LF

+-: Signs; the “+” sign can be hidden under “**Device parameters: COMx:Data communications:SBI:Sign format.**”

\*: Space

A: Digit or letter (max. 7 characters plus decimal point)

E: Unit symbol<sup>1)</sup> (1 to 3 letters followed by 2-0 spaces)

CR: Carriage return

LF: Line feed

#### Special Codes

Position	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
	*	*	*	*	*	*	-	-	*	*	*	*	*	*	CR	LF
or	*	*	*	*	*	*	H	*	*	*	*	*	*	*	CR	LF
or	*	*	*	*	*	*	H	H	*	*	*	*	*	*	CR	LF
or	*	*	*	*	*	*	L	*	*	*	*	*	*	*	CR	LF
or	*	*	*	*	*	*	L	L	*	*	*	*	*	*	CR	LF
or	*	*	*	*	*	*	L	*	*	*	*	*	*	*	CR	LF

\*: Space

--: Final readout

H: Overload

HH: Overload in checkweighing

L: Underweight

L L: Underweight in checkweighing

C: Calibration/Adjustment

#### Error Messages

Position	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
	*	*	*	E	r	r	*	*	#	#	*	*	*	*	CR	LF
	*	*	*	E	r	r	*	*	#	#	#	*	*	*	CR	LF

\*: Space

#: Number (2 or 3 digit error number)

<sup>1)</sup> based on the model type, e.g. not all units are available for use in legal metrology

# Data Interfaces

Output of the weight value +1255.7 g

Position	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
	+	*	*	*	1	2	5	5	.	7	*	g	*	*	CR	LF

- Position 1: Plus +, or minus - or space
- Position 2: Space
- Positions 3-10: Weight value with decimal point; leading zeros are output as spaces.
- Position 11: Space
- Positions 12-14: Characters for unit of measure, space or ! sign as a symbol
- Position 15: Carriage return
- Position 16: Line feed

## Data Output Format with 22 Characters

When data is output with an ID code, the 6-character code precedes the 16-character string described above. These six characters identify the subsequent value.

Normal Operation

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22
K	K	K	K	K	K	+	A	A	A	A	A	A	A	A	*	E	E	E	CR	LF	
K	K	K	K	K	K	-	A	A	A	A	A	A	A	A	*	E	E	E	CR	LF	
*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	CR	LF

- K: ID code character, right-justified with spaces
- + -: Plus or minus sign
- \*: Space
- A: Digit or letter (max. 7 characters plus decimal point)
- E: Measurement unit symbol<sup>1)</sup> (1 to 3 letters followed by 2-0 spaces)
- CR: Carriage return
- LF: Line feed

Special Codes

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22
S	t	a	t	*	*	*	*	*	*	*	*	-	-	*	*	*	*	*	*	CR	LF
S	t	a	t	*	*	*	*	*	*	*	*	H	*	*	*	*	*	*	*	CR	LF
S	t	a	t	*	*	*	*	*	*	*	*	H	H	*	*	*	*	*	*	CR	LF
S	t	a	t	*	*	*	*	*	*	*	*	L	*	*	*	*	*	*	*	CR	LF
S	t	a	t	*	*	*	*	*	*	*	*	L	L	*	*	*	*	*	*	CR	LF
S	t	a	t	*	*	*	*	*	*	*	*	C	*	*	*	*	*	*	*	CR	LF

- \*: Space
- -: Final readout
- H: Overload
- HH: Overload in checkweighing
- L: Underweight
- LL: Underweight in checkweighing
- C: Calibration/Adjustment

Error Message

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22
S	t	a	t	*	*	*	*	*	S	r	r	*	*	#	#	*	*	*	*	CR	LF
S	t	a	t	*	*	*	*	*	S	r	r	*	#	#	#	*	*	*	*	CR	LF

- \*: Space
- #: Number (2 or 3 digit error number)

<sup>1)</sup> based on the model type, e.g. not all units are available for use in legal metrology

## Data Interfaces

<b>G #</b>	Gross value	<b>Stat</b>	Status
<b>N</b>	Net value	<b>Class x</b>	Classification, class x
<b>T</b>	Application tare memory 1	<b>Lim x</b>	Class limit
<b>T2</b>	Application tare memory 2	<b>D</b>	Percentage (as loss)
<b>Diff</b>	Difference from calibration value	<b>Prc</b>	Percentage (as residue)
<b>Targ .</b>	Exact adjustment weight value	<b>Wxx%</b>	Reference percentage weight
<b>Nom .</b>	Exact calibration weight for SBI protocol output	<b>Cmpxxx</b>	Component xxx
<b>nRef</b>	Reference sample quantity	<b>Cont . T</b>	Contents of the tare memory in Net-total Formulation
<b>pRef</b>	Percentage of reference	<b>S-Comp</b>	Total of initial weighings for Net-total Formulation
<b>wRef</b>	Reference piece weight	<b>PT2</b>	Preset tare
<b>Qnt</b>	Result from Counting application Result from Counting (piece count) and Neutral Measurement applications	<b>n</b>	Transaction counter
<b>mDef</b>	Target value for animal weighing	<b>*G</b>	Sum of gross weights in Totalizing
<b>x-Net</b>	Animal weighing results	<b>*N</b>	Sum of net weights in Totalizing
<b>Setp</b>	Target value for checkweighing	<b>Ser . no</b>	Serial number of the platform or indicator
<b>Diff . W</b>	Absolute difference (e. g., in kg) in Checkweighing		
<b>Lim</b>	Deviation in % in Checkweighing		
<b>Max</b>	Upper tolerance for checkw.		
<b>Min</b>	Min. tolerance for checkw.		

Example:

Output of the weight value +1255.7 g

```

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22
G # * * * * + * * * 1 2 5 5 . 7 * g * * CR LF

```

Position 1-6: ID code, right-justified with spaces

Position 7: Plus +, or minus - or space

Position 8: Space

Positions 9-16: Weight value with decimal point; leading zeros are output as spaces (a comma can also be set instead of a decimal point).

Position 17: Space

Positions 18-20: Characters for unit of measure, space or ! sign as a symbol

Position 21: Carriage return

Position 22: Line feed



If the weight value is output with 10-fold increased resolution, this value is not permitted to be printed or saved in a weighing instrument operated in legal metrology in the SBI mode. In this case, the unit symbol is not included with output.

















## External Keyboard Functions (PC Keyboard)

For settings, go to the Setup menu under “**Device parameters:**  
**Bar code: External keyboard.**”

The alphanumeric key codes implemented here are specific to the German keyboard layout. The following alphanumeric characters are used (some require the “Shift” key):

a - z, A - Z, 0 - 9, <space>, and these characters: ., \ + ' < > / » \$ @ % / () ; = : \_ ? \*

Function keys:

PC keyboard	Combiics 3
F1	 key
F2	 key
F3	 key
F4	F5 soft key (far left)
F5	F4 soft key (second from left)
F6	F3 soft key (middle)
F7	F2 soft key (second from right)
F8	F1 soft key (far right)
F9	 key
F10	 key - long (info function)
F11	 key
F12	 key
Print	 key
Return	F1 soft key (far right)
Cursor up	F3 soft key (middle)
Cursor left	F4 soft key (second from left)
Cursor down	F2 soft key (second from right)
Cursor right	F1 soft key (far right)
Pos 1	   
Backspace	 key
ESC	 key

## Configuring the Data Interface as a Printer Port

### Device Parameters

Config. printout		
Headers	Line 1: Line 2:	
Identifiers	ID1: ID2: ID3: ID4:	
ISO/GMP Protocol	o Off For several application results	
Date/Time	o Date with time Date only	
Once at Stability <sup>2)</sup>	o Off On	
FlexPrint	o Off On	
Printer 1	Number of printouts	o 1 printout 2 printouts
	Single printout <sup>1)</sup>	o Max. 30 print items can be selected o ID1, ... ID4
	Component/Printout <sup>1)</sup>	o Max. 30 print items can be selected o
	Total data printout	Max. 30 print items can be selected
Printer 2	as for Printer 1	
Factory setting Printout	Reset Do not reset	

o Factory setting

<sup>1)</sup> Multiple selections possible

<sup>2)</sup> When the minimum load is exceeded (can be set under menu item: "Application parameters: ... : Min. load for autom. taring")

# Data Interfaces

There are several actions that generate the command for outputting data to the printer port:

- Pressing the **(E)** key.  
If the operating menu is active, all menu settings under the active menu level are printed.
- In some applications, pressing a given key (e. g., to save a value or start a routine) also generates a print command, or it is generated automatically depending on the application configuration. In this case, a configurable printout is generated with application-specific data.

The **Ⓞ** and **◆** symbols are displayed when data is being output to the printer port.

## Configuring a Printout

A printout can be configured in the Setup menu under “**Device parameters: Config. printout.**” This should be carried out **after** configuring the application since some data in the printout is application-dependent.

You can configure a separate printout for each interface. Each printout is comprised of different information blocks that can be activated or deactivated via multiple selection in the menu.

For the “Totalizing” and “Net-total Formulation” applications, the totalizing/results printout can be configured independent of the individual/component printout.

The individual information blocks are shown below with detailed explanations. Samples of complete printouts are provided following the end of this section.

### Headers

2 headers each with a max. of 20 characters are available (e. g. for printing the company name).

Print image example:

ACE HARDWARE  
GOETTINGEN

### Date/Time

Print image example:

21.01.2010            16:02

To maintain a uniform time (e. g. for documentation within a complete automatic system), the printing of the time can be suppressed in “**Device parameters: Config. printout: Date/time.**” When you set “**Date only.**” the time can be added, e. g. from a superordinate control in order to always have the same time throughout the system. This setting is mainly designed for communication with a PC.

### Identifiers

Use the “**ID**” soft key to enter text in the named IDs via the keypad.

ID:	
LOT NO.	12345
CUSTOMER	ACE HARDWARE
PRODUCT	SCREWS
EMPLOYEE	SMITH
ID5	
ID6	

<< Delete ^ v

## Application Initialization Data

Which data is included in this block depends on the active application. In the “Counting” application, for example, the reference sample quantity and reference weight are printed (plus a blank line).

“Counting” print block example:

```
nRef          10 pcs
wRef +       0.035 kg
```

## Scale Identification

Print image example for weighing platform serial number:

```
Ser.no.      1234567890
```

## Scale Identification

This content is application-dependent. If provided in the application, the gross, net and tare weights are usually printed, followed by a blank line. This block is terminated by a dotted line. “Counting” application print image example:

```
G#   +   1.402 kg
T    +   0.200 kg
N    +   1.202 kg

Qnt          34 pcs
-----
```

## GMP-compliant printouts

When this function, the printout is supplemented with a GMP header and a GMP footer (GMP: “Good Manufacturing Practice”).

If the GMP-compliant printout is activated, the  $\square$  symbol remains displayed until the GMP footer is printed.

Setting: Setup menu under “**Device parameters: Config. printout: ISO/GLP/GMP- printout.**”

You can choose from the following settings:

- GMP-compliant printout off (factory setting)
- GMP-compliant printout for multiple application results

The GMP header is included from the first printout generated subsequent to the activation of the GMP printout.

The GMP footer is printed after several measurement results by pressing and holding the  $\square$  key, e.g. for component printing (menu item “For multiple application results”). In this case, the  $\square$  symbol remains visible until the GMP footer is printed.

If you toggle to a different platform while a GMP printout of several measured results is being generated, the GMP footer for the platform used up to that point is generated when you press the  $\square$  key. The GMP header for the other platform is included on the next printout generated.

A GMP-compliant printout is generated automatically at the conclusion of calibration/adjustment and linearization routines, as well as when you set or delete a preload.

If you use a label printer for GMP-compliant printouts, you may find that a single label is not long enough for the data printed. If this is the case, you can activate the automatic form feed after each printout of a GMP header and measurement results. The following provides sample GMP headers and footers (see “Sample Printouts”).

# Data Interfaces

## Sample Printouts

For details on the individual information blocks, see “Configuring Printouts.” For details on configuring the header lines, refer to the chapter of the respective application.

### “Weighing” application

The “Application initialization data” information block is empty. If selected, an empty line will be printed.

Display with ID and weighing platform:

```

          HEADER LINE1
          HEADER LINE2
14.01.2010      09:43
-----
Ser.no.        80705337

G#   +   1.402 kg
T    +   0.200 kg
N    +   1.202 kg
-----

```

### “Counting” application

The initialization data block contains the reference sample quantity and the reference sample weight.

The results block contains gross, net and tare weight and the piece count as a result.

```

          HEADER LINE1
          HEADER LINE2
14.07.2010      09:43
-----
nRef          10 pcs
wRef +   0.035 kg

G#   +   1.402 kg
T    +   0.212 kg
N    +   1.190 kg

Qnt          34 pcs
-----

```

### “Neutral Measurement” application

The initialization data block contains the reference sample quantity and reference weight. The results block contains gross, net and tare weight and the piece count as a result.

```

          HEADER LINE1
          HEADER LINE2
Ref         2 o
wRef +   1.200 kg

G#   +   14.700 kg
T    +   0.300 kg
N    +   14.400 kg

Qnt          12 o
-----

```

### “Weighing in Percent” application

The initialization data block contains the reference percentage and reference weight. The results block contains gross, net and tare weights, as well as the percentage, which is shown as either the loss or the residual amount.

Percentage = residual

```

          HEADER LINE1
          HEADER LINE2
14.07.2010      09:43
-----
pRef          100 %
Wxx% +   2.100 kg

G#   +   1.859 kg
T    +   0.200 kg
N    +   1.659 kg

Prc          79 %
-----

```

Percentage = loss:

```

          :
          :
          :
D          21 %
-----

```

### “Checkweighing” application

The initialization data block contains the target weight, the minimum and maximum load. The results block always contains the gross, net and tare weight. Additional results can be printed in 2 different display types:

- Weight display:

In the OK and nonconforming range, the deviation from the target weight is always printed as a percentage and absolute deviation.

- Relation to target value:

In the OK range, the deviation from the target weight is printed as a percentage and absolute deviation. In the nonconforming range, “HH” is printed for exceeding the weight and “LL” for falling below the weight.

OK range in the weight and tolerance limit display

```

          HEADER LINE1
          HEADER LINE2
14.07.2010      09:43
-----
Setp +   1.300 kg
Min  +   1.235 kg
Max  +   1.365 kg

G#   +   1.312 kg
T    +   0.000 kg
N    +   1.312 kg

Lim  +   0.92 %
W.Diff+ 0.012 kg
-----

```

Nonconforming range in the weight display

```

          :
          :
          :
Lim  -   7.69 %
W.Diff- 0.100 kg
-----

```

Result outside (under) “OK” range; “Threshold” printout:

```

          :
          :
          :
Stat      LL
-----

```

Result outside (over) “OK” range; “Threshold” printout:

```

          :
          :
          :
Stat      HH
-----

```

# Data Interfaces

## “Classification” Application

The initialization block contains the upper limits of weight classes 1, 2, 3, 4.

The results block contains gross, net and tare weights, as well as the assigned weight class as a result (1 to 5, whereby class 5 is the one that exceeds class 4).

```

          HEADER LINE1
          HEADER LINE2
14.07.2010      09:43
-----
Lim1 + 10.000 kg
Lim2 + 11.000 kg
Lim3 + 12.000 kg
Lim4 + 13.000 kg

G# + 9.700 kg
T + 0.000 kg
N + 9.700 kg

Class 1)
-----

```

1) Classification can range from 1 to 5.

The sample is assigned to class 5 if its weight exceeds the weight limit “Lim4” and “5 classes” was previously selected in the menu.

## “Animal Weighing” Application

The Initialization data block contains the number of measured values that averaging is based on. The results block contains the tare weight and the average value.

```

          HEADER LINE1
          HEADER LINE2
14.07.2010      09:43
-----
mDef 8

T + 0.000 kg
x-Net + 4.202 kg
-----

```

## “Net-total Formulation” Application

The Initialization data block is empty. The data that is contained in the results block depends on the program operating status at the time of printing. The following options are available:

- Total/results printout (CF key)
- Individual/components printout (when the “M+” soft key is pressed to save a component, or when (E) is pressed for an individual printout)

Total printout

```

          HEADER LINE1
          HEADER LINE2
14.07.2010      09:43
-----
n 3
Tot.cp+ 3.400 kg
Cont.T+ 0.200 kg
-----

```

## Individual/Component Printout

If you press O the header is printed only once. Each component is printed automatically when you press M+.

If this printout should be printed on a label printer, the label length should be checked. For printer models YDP01IS and YDP04IS, you can configure manual form feed in the Setup menu.

With the YDP02IS printer, form feed is automatic after each print command (fixed setting).

If an automatic printout is generated when you store a component, the component weight is equal to the current net weight. This is why components rather than net weights are printed.

Menu setting “Print components” with 3 components:

```

          HEADER LINE1
          HEADER LINE2
14.07.2010      09:43
-----
Cmp001+ 1.200 kg
Cmp002+ 2.000 kg
-----

```

Printout of third component generated by pressing (E).

```

G# + 4.400 kg
T + 0.200 kg
T2 + 4.200 kg
N + 0.000 kg

```

Individual printout when storing a component in tare memory by pressing (OK).

Menu setting “Print components” example: print 2nd component

```

          HEADER LINE1
          HEADER LINE2
14.07.2010      09:43
-----
Cmp002+ 1.000 kg

```

Individual printout of component generated by pressing (E), example: 2nd component

```

          HEADER LINE1
          HEADER LINE2
14.07.2010      09:43
-----
G# + 2.400 kg
T + 0.200 kg
T2 + 2.200 kg
N + 0.000 kg

```

## “Totalizing” application

The initialization data block is empty; an empty line is printed as required.

The values displayed in the results block depend on the program status. The following options are available in the Setup menu:

- Results printout (press CF key): Printout of values from gross totalizing memory “\*G,” net totalizing memory “\*N” and number of transactions “n”.
- Individual/component printout automatic with M+ soft key
- Individual/component printout manual with (E) key

The record header is only printed once for the component printout. All components are printed one below the other.

If this printout should be printed on a label printer, the label length should be checked (see “Net Total” application).

The transaction counter is not printed for a manual printout (with the (E) key).

Component printout,  
example with 3 transactions:

```

      HEADER LINE1
      HEADER LINE2
14.07.2010      09:43
-----
G#   +   1.400 kg
T    +   0.200 kg
N    +   1.200 kg
n                1

G#   +   3.400 kg
T    +   0.200 kg
N    +   3.200 kg
n                2

G#   +   4.400 kg
T    +   0.200 kg
N    +   4.200 kg
n                3

```

Total printout (by pressing **[CF]**);  
application data and status as above:

```

      HEADER LINE1
      HEADER LINE2
14.01.2010      09:43
-----
*G           9,200 kg
*N    +     8,600 kg
n                3
-----

```

Individual printout when storing a  
transaction in totalizing memory by  
pressing **[SETUP]**  
Example: print 2nd transaction

```

      HEADER LINE1
      HEADER LINE2
14.07.2010      09:43
-----
G#   +   2.400 kg
T    +   0.200 kg
N    +   2.200 kg
n                2

```

Individual printout (by pressing **[E]**),  
example: print 2nd transaction

```

      HEADER LINE1
      HEADER LINE2
14.07.2010      09:43
-----
G#   +   2.400 kg
T    +   0.200 kg
N    +   2.200 kg

```

### GMP-compliant printouts

The GMP-compliant printout consists  
of 3 sections (see also the section  
entitled "Enabling GMP-compliant  
Printouts," above):

- GMP header
- Printout of data record  
(for example, from the Weighing  
application)
- GMP footer

"Linearization" printout

```

-----
14.07.2010      13:00
Type           CAIS3
Ser.no.       12345678
Vers.        1.02.101110
BVers.       01-63-01
-----

```

Linearization

```

Wt.1 +   7.00 kg
Wt.2 +  15.00 kg
Wt.3 +  22.00 kg
Wt.4 +  30.00 kg
-----
                    completed
-----

```

```

14.07.2010      13:02
Name:
-----

```

Calibration/adjustment printout

```

-----
14.07.2010      13:50
Type           CAIS3
Ser.no.       12345678
Vers.        1.02.101110
BVers.       01-63-01
-----

```

External calibration

```

Targ. +   30.00 kg
Diff. -    0.03 kg
External adjustment
Diff. +    0.00 kg
-----

```

```

14.07.2010      13:52
Name:
-----

```

Setting the preload printout

```

-----
14.01.2010      13:50
Type           CAIS3
Ser.no.       12345678
Vers.        1.02.101110
BVers.       01-63-01
-----
Set preload
                    completed
-----
14.07.2010      13:52
Name:
-----

```

Deleting the preload printout

```

-----
14.07.2010      13:50
Type           CAIS3
Ser.no.       12345678
Vers.        1.02.101110
BVers.       01-63-01
-----
Delete preload
                    completed
-----
14.07.2010      13:52
Name:
-----

```

Weighing printout with multiple results  
(example: 2 results):

```

-----
14.07.2010      09:43
Type           CAIS3
Ser.no.       12345678
Vers.        1.02.101110
BVers.       01-63-01
-----

```

```

      HEADER LINE1
      HEADER LINE2
14.07.2010      09:43
-----
G#   +   2.40 kg
T    +   0.20 kg
N    +   2.20 kg
-----

```

```


      HEADER LINE1
      HEADER LINE2
14.07.2010      09:44
-----
G#   +   3.40 kg
T    +   0.30 kg
N    +   3.10 kg
-----
14.07.2010      09:45
Name:
-----

```

# Error Codes

Errors are divided into the following:

- Fatal and dynamic errors are displayed for the duration of the error via the “ERR” error code.
- Temporary errors are displayed for 2 seconds via the “INF” error code; then the program automatically switches back to normal weighing operation.

Display	Cause	Solution
ERR 101 - 104	Key is stuck Key pressed when switching on device	Release key or contact Sartorius customer service
ERR 320	Operating program memory faulty	Contact your local Sartorius Service Center
ERR 335	Verified weighing platform not compatible with the connected terminal	Connect a compatible weighing platform
ERR 340	Incorrect operating parameter (EEPROM)	Turn the scale off and then on again. If the error code Err340 is still displayed please contact your local Sartorius Service Center
ERR 341	RAM has lost data Battery is empty	Connect the device to power for at least 10 hours
ERR 343	Loss of data in the memory area for transaction numbers in external alibi memory	Contact your local Sartorius Service Center
INF 01 »Display overload«	Data output not compatible with output format	Set output format correctly
INF 02 »Zero point error at start of cal.«	Calibration condition was not maintained, e.g. not tared or weighing pan loaded	Unload the scale first then zero, then tare via the  key
INF 03	Adjustment could not be completed within a specific time.	Allow to warm up again and repeat the adjustment process
INF 06 »Int. weight not available or missing«	Integrated adjustment weight defective	Contact your local Sartorius Service Center
INF 07 »Function not allowed for verifiable weighing«	Function not allowed in scales verified for use in legal metrology	Contact your local Sartorius Service Center for information on changing settings
INF 08	The load on the scale is too heavy to zero the readout	Check whether “Tare/zero at power on” was complied with in your configuration.
INF 09	Taring is not possible when the scale gross weight is < zero	Zero the scale
INF 10	Tare key is blocked when there is data in the tare memory	The data stored for the application program must be deleted before taring.
INF 22	Error in storing reference value	Load is too light, place a heavier weight on the weigher
INF 23 »Error Application error«	Error in initializing an application	Contact your local Sartorius Service Center
INF 29 »Scale minimum load not reached«	Minimum load not reached	Reduce minimum load (in the “Application parameters,” under “Minimum load for autom. initialization”)
INF 71 »Invalid value, Value too low/high or selection is not possible«	Cannot store the current weight value (e.g., control limits too low or too high)	None
INF 72 »Maximum quantity reached«	Cannot store the current weight value (e.g. transaction counter maximum reached)	None
INF 73 »Memory deleted/ Memory not available«	Data not found or unreadable	Contact your local Sartorius Service Center
INF 74 »Function is not available« or »Function is blocked«	Function is blocked (e.g. Menu is blocked)	None
INF 88 »Function was started«	A function has been activated	None
INF 98	No weighing platform connected	Connect a weighing platform
INF 99	No weighing platform connected	Connect a weighing platform
NO WP	No weighing platform connected	Connect a weighing platform



# Care and Maintenance

## Service

Regular servicing by a Sartorius technician will extend the service life of your equipment and ensure its continued weighing accuracy. Sartorius offers its customers service contracts with regular maintenance intervals ranging from one month to two years. The frequency of the maintenance intervals depends on the operating conditions and the operator's tolerance requirements.

## Repairs



Disconnect the power supply to the defective equipment immediately (unplug the power cord from the mains supply). Repair work must be performed by authorized Sartorius service technicians using original spare parts. Repairs performed by untrained persons may result in considerable hazards for the user.



If a cable or cable gland is damaged or defective, replace the cable as a complete unit with all its connectors.



Do not open the indicator while it is carrying current. Wait at least 10 seconds after disconnecting it from power before beginning to open the equipment. Proper fitting of all surfaces is essential for the IP rating of the housing; for this reason the device must be opened and closed by a certified technician.

---

## Cleaning

Indicators are designed in compliance with European Hygienic Equipment Design Group (EHEDG) directives on suitable measures to avoid contamination, so that they are particularly easy to clean and disinfect.



Disconnect the power supply to the indicator (unplug the power cord from the mains supply). If necessary, disconnect the data cable.



Make sure that no liquid enters the indicator.



Do not use aggressive cleaning agents (solvents or similar agents).



Do not spray the device with water or blow with compressed air.

---

- ▶ Clean the indicator with a cloth lightly moistened with a soap solution. For use in the food industry, use a cleaning agent suitable for the particular working environment.
- ▶ Wipe the indicator with a soft, dry cloth.

## Cleaning Stainless Steel Surfaces

- Only use conventional household cleaning agents which are suitable for stainless steel.
- Only use solvents for cleaning stainless steel parts.
- ▶ All stainless steel parts should be cleaned at regular intervals: Rub stainless steel surfaces with a moist cloth, with a cleaning agent if required, then remove all residue from the surface.
- ▶ Allow device to dry. For additional protection, protective oil may be applied.

## Replacing the Dust Cover

A damaged dust cover should be replaced immediately.

- ▶ Remove damaged dust cover.
- ▶ Place the new dust cover on the display and control unit and press it over the edge of the front and rear side of the device until it is fixed in place.

## Safety Inspection

Safe operation of the equipment is no longer ensured:

- The device or the mains connecting lead shows visible damage.
- The integrated power supply for the indicator no longer functions properly.
- The device has been stored for a relatively long period under unfavorable conditions (e. g., excessive humidity)

If there is any indication that safe operation of the device is no longer warranted:

- ▶ Disconnect the power supply to the device (unplug the power cord from the mains supply) and make sure the device cannot be used for the time being.
- ▶ Notify your nearest Sartorius Service Center.

Maintenance and repair work may only be carried out by service technicians:

- Who have access to the required maintenance documents and manuals  
and
- Who have attended the appropriate training workshops




The seals on the device indicate that the device may only be opened and maintained by authorized specialist personnel, so that the correct and safe operation of the device is ensured and the guarantee remains valid.

---

# Disposal

If the packaging is no longer needed, it can be disposed of by local waste disposal authorities. The packaging is made of environmentally friendly materials that can be used as secondary raw materials.



The equipment, including accessories and batteries, should not be disposed of as regular household waste. EU legislation requires its Member States to collect electrical and electronic equipment and dispose of it separately from other unsorted municipal waste so that it may be recycled.

In Germany and many other countries, Sartorius AG takes care of the return and legally compliant disposal of its electrical and electronic equipment. These products may not be placed with household waste or brought to collection centers run by local public disposal operation - not even by small commercial operators. For disposal in Germany and in the other member nations of the European Economic Area (EEA), please contact our local service technicians or our Service Center in Goettingen, Germany:

Sartorius AG  
Weender Landstrasse 94-108  
37075 Goettingen, Germany

In countries that are not members of the European Economic Area (EEA) or where no Sartorius subsidiaries or dealerships are located, please contact your local authorities or a commercial disposal operator.

Prior to disposal and/or scrapping of the equipment, any batteries should be removed and disposed of in local collection boxes.

Sartorius will not take back equipment contaminated with hazardous materials (ABC contamination) either for repair or disposal. Please refer to our website ([www.sartorius.com](http://www.sartorius.com)) or contact the Sartorius Service Department for more detailed information regarding repair service addresses or the disposal of your device.

# Specifications

## ADC scale interface 2\*3000e (option A8)

When used in standard applications (as opposed to legal metrology):

- Display resolution  $\leq 31250$  d
- Lowest permissible input signal 625 d

Using the Equipment in Legal Metrology:

Accuracy class  $\textcircled{\text{III}}$ ,  $\textcircled{\text{III}}$

Verification scale intervals when used as:

- Single-range mode  $\leq 3125e$
- Multi-interval mode  $\leq 3125e$

Maximum  $e1$  6250e

- Multiple-range mode  $\leq 3125e$

Load cell connection:

- Supply voltage 8.4 V ( $\pm 4.2$  V)
- Bridge impedance 83  $\Omega$  to 2000  $\Omega$
- Available sensor technology 4-conductor or 6-conductor technology

When used in legal metrology:

- Available sensor technology 6-conductor technology
- Max. cable length per gauge 150 m/mm<sup>2</sup>
- Lowest permissible input signal  
for  $P_{ind} = 0.5$  0.672  $\mu\text{V}/e$   
for  $P_{ind} = 0.3$  1.12  $\mu\text{V}/e$
- Fraction of tolerance for this module:  
for  $\Delta U_{min} \geq 0.672 \mu\text{V}/e$  0,5  
for  $\Delta U_{min} \geq 1.12 \mu\text{V}/e$  0.3

Measuring signal 0 mV to 27.7 mV

Measuring signal variation 4.2 mV to 27.7 mV

Sensitivity 4 million digits max. (internal)

Digital protective interface According to EN45501

Data interface Bidirectional RS-232 interfaces with control outputs (5 V, TTL standard), built-in as standard

Additional data interface: Optional

Display 20 mm weight value, 7-digit plus status symbols, backlit

Housing:

- Material Stainless steel 1.4301
- Protection class according to EN60529 CAISL3: IP44 (IP65 as accessory)  
CAIS3: IP69K

Temperature range -10°C to +40°C

Power supply 100-240 V AC (-15/+10%), 50-60 Hz, max. 17 W / 23 VA  
optional 15.5-24 V DC ( $\pm 10\%$ ), max. 12 W  
optional 13-17 V AC ( $\pm 10\%$ ), 50-60 Hz, max. 12 W

Emissions Acc. to EN 61326-A1, Class B (IEC 61326-A1)

Defined immunity to interference Acc. to EN 61326-1, industrial areas (IEC 61326-1)

Electrical safety Acc. to EN 61010-1 (IEC 101-1), EN 60950-1 (IEC 950)

# Specifications

## ADC scale interface 10,000e (Option A20)

When used in standard applications (as opposed to legal metrology):

- Display resolution  $\leq 100.000$  d
- Lowest permissible input signal 1510 d

Using the Equipment in Legal Metrology:

Accuracy class  $\textcircled{\text{III}}$ ,  $\textcircled{\text{III}}$

Verification scale intervals when used as:

- Single-range mode  $\leq 10000e$
- Multi-interval mode  $\leq 3125e$

Maximum  $e1$   $\leq 15100e$

- Multiple-range mode  $\leq 3125e$

Load cell connection:

- Supply voltage 8.2 V ( $\pm 4.1$  V)
- Bridge impedance 83  $\Omega$  to 2000  $\Omega$
- Available sensor technology 4-conductor or 6-conductor technology

When used in legal metrology:

- Available sensor technology 6-conductor technology
- Max. cable length per gauge 150 m/mm<sup>2</sup>
- Lowest permissible input signal  
for  $P_{ind} = 0.5$  0.328  $\mu\text{V}/e$   
for  $P_{ind} = 0.3$  0.546  $\mu\text{V}/e$
- Fraction of tolerance for this module:  
for  $\Delta U_{min} \geq 0.328 \mu\text{V}/e$  0.5  
for  $\Delta U_{min} \geq 0.546 \mu\text{V}/e$  0.3

Measuring signal 0 mV to 24.6 mV

Measuring signal variation 3.28 mV to 24.6 mV

Sensitivity 4 million digits max. (internal)

Digital protective interface According to EN45501

Data interface Bidirectional RS-232 interface with control outputs (5 V, TTL standard), built-in as standard

Additional data interface: Optional

Display 20 mm weight value, 7-digit plus status symbols, backlit

Housing:

- Material Stainless steel 1.4301
- Protection class according to EN60529 CAISL3: IP44 (IP65 as accessory)  
CAIS3: IP69K

Temperature range -10°C to +40°C




Power supply 100-240 V AC ( $-15/+10\%$ ), 50-60 Hz, max. 17 W / 23 VA  
optional 15.5-24 V DC ( $\pm 10\%$ ), max. 12 W  
optional 13-17 V AC ( $\pm 10\%$ ), 50-60 Hz, max. 12 W  
Acc. to EN 61326-A1, Class B (IEC 61326-A1)

Emissions

Defined immunity to interference Acc. to EN 61326-1, industrial areas (IEC 61326-1)


Electrical safety Acc. to EN 61010-1 (IEC 101-1), EN 60950-1 (IEC 950)

# Device Dimensions



All data in mm

# Accessories



**Product**

**Order No.**

Verifiable printer with functions for date, time and statistical evaluations and LC display.

- 5x 50 m paper rolls for data printer
- Replacement ink ribbon cartridge for printer

YDP20-OCE  
6906937  
6906918



Verifiable strip and label printer with barcode printout, paper width 108 mm, with adapter cable (12-pin round male connector) and external power supply.

YDP14IS-OCEUV

Verifiable strip and label printer with barcode printout, paper width 60 mm, with adapter cable (12-pin round male connector) and external power supply.

YDP04IS-OCEUV

- Adapter cable for CAISL indicator
- Adapter cable for CAIS indicator

YCC01-01CISLM3  
YCC02-R12F6



Verifiable strip and label printer with thermal print head, paper width 60 mm, with adapter cable (12-pin round male connector) and external power supply.

YDP14S-OCEUVTH

- Adapter cable for CAISL indicator
- Adapter cable for CAIS indicator
- Ink ribbon for YDP14IS-OCEUVTH
- 3 paper rolls for YDP04IS, 60 mm x 75 m, thermal paper
- Labels, small, 58 mm x 30 mm, 1000 labels
- Labels, medium, 58 mm x 76 mm, 500 labels
- Labels, large, 58 mm x 100 mm, 350 labels

YCC01-01CISLM3  
YCC02-R12F6  
69Y03234  
69Y03090  
69Y03092  
69Y03093  
69Y03094

**Installation option as accessory of the optional UniCOM interface**

Interface module (RS-232)  
Interface module (RS-485 and RS-485), electrically isolated  
Electrically isolated digital I/Os, 5 outputs and 5 inputs, freely configurable  
Analog current output, 0-20 mA, 4-20 mA, 0-10 V, 16 bit <sup>1)</sup>  
Profibus DP interface module <sup>1)</sup>  
Ethernet interface module

**CAISL3**

for installation in IP44 version  
•  
•  
•  
•  
-  
-

**CAIS3**

for installation in IP69K version  
•  
•  
•  
•  
•

YD002C-232  
YD002C-485  
  
YD002C-DIO  
YD002C-AO  
YD002C-DP  
YD002C-ETH

<sup>1)</sup> suitable for use in zones 2 + 22

Product	Order No.
<b>Replacement 1st weighing point/scale connection instead of internal A/D converter (3000e)</b>	
Analog platform 10,000e	YDI02C-WPA
RS-232 interface for digital platform	YDI02C-WPD
RS-485 interface for digital platform	YDI02C-WPD
<b>2nd weighing point/Scale connection</b>	
Analog platform 10,000e	YDI02C-WPA
RS-232 interface for digital platform	YDI02C-WPD
RS-485 interface for digital platform	YDI02C-WPD
<b>External interface adapter</b>	
Connection cable from RS-232 data interface to USB interface on the PC, D-SUB plug 25-pin, 2 m <sup>1)</sup>	YCC01-USBM2
Digital input/output module to connect Combics 2 to external control units, with 8 open collector outputs (50 mA) and 7 TTL-compatible inputs (0 - 30 V), YCC02-RELAIS01/02 connection cable required	YSB02
Relay box to connect Combics 2 to external control units, YCC02-RELAIS01/02 connection cable required	VF3033
<b>Software</b>	
Sartorius Nice Label Express (SNLE)	YAD02IS
WinScale for Windows	YSW03
SartoCollect	YSC02
<b>Other functions</b>	
Guard covers (x2)	YDC01CI
IP65 kit for cable connections (D-SUB 25)	on request
Cable gland for cables with diameter 4.5 to 9 mm, M16 x 1.5	YAS04CIS
Kit for control panel installation <sup>2)</sup>	YAS07CI
Plug and socket set to connect similar weighing platforms to indicators (separable connection)	YAS99I
Stainless steel cable connection box for connecting up to 4 load cells in one platform or for external assembly, PR6130/64S	940536130642
Relay box to connect scale to external control units with 4 (5), relay outputs (250V/3A) and 1 optocoupler input (0 - 30 V)	YSB01
<b>Peripheral devices</b>	
Control display red/green/red	YRD14Z
Remote display for Combics CAISL indicators	YRD02Z
Remote display, 7-segment, up to 45 mm character size	on request
Barcode scanner, 120 mm scanning width, with cable for connection to CAISL2	YBR03PS2
Foot switch, incl. D-Sub 25-pin T-connector	YFS01
Hand switch, incl. D-Sub 25-pin T-connector	YHS02
Flow control for pumps with analog or pulse interface	YFC02Z-V2
Flexible formatting options for printouts (e. g., barcodes, variable font sizes, graphics, etc.)	on request

<sup>1)</sup> Model CAISL only

<sup>2)</sup> Suitable for use in zones 2 + 22



# Accessories

Product	Order No.
<b>Mechanical accessories</b>	
Brackets for wall mounting, stainless steel	YDH02CIS
Floor-mounted column	YDH03CIP
Floor-mounted column, stainless steel	YDH03CIS
Base for installing floor-mounted column	YBP03CIP
Base for installing floor-mounted column, stainless steel	YBP03CIS
Mount for barcode scanner, to be attached to: floor-mounted column, bench stand, complete scale retainer	YBH01CWS
Plate for attaching a printer to the floor-mounted column or bench stand	YPP01CWS
Castor set (2 guide castors, 2 lockable castors) for YBP03CIP/S floor-column base	YR003CI
Plug and socket set to connect similar weighing platforms to indicators (separable connection)	YAS99I
<b>Electrical requirements</b>	
24 V industrial power supply module <sup>1)</sup>	on request
External rechargeable battery pack, up to 40 h operation, incl. charger	YRB10Z
External rechargeable battery pack, up to 40 h operation, w/out charger	YRB10Z-R
<b>Connection cable for CAIS (IP 69K)</b>	
Connection cable with cable gland, open cable ends on Combics side	
- for barcode scanner YBR03FC, 5-pin DIN socket, 1 m	YCC02-BR02
- for printer YDP12/04IS, 9-pin D-SUB plug, 6 m	YCC02-D09M6
- for printer YDP20-OCE or PC, 9-pin D-SUB socket, 6 m	YCC02-D09F6
- for Sartorius scales, 25-pin D-SUB plug, 6 m	YCC02-D25M6
- for various accessories, 25-pin D-SUB socket, 6 m	YCC02-D25F6
- for Sartorius scales, 12-pin round plug, 6 m	YCC02-R12M6
- for various accessories and IS platforms, 12-pin round plug socket, 6 m	YCC02-R12F6
- open cable ends, 6 m	YCC02-RELAIS02
Ethernet connection cable with cable gland and RJ45 plug, 7 m	YCC02-RJ45M7
<b>Connection cable for CAISL (IP 44)</b>	
Connection cable 25-pin D-SUB plug on Combics side	
- for printer YDP12/04IS, 9-pin D-SUB plug, 6 m	YCC01-01CISLM3
- for PC, 9-pin D-SUB socket, 6 m	7357314
- for Sartorius scales, 25-pin D-SUB plug, 3 m	YCCDI-01M3
- for various accessories, 25-pin D-SUB socket, 6 m	7357312
- for Sartorius scales, 12-pin round plug, 3 m	YCC01-02ISM3
- for various accessories and IS platforms, 12-pin round plug socket, 6 m	YCC01-03CISLM3
- open cable ends, 6 m	YCC02-RELAIS01
Connection cable from RS-232 data interface to USB interface on the PC, 25-pin D-SUB plug, 2 m	YCC01-USBM2

<sup>1)</sup> Suitable for use in zones 2 + 22

## Documents List

### Operating instructions

Basis-Applikation Programs (Option H0 and I2)	98646-003-22
Basic filling (Option H3)	98646-002-18
Filling with Extras (Option H4)	98646-002-23
ProControl Terminal (Option H6)	98646-002-34
UniCOM interfaces:	98647-004-24
Standard field bus interface	98646-002-04
Verifiable alibi memory	98647-004-40

### Installation Instructions

Use in Zone 2 and 22 potentially explosive atmospheres (option Y2)	98647-003-40
--	--------------

## Sartorius Services

### “Installation” service in Germany

Our “Installation” service package provides a range of important services that guarantee satisfactory work from your device:

- Installation
- Commissioning
- Inspection
- Instruction

You can request these services from our customer service using the “Installation Check No. 2” in the included warranty and service check folder.

### Re-verification in Germany

Scale verification for legal metrology is valid until the end of the calendar year after next. If the scale is used for fill level control in accordance with legislation on prepackaging, verification is valid until the end of the following calendar year. Re-verification must currently be carried out by a weights and measures official. Re-verification should be requested in good time from the local Weights and Measures office. As appropriate, please observe all statutory amendments.

### Re-verification within Europe and Outside of Germany

The expiration date of the verification depends on the national regulations of the country in which the weighing instrument is used. For information on verification and legal regulations currently applicable in your country, and to obtain the names of the persons to contact, please contact your local Sartorius office, dealer, or Service Center. Further information concerning verification can be obtained from our customer service centers.

# Declarations of Conformity

CE Directive 2004/108/EC and CE Directive 2006/95/EC



**sartorius**  
mechatronics

## CE EG-Konformitätserklärung EC Declaration of Conformity

Sartorius AG  
Weender Landstr. 94 - 108  
37075 Göttingen, Germany

erklärt, dass das Betriebsmittel  
*declares that the equipment*

Gerät: **Combics Indikator**  
*Apparatus: Combics indicator*

Typbezeichnung / *Type:* CAIS1, CAIS2, CAIS3, CAISL1, CAISL2, CAISL3

mit den grundlegenden Anforderungen der folgenden Europäischen Richtlinien übereinstimmt:  
*complies with the basic requirements of the following European Directives:*

**Richtlinie 2004/108/EG** Elektromagnetische Verträglichkeit  
*Directive 2004/108/EC Electromagnetic compatibility*

**Richtlinie 2006/95/EG** Elektrische Betriebsmittel zur Verwendung innerhalb bestimmter Spannungsgrenzen  
*Directive 2006/95/EC Electrical equipment designed for use within certain voltage limits*

Das Gerät erfüllt die anwendbaren Anforderungen der folgenden harmonisierten Europäischen Normen:  
*The apparatus meets the applicable requirements of the following harmonized European Standards:*

EN 61326-1:2006 Elektrische Mess-, Steuer-, Regel- und Laborgeräte - EMV- Anforderungen - Teil 1: Allgemeine Anforderungen (IEC 61326-1:2005)  
*Electrical equipment for measurement, control and laboratory use - EMC requirements - Part 1: General requirements (IEC 61326-1:2005)*

EN 61010-1:2001 Sicherheitsbestimmungen für elektrische Mess-, Steuer-, Regel- und Laborgeräte - Teil 1: Allgemeine Anforderungen (IEC 61010-1:2001)  
*Safety requirements for electrical equipment for measurement, control, and laboratory use - Part 1: General requirements (IEC 61010-1:2001)*

Jahr der Anbringung des CE-Zeichens: **10**  
*Year of attachment of CE mark:*

Sartorius AG  
Göttingen, 2010-09-17

Dr. Reinhard Baumfalk  
Leitung Entwicklung /  
Vice President, R&D  
Mechatronik / Mechatronics

Dr. Dieter Klausgrete  
Leitung International Certification Management /  
Head of International Certification Management  
Mechatronik / Mechatronics

SAG10CE021

65954-000-58

SOP-3.RD-045-fo2

# Declarations of Conformity

CE Directive 2002/95/EC



## Konformitätserklärung *Declaration of Conformity*

Sartorius AG  
Weender Landstr. 94 - 108  
37075 Göttingen, Germany

erklärt, dass das Betriebsmittel  
*declares that the equipment*

Gerät: **Combics Indikator**  
*Apparatus: Combics indicator*

Modell / *Model:* CAIS1, CAIS2, CAIS3, CAISL1, CAISL2, CAISL3

übereinstimmt mit den Regelungen der Europäischen Richtlinie (in der heute gültigen Fassung):  
*complies with the regulations of the European Directive (in the today valid version):*

Richtlinie 2002/95/EG Zur Beschränkung der Verwendung bestimmter gefährlicher Stoffe  
in Elektro- und Elektronikgeräten

*Directive 2002/95/EC on the restriction of the use of certain hazardous substances in electrical  
and electronic equipment*

sofern das Betriebsmittel gekennzeichnet ist mit:  
*provided that the equipment is marked with:*



Sartorius AG  
Göttingen, 2010-09-17

Dr. Reinhard Baumfalk  
Leitung Entwicklung /  
*Vice President, R&D*  
Mechatronik / *Mechatronics*

Dr. Dieter Klausgrete  
Leitung International Certification Management /  
*Head of International Certification Management*  
Mechatronik / *Mechatronics*



## Konformitätserklärung zur Richtlinie 2009/23/EG *Declaration of Type Conformity to Council Directive 2009/23/EC*

nichtselbsttätige elektromechanische Waagen  
*Non-automatic electromechanical weighing instruments*

(Alle Daten sind in den Prüfberichten, Bauartzulassungen oder den betroffenen Geräten selbst zu entnehmen)  
*(All data are given in the test certificates, type-approval certificates, or in the instruments in question.)*


Auswertegerät <i>Indicator</i>	Bauart Auswertegerät <i>Indicator type</i>	Bauart Waage Weighing <i>instrument type</i>	Genauigkeits- klasse <i>Accuracy class</i>	EG-Bauart- zulassung Nr. EC type approval no.	Prüfschein Nr. Auswertegerät <i>Indicator test certificate no.</i>
CAI...	TA	SARTOCOMB	III, IIII	T7884	D09-11.02

### Elektromechanische Waage

Die Konformitätserklärung gilt, wenn:

- das Auswertegerät als unverändertes Originalmodul verwendet wird. (Diese Erklärung gilt nur für die Waage ohne Zusatzeinrichtungen)
- die Kompatibilität der Module über das zur Verfügung gestellte Programm "KOMPMOD.xls" bestätigt und vom Waagenbauer unterschrieben wurde. Hiermit übernimmt der Waagenbauer die Verantwortung für die Richtigkeit und die Konstruktion.
- eine Benannte Stelle der EU geprüft und in einer Konformitätsbescheinigung bestätigt hat:
  - \* die Übereinstimmung der im Formular (Programm) gemachten Angaben mit Waage und EG-Bauartzulassung.
  - \* die Richtigkeit der Aufschriften auf dem Kennzeichnungsschild
  - \* die Einhaltung der gesetzlichen Vorschriften durch vorhandene Anwendungsprogramme
  - \* die Prüfung der Waage nach EN 45501 Punkt 8.2
- die Benannte Stelle das Kennzeichnungsschild mit der grünen Klebmarke mit dem Messtechnik-M und ihrer Nummer ausgerüstet und die in der EG-Bauartzulassung geforderten Stellen mit ihren Sicherungsmarken verschlossen hat.

Sartorius AG  
37070 Göttingen, Deutschland  
Göttingen, 01.03.2011


  
Dr. G. Krebs  
( Geschäftsbereichsleiter Operations )  
( Senior Vice President of Operations )

### Electromechanical weighing instrument

The Declaration of EC Type Conformity applies if:

- The indicator is used as an unchanged original module. (This Declaration applies only to the weighing instrument without peripheral devices.)
- The Compatibility of Modules is confirmed by the program "KOMPMOD.xls" provided and signed by the scale assembler. The scale assembler hereby assumes responsibility for the accuracy and construction.
- A Notified Body of the EU has tested and confirmed the following in its own Certificate of Conformity:
  - \* The information and specifications on the form (program) conform to those of the weighing instrument and on the EC type-approval certificate;
  - \* The marking on the descriptive plate is correct;
  - \* The application programs available meet the legal regulations;
  - \* The weighing instrument has been tested in conformance with EN 45501, section 8.2.
- The Notified Body has affixed the green sticker with the metrology mark "M" and its number to the descriptive plate, and sealed the positions in accordance with the EC type-approval certificate using the Notified Body's protective marks.

Sartorius AG  
37070 Göttingen, Deutschland / Germany  
Signed in Göttingen on 01 March 2011

  
i.v. J. Rehwald  
( Leitung Produktion Mechatronik / Wägetechnik )  
( Head of the Production Department  
Mechatronics / Weighing Technology Division )

# Declarations of Conformity



## EC type-approval certificate

Number **T7884** revision 0  
Project number 10200410  
Page 1 of 3

Issued by NMI Certin B.V.  
Hugo de Grootplein 1  
3314 EG Dordrecht  
The Netherlands

In accordance with The Council Directive 2009/23/EC on non-automatic weighing instruments.

Manufacturer Sartorius AG  
Weender Landstrasse 94 – 108  
37075 Goettingen  
Germany

In respect of A class **(III)** or **(IIII)**, electronic, **non-automatic weighing instrument**.  
Manufacturer mark/name: Sartorius  
Type : SARTOCOMB

Characteristics  $n \leq$  the number of verification scale intervals mentioned in the test certificates.  
In the description number T7884 revision 0 further characteristics are described.

Valid until 14 February 2021

Description and documentation The instrument is described in the description number T7884 revision 0 and documented in the test certificates involved.

The Notified Body no. 0122  
NMI Certin, 14 February 2011

  
C. Oosterlaan  
Head Certification Board

NMI Certin B.V.  
Hugo de Grootplein 1  
3314 EG Dordrecht  
The Netherlands  
T +31 78 6332332  
certin@nmi.nl  
www.nmi.nl

This document is issued under the provision that no liability is accepted and that the applicant shall indemnify third-party liability.

The designation of NMI Certin BV, as Notified Body can be verified at <http://ec.europa.eu/enterprise/newapproach/nando/>

Parties concerned can lodge objection against this decision, within six weeks after the date of submission, to the general manager of NMI (see "Regulation objection and appeal against decisions of NMI" [www.nmi.nl](http://www.nmi.nl))

Reproduction of the complete document only is permitted



**Physikalisch-Technische Bundesanstalt**

Braunschweig und Berlin



**Prüfschein**

Test Certificate

Ausgestellt für:  
*Issued to:*

Sartorius AG  
Weender Landstr. 94-108  
37075 Göttingen

Prüfgrundlage:  
*In accordance with:*

DIN EN 45501 (1992) Nr. 8.1, WELMEC-Leitfaden 2.1 (2001),  
Richtlinie 2009/23/EG, OIML R 76-1

Gegenstand:  
*Object:*

Auswertegerät *Indicator*  
oder Anzeige - und Bedienterminal  
*or indicating and operating terminal*

Typ:  
*Type:*

TA

Kennnummer:  
*Serial No.:*

Prüfscheinnummer:  
*Test Certificate No.:*

D09-11.02  
D09-11.02

Datum der Prüfung:  
*Date of test:*

Anzahl der Seiten:  
*Number of pages:*

17

Geschäftszeichen:  
*Reference No.:*

PTB-1.12-4050123

Benannte Stelle:  
*Notified Body:*

0102

Im Auftrag  
*On behalf of PTB*

Dr. Oliver Mack

Siegel  
*Seal*



Im Auftrag  
*On behalf of PTB*


Dipl.-Ing. M. Denzel

# Plates and Markings

## Plates and Markings

CAI... (Type TA)

- S** Protective mark (self-adhesive mark or seal)
- S\*** Protective mark (self-adhesive mark or seal) , only for transferable labels (detachable labels that remain intact after removal)
- S\*\*** Protective mark (self-adhesive mark or seal), only in case of existent ADC
- S\*\*\*** Protective mark (self-adhesive mark or seal), only in case of existent approved data storage device.
- K** Descriptive plate with CE konformity mark
- M** green metrology sticker
- MD** Metrological data Max, Min, e and if existent d
- T** Plate with model designation




PPTA160111e

Type of weighing instrument: SARTOCOMB + Type of indicator: TA  
 EC type-approval certificate T7884 + test certificate D09-11.02





# Plates and Markings



PPTA160111e

Type of weighing instrument: SARTOCOMB + Type of indicator: TA  
 EC type-approval certificate T7884 + test certificate D09-11.02

# Plates and Markings




PPTA160111e


Type of weighing instrument: SARTOCOMB + Type of indicator: TA  
 EC type-approval certificate T7884 + test certificate D09-11.02

# Plates and Markings


Alternative separable (disconnectable) plug connection between Indicator and load receptor.




If a junction box is in existence between load receptor with strain-gauge load cells and indicator it has to be secured against inadmissible manipulation.



Example of plate with model designation (indicator) T




Example of descriptive plate on a weighing instrument already verified K




Examples of labels with metrological data MD


One range instrument



Three ranges instrument




Two-intervals instrument



Labels for entering metrological data



Example:



PPTA160111e

Type of weighing instrument: SARTOCOMB + Type of indicator: TA  
EC type-approval certificate T7884 + test certificate D09-11.02

## Evidence of compatibility for modules used with non-automatic weighing instruments

The documents required to verify a weighing instrument for legal metrology can be created using the data, documents, and programs available from the Sartorius website.

The printout of the completed forms is valid as a model for verification of the weighing instrument produced by the scale manufacturer. Once this has been properly completed and signed by the weighing instrument manufacturer, it is submitted to the weights and measures officer together with the Declaration of Conformity (under "Documents").

Information important to the weights and measures officer may include the type approval certificate, test certificate or a test report. The test certificate and the manufacturer's information concerning the weigh cell will also be required.

### Filling in the evidence of compatibility

- ▶ The Guide to Verification of Weighing Instruments, complete with Excel file, documents and information, is available from Sartorius on the Internet at:  
[http://www.sartorius.com/leitfaden\\_eichen/](http://www.sartorius.com/leitfaden_eichen/)

### Creating the evidence of compatibility without internet access

- ▶ You can order the "Guide to Verification of Weighing Instruments" on CD-ROM directly from Sartorius. Order address:

Sartorius AG  
Hotline Dept.  
Weender Landstrasse 94-108  
Phone: +49.551.308.4440  
Fax: +49.551.308.4440  
[www.sartorius.com](http://www.sartorius.com)

- ▶ Select the required language version by clicking on the corresponding language.
- ▶ Select the required indicator at the top of the page.

### Using the program

ReadMe file:

Read this file before opening the Excel file. The ReadMe file contains important information about using the Excel file, and offers important information on filling out the documents.

Documents

All documents relevant to the compatibility declaration of the indicator are available (please click on the appropriate links).

Start:

- ▶ Click on "Start the Excel Program."
- ▷ The Excel file automatically opens with the Excel program. MS-Excel must already be installed on your computer. A dialog box for selecting macros opens.
- ▶ Click on the "Activate macros" button.
- ▷ Note: This window might not open, depending on the settings in your computer system.
- ▶ All fields on the "Data" page (highlighted in yellow) must be filled out by a qualified person.
- ▷ A filled out sample document is available in the "Documents" folder with explanations of the fields that are highlighted in yellow. Once the technical specifications provided by the manufacturer have been entered correctly, the program calculates all values automatically.

---

## Appendix: Guide to Verification of Weighing Instruments

On the second page, the green or red fields show whether the components (indicator and weigh cell/s) are compatible:

- Red = incompatible
- Green = compatible

Note: A manufacturer of weighing equipment who configures a weighing instrument from individual components (indicator and weigh cell/s) is responsible for the specifications in the documentation.

- ▶ Once all data has been entered correctly (all fields on page 2 are green), print out both pages.
- ▶ The file can then be archived (for example, saved on the PC) under a name of your choice.
- ▶ Double-check the information and sign the data sheet.

### Legal Information

Copyright:

This documentation may not be duplicated or transmitted for any purpose whatsoever, either in whole or in part, without the express written permission of Sartorius AG. All rights defined under copyright law are reserved by Sartorius AG.


The program is intended for use by the purchaser only. Transfer to third parties, whether free of charge or in return for payment, is not permitted.

The software may not be modified, reverse engineered or changed by assimilation.

The Excel program used here was developed by the German Association of Metrology and Calibration (Arbeitsgemeinschaft für Mess- und Eichwesen (AGME)). It is also available as freeware on the Internet. The program is copyrighted and may not be modified. Users shall be liable for the improper use of said software.




# Appendix: Passwords




## Service Password

- ▶ Press **[I/O]** to turn on the device.
- ▷ When turned on the scale is in an application program.
- ▶ Enter the service password and confirm with the **[SETUP]** key.
- ▷ The device in now is Service mode. An “S” appears in the top right-hand corner of the display.




## General Password


- ▶ Press **[SETUP]**.
- ▷ The menu appears on the display.
- ▶ Press the “v” soft key several times to select the “Device parameters” line (or “Application parameters”).



- ▶ Press the “>” soft key.
- ▷ The Access window appears on the display.
- ▶ Enter the general password (see below) via the keypad, see “Numeric Input via the Keypad.”
- ▶ Press the “J” soft key.



- ▷ The device selection appears on the display.
- ▶ Press the “v” several times to select the “Password” line.
- ▶ Press the “>” soft key.



- ▷ The input line appears on the display.
- ▶ Read the old password, or enter a new password (max. 8 characters).
- ▶ Press **[.]** or **[CF]** several times to delete the password.
- ▶ Press the “J” soft key to save the delete.  
If not yet saved, the process can be canceled using the “ESC” soft key.
- ▶ Press **[SETUP]** or “<<” to exit the Setup menu.
- ▶ Press **[I/O]** to turn off the device.
- ▶ Press **[I/O]** turn the device back on.

**General password:**  
**40414243**

**Service password:**  
**202122**







Sartorius AG  
Weender Landstrasse 94-108  
37075 Goettingen, Germany

Telephone +49.551.308.0  
Fax +49.551.308.3289  
[www.sartorius-mechatronics.com](http://www.sartorius-mechatronics.com)

Copyright by Sartorius AG,  
Goettingen, BR Germany.  
No part of this publication may be  
reprinted or translated in any form or  
by any means without the prior written  
permission of Sartorius AG.  
All rights reserved by Sartorius AG in  
accordance with copyright law.  
The information and figures contained  
in these instructions correspond to the  
version date specified below.  
Sartorius AG reserves the right to make  
changes to the technology, features,  
specifications and design of the  
equipment without notice.

Status:  
March 2011, Sartorius AG,  
Goettingen