


RS-232 Option Card

For PN 107238 Rice Lake TC-Series Balance

Installation Manual



RICE LAKE[®]
WEIGHING SYSTEMS
To be the best by every measure[®]

115148

1.0 Installation 1

- 1.1 Remove the Case 1
- 1.2 Install PC Board for Option 2
- 1.3 Parts List 3
- 1.4 Terminal Numbers and Functions 3
- 1.5 Connection between Balances and Personal Computers 4
- 1.6 Interface Specifications 5
- 1.7 Output Data 5
- 1.8 Data Format 5
- 1.9 Polarities (PI: one character) 6
- 1.10 Numeric Data 6
- 1.11 Units (U1, U2: two characters) 6
- 1.12 Result of judgment when operating balance with the limit function 7
- 1.13 Input Commands 7
- 1.14 Command Transmission Method 7
- 1.15 Command Format 7
- 1.16 Response Output 8
- 1.17 Description of Functions 9
- 1.18 Interface Section 10



Technical training seminars are available through Rice Lake Weighing Systems. Course descriptions and dates can be viewed at www.ricelake.com/training or obtained by calling 715-234-9171 and asking for the training department.

© Rice Lake Weighing Systems. All rights reserved. Printed in the United States of America.
Specifications subject to change without notice.
Rice Lake Weighing Systems is an ISO 9001 registered company.
November 21, 2014



Rice Lake continually offers web-based video training on a growing selection of product-related topics at no cost. Visit www.ricelake.com/webinars.

1.0 Installation

Use the following procedure to install the RS-232 option in the TC Series Balance.

1.1 Remove the Case

1. Pull out the AC adaptor from the scale
2. Remove the pan and pan base.
3. Remove the case-fixing screw.
4. Unfasten the hooks on the bottom front while pulling up the case.




Figure 1-1. Location of Parts

5. Unfasten the hooks on the back and remove the case.




Figure 1-2. Back Hooks Location

1.2 Install PC Board for Option

1. Install PC board to the chassis. See Figure 1-3 and Figure 1-4.




Figure 1-3. Insert PC Board




Figure 1-4. Installed Board

2. Insert connectors into SJD board.




Figure 1-5. Connector to Board Location

3. Cover the case and put RS-232C label on the output terminal.




Figure 1-6. Label Location

1.3 Parts List

Part Number	Name	Amount
21AE002	SJRS Board Assembly	1
3365P	Label for RS232C Output	1
FC 059	TCP0556-01-0201	1

Table 1-1. Parts List for RS232C Option


Part Number	Name	Amount
21AE003	SJLM Board Assembly	1
3339P	Label for Relay Contact	1
FC 062	TCP0568-01-0201	1

Table 1-2. Parts List for Relay Contact

1.4 Terminal Numbers and Functions

Terminal Number	Signal	Input/output	Function & remarks
1	EXT.TARE	Input	External tare subtraction [※]
2	DTR	Output	HIGH (when balance is powered-up)
3	RXD	Input	Receiving data
4	TXD	Output	Transmitting data
5	GND	—	Signal ground

Compatible plug: TCP 0556-01-0201 (Hoshiden - supplied with balance)



RS-232C connector (DIN 5-pin): Rear panel

Tare subtraction (zero adjustment) is possible by connecting an external tare subtraction input and a signal ground, through contacts or a transistor switch. When following this procedure, secure a connection time of at least 400 milliseconds. (When the switch is off, the voltage maximum is 15 V; when the switch is on, the sink current is 20 mA or less.)

NOTE: Before plugging in the connectors, unplug the AC adapter.

1.5 Connection between Balances and Personal Computers




Figure 1-7. Sample connection with an IBM-PC/AT Compatible Computer





Figure 1-8. Sample Connection with PC9801

1.6 Interface Specifications

(1) Transmission system	Serial transmission with start-stop synchronization
(2) Transmission rates	1200/2400/4800/9600 bps
(3) Transmission codes	ASCII codes (8-bit)
(4) Signal levels	Compliant with EIA RS-232C HIGH level (Data logic 0) +5 to +15 V LOW level (Data logic 1) -5 to -15 V
(5) One-character bit configuration	Start bit: 1 bit Data bit: 8 bits Parity bit: 0/1 bits Stop bit: 2 bits
(6) Parity bit	none/odd/even



1.7 Output Data

By changing the function settings on the main unit of the balance, users can select either of the following formats: (See Section “Description of Functions” on page 9)

1.8 Data Format

- Six-digit numeric format

Composed of 14 characters, including the terminators (CR = 0DH, LF = 0AH).

1	2	3	4	5	6	7	8	9	10	11	12	13	14
P1	D1	D2	D3	D4	D5	D6	D7	U1	U2	S1	S2	CR	LF

- Seven-digit numeric format

Composed of 15 characters, including the terminators (CR = 0DH, LF = 0AH). A parity bit can also be appended.

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
P1	D1	D2	D3	D4	D5	D6	D7	D8	U1	U2	S1	S2	CR	LF

1.9 Polarities (P1: one character)

P1	Code	Description
+	2BH	When data is zero or positive
-	2DH	When data is negative
(SP)	20H	When data is zero or positive

1.10 Numeric Data

Six-digit numeric format: (D1-D7: seven characters)

Seven-digit numeric format: (D1-D8: eight characters)

D1-D7 (D8)	Code	Description
0-9	30H-39H	Numerical value 0-9
.	2EH	Decimal point (floating position) ※When the data is an integer, it may be omitted and replaced with a blank space (SP) in the lowest-order place.
(SP)	20H	Space: zero of leading portion of value (leading zero suppress)

1.11 Units (U1, U2: two characters)

NOTE: All the codes are ASCII codes.

U1	U2	Code	Meaning	Balance indicators
(SP)	G	20H 47H	Gram	g
C	T	43H 54H	Carat	ct
O	Z	4FH 5AH	Ounce	oz
L	B	4CH 42H	Pound	lb
O	T	4FH 54H	troy ounce	oz t
D	W	44H 57H	Pennyweight	dwt
G	R	47H 52H	Grain	? (lower right)
T	L	54H 4CH	tael (Hong Kong)	tl
T	L	54H 4CH	tael (Singapore, Malaysia)	tl? (upper right)
T	L	54H 4CH	tael (Taiwan)	tl? (lower right)
M	O	4DH 4FH	Momme	Mom
t	o	74H 6FH	Tola	to
(SP)	%	20H 25H	Percentage	%
P	C	50H 43H	Pieces	Pcs

1.12 Result of judgment when operating balance with the limit function

(S1: one character)

S1	Code	Description
L	4CH	LO (LOW)
G	47H	OK (GOOD)
H	48H	HI (HIGH)
(SP)	20H	No limit value specified

Status (S2: one character)

S2	Code	Description
S	53H	Data stable
U	55H	Data unstable
E	45H	Data error (data other than S2 is invalid.) [$\sigma - Err$], [$\mu - Err$]
(SP)	20H	No status specified

1.13 Input Commands

Users can control the balance remotely by transmitting commands from an external device. Two types of control commands are available:

- Instruction for tare subtraction
- Setup of output control

1.14 Command Transmission Method

- A command is transmitted to the balance from an external device. Since the data flow (transmission and reception) is stored by a full-duplex system, commands can be transmitted regardless of their data-transmission timing.
- When the balance has executed the received command, it activates a normal end response or transmits the requested data, via the transmitting command. If the balance was unable to execute the command or received an erroneous command, it transmits an error end response. If the balance is working properly, it usually returns a response within a second after it receives the transmitted command. If the balance receives a transmission while it is conducting a procedure (such as the setup of a function or a span adjustment), it will transmit a response when the procedure finishes.
- When transmitting more than one command to the balance from a remote device, wait until you have received a confirmation on the first transmission before transmitting the next.

1.15 Command Format

- Command format

Composed of four characters (ASCII), including the terminators (CR=0DH, LF = 0AH)

1	2	3	4
C1	C2	CR	LF

- Instruction for tare subtraction (zero adjustment)

C1	C2	Code		Description	Value	Response
T	(SP)	54H	20H	Instruction for tare subtraction (zero adjustment)	None	A00: Normal end E01: Tare subtraction cannot be executed due to an error in the weight value.

- Setup of output control

C1	C2	Code		Description
0	0	4FH	30H	Stop output
0	1	4FH	31H	Output continuous at all times
0	2	4FH	32H	Output continuous if stable (stop output if unstable)
0	3	4FH	33H	Outputs once by pressing Memory key (irrespective of whether stable).
0	4	4FH	34H	Outputs once if stable. Outputs if the balance is stable when a sample is loaded after the preceding sample has been removed and the balance indicated zero, or less.
0	5	4FH	35H	Outputs once if stable, and stops output when unstable. Even if the sample is not replaced, the balance is output once when it stabilizes next time (including the zero indication).
0	6	4FH	36H	Outputs once if stable, and outputs continuously when unstable. Even if the sample is not replaced, output of the balance stops when it stabilizes after being output once.
0	7	4FH	37H	Pressing Memory key causes the balance to output once when stable.
0	8	4FH	38H	Output once immediately.
0	9	4FH	39H	Output once after stabilization.

The output controls executed with commands [O0] - [O7] work the same as the output controls executed through function setup on the main unit of the balance.

The commands [O8] and [O9] are data request commands issued to the balance.

Once any command from [O0] to [O9] is executed, the balance runs that function until another command is entered. However, if the balance is switched off and on again, the output control is reset to the initial function (function set value).

1.16 Response Output

- Response output format

Composed of five characters, including the terminators (CR = 0DH; LF = 0AH)

1	2	3	4	5
A1	A2	A3	CR	LF

- Types of response outputs

A1	A2	A3	Code		Description
A	0	0	41H	30H 30H	Normal end
E	0	1	45H	30H 31H	Command error (Abnormal command received; other errors)

1.17 Description of Functions

Item		Set Value	Description	
Bar graph display		1. b.G.	<input type="checkbox"/>	Disable
			☆1	Enable
Limit function		2. SEL	☆ <input type="checkbox"/>	Disable
			1	Enable
Displayed only when limit function is activated	Judgement condition	21. Co.	☆1	Always judge (judges even when the balance is unstable)
			2	Judge only when the balance is stable (does not judge if the balance is unstable)
	Judgement range	22.L	<input type="checkbox"/>	Ranges beyond +5 graduation is judged (ranges +5 graduation or below, including negative ranges, are not judged.)
	☆1		The entire range is judged (the entire range, including the negative, is judged).	
Number of points for judgement	23.P	1	One-point setup (judges between OK and LO)	
		☆2	Upper-limit and lower-limit values are set up (judges among HI, OK and LO).	
Auto-zero (zero-tracking)		3.R.0	<input type="checkbox"/>	Disable
			☆1	Enable
Auto power-off		4.R.P.	<input type="checkbox"/>	Disable (balance operates continuously)
			☆1	Enable (balance powers off in approximately three minutes)
Response speed		5.r.E.	<input type="checkbox"/>	Measurement by consecutive weighings.
			1	
			2	Fast
			☆3	↓
			4	Slow
Stability parameters		6.S.d.	1	
			☆2	Wide (mild)
			3	↓
			4	Narrow (strict)
Interface		7. 1.F.	<input type="checkbox"/>	Disable input/output
			☆1	Six-digit numeric format
			2	Seven-digit numeric format
Setup of units of measurement to be displayed		8. 15.u. 5	☆1 01	[g]
			☆2 14	[oz t] (ct)
			15	[lb] (oz)
			16	[01] (lb)
			17	[ct] (ozt)
			18	[dw] (dwt)
			*19	[? Lower right] (grain)
Register selected measuring units with Function key.				

Items marked ☆ are the default factory settings.

☆1~☆5: default settings [B1.5.u]~[B5.5.u.]

*Not available in TC-12K.

Description of Functions, continued

Setup of measurement units to be displayed ^{※1}	8 15.u	1A	[tl] (tl_Hong Kong)
		1b	[tl ►] Upper right] (tl_Singapore, Malaysia)
Register measurement units by selecting Function key	85.5.u	1C	[tl ►] Lower right] (tl_Taiwan)
		1d	[mom]
		1E	[to] (to)
		☆3 20	[Pcs]
		☆4 1F	[%]
		☆5 00	Unit not set

☆1~☆5: default factory settings [8 15.u]~[85.5.u]

※1 [00] cannot be set at [8 15.u].

1.18 Interface Section

Displayed when [7 1F □] is set to [1] or [2]

Item	Set Value	Description	
Output Control	7 1 o.c.	0	Stop output
		1	Output continuous at all times
		2	Output continuous if stable (stop output if unstable)
		3	Outputs once by pressing Memory key (irrespective of whether stable).
		4	Outputs once if stable. Outputs if the balance is stable when a sample is loaded after the preceding sample has been removed and the balance indicated zero, or less.
		5	Outputs once if stable, and stops output when unstable. Even if the sample is not replaced, the balance is output once when it stabilizes next time (including the zero indication).
		6	Outputs once if stable, and outputs continuously when unstable. Even if the sample is not replaced, output of the balance stops when it stabilizes after being output once.
		☆7	Pressing Memory key causes the balance to output once when stable.
Baud Rate	72 b.L.	☆1	1200 bps
		2	2400 bps
		3	4800 bps
		4	9600 bps
Parity	73 P.R.	☆0	None
		1	Odd
		2	Even
		Displayed only when [7 1F 2] (7-digit numeric format) is specified.	

☆ denotes a factory-setting

※ The data interval in continuous output mode is 0.1 to 1 second. (The interval varies depending on weighting conditions and other factors.)



230 W. Coleman St. • Rice Lake, WI 54868 • USA
U.S. 800-472-6703 • Canada/Mexico 800-321-6703 • International 715-234-9171 • Europe +31 (0)26 472 1319

www.ricelake.com www.ricelake.mx www.ricelake.eu www.ricelake.co.in m.ricelake.com