


# SCT-4XD

*Belt Scale Integrator*

## Technical Manual



© Rice Lake Weighing Systems. All rights reserved.

Rice Lake Weighing Systems® is a registered trademark of  
Rice Lake Weighing Systems.

All other brand or product names within this publication are trademarks or  
registered trademarks of their respective companies.

All information contained within this publication is, to the best of our knowledge, complete and  
accurate at the time of publication. Rice Lake Weighing Systems reserves the right to make  
changes to the technology, features, specifications and design of the equipment without notice.

The most current version of this publication, software, firmware and all other product  
updates can be found on our website:

[www.ricelake.com](http://www.ricelake.com)

# Revision History

---

This section tracks and describes manual revisions for awareness of major updates.

| Revision | Date           | Description                       |
|----------|----------------|-----------------------------------|
| A        | July 30, 2024  | Initial release; Firmware 1.24.00 |
| B        | March 10, 2025 | Established revision history      |
|          |                |                                   |
|          |                |                                   |

*Table i. Revision Letter History*



*Technical training seminars are available through Rice Lake Weighing Systems. Course descriptions and dates can be viewed at [www.ricelake.com/training](http://www.ricelake.com/training) or obtained by calling 715-234-9171 and asking for the training department.*

# Contents

|            |  |           |
|------------|--|-----------|
| <b>1.0</b> | <b>Introduction</b>                    | <b>7</b>  |
| 1.1        | Safety                                 | 7         |
| 1.2        | Disposal                               | 8         |
| 1.3        | FCC Compliance                         | 8         |
| 1.4        | Definitions                            | 8         |
| 1.4.1      | Idlers Distance (Weigh Length)         | 8         |
| 1.4.2      | Length per Encoder Pulse Belt          | 10        |
| 1.4.3      | Belt Ratio                             | 11        |
| 1.4.4      | Zero                                   | 11        |
| 1.4.5      | Equations                              | 11        |
| <b>2.0</b> | <b>Installation</b>                    | <b>12</b> |
| 2.1        | Electrical Schema                      | 13        |
| 2.2        | Key Functions                          | 14        |
| 2.3        | Indicator Light Descriptions           | 14        |
| <b>3.0</b> | <b>Setup</b>                           | <b>15</b> |
| 3.1        | Main Menu                              | 15        |
| 3.2        | Initial Settings                       | 15        |
| 3.3        | General Parameters                     | 17        |
| 3.3.1      | Analog Output Parameters               | 18        |
| 3.3.2      | Air Purge Parameters                   | 19        |
| 3.4        | Belt Parameters                        | 19        |
| 3.4.1      | Filter Parameters                      | 21        |
| 3.5        | Default                                | 21        |
| <b>4.0</b> | <b>Calibration</b>                     | <b>23</b> |
| 4.1        | Calibration Menu                       | 23        |
| 4.2        | Zero Scale                             | 24        |
| 4.3        | Load Cell Filter                       | 25        |
| 4.4        | Test Weight Calibration                | 26        |
| 4.4.1      | Bulkslide Calibration Procedure        | 26        |
| 4.4.2      | Belt Scale Calibration Procedure       | 27        |
| 4.4.3      | Test Weight Procedure by Digital Input | 28        |
| 4.4.4      | Calibration Equations                  | 28        |
| 4.4.5      | New Correction Factor Equation         | 28        |
| <b>5.0</b> | <b>Operation</b>                       | <b>29</b> |
| 5.1        | User Menu                              | 29        |
| 5.2        | Zero Belt Procedure                    | 29        |
| 5.3        | Run Input                              | 29        |
| 5.4        | Available LED Data                     | 30        |
| 5.5        | Alarm Settings                         | 30        |
| 5.6        | Diagnostics                            | 32        |
| <b>6.0</b> | <b>Communications</b>                  | <b>33</b> |
| 6.1        | Serial Settings for 1280 Connection    | 33        |
| 6.2        | Analog Outputs                         | 33        |
| 6.3        | PC Port Modes                          | 34        |



Rice Lake continually offers web-based video training on a growing selection of product-related topics at no cost. Visit [www.ricelake.com/webinars](http://www.ricelake.com/webinars)

|            |                                   |           |
|------------|-----------------------------------|-----------|
| 6.4        | PRN Port Modes .....              | 34        |
| 6.5        | USB Communication .....           | 35        |
| <b>7.0</b> | <b>Fieldbus .....</b>             | <b>36</b> |
| 7.1        | Enable Protocol .....             | 36        |
| 7.2        | Fieldbus Parameters .....         | 36        |
| 7.3        | Input Data .....                  | 37        |
| 7.4        | Output Data .....                 | 37        |
| 7.5        | Fieldbus Files .....              | 38        |
| 7.6        | Messages .....                    | 38        |
| 7.6.1      | Profibus .....                    | 38        |
| 7.6.2      | Other Fieldbus .....              | 39        |
| 7.6.3      | Error Codes .....                 | 39        |
| 7.7        | Ethernet Configuration .....      | 39        |
| 7.8        | Symbols .....                     | 39        |
| 7.9        | Input Registers .....             | 40        |
| 7.9.1      | Command Status Register .....     | 47        |
| 7.9.2      | Belt Status Register .....        | 47        |
| 7.9.3      | Flow-Rate .....                   | 48        |
| 7.9.4      | Analog Output Percentage .....    | 48        |
| 7.9.5      | Partial and general totals .....  | 48        |
| 7.9.6      | Input Status Register .....       | 49        |
| 7.9.7      | Output Status Register .....      | 50        |
| 7.9.8      | Other Data .....                  | 50        |
| 7.9.9      | Digital Output Function .....     | 50        |
| 7.9.10     | Digital Output ON/OFF Value ..... | 51        |
| 7.10       | Holding Registers .....           | 51        |
| 7.10.1     | Available Commands .....          | 52        |
| 7.10.2     | Commands Parameters .....         | 53        |
| 7.10.3     | Status Holding Registers .....    | 55        |
| 7.10.4     | Setting Registers .....           | 58        |
| <b>8.0</b> | <b>Specifications .....</b>       | <b>61</b> |



Technical training seminars are available through Rice Lake Weighing Systems.  
 Course descriptions and dates can be viewed at [www.ricelake.com/training](http://www.ricelake.com/training)  
 or obtained by calling 715-234-9171 and asking for the training department.



*Rice Lake continually offers web-based video training on a growing selection of product-related topics at no cost. Visit [www.ricelake.com/webinars](http://www.ricelake.com/webinars)*

# 1.0 Introduction



Manuals are available from Rice Lake Weighing Systems at [www.ricelake.com/manuals](http://www.ricelake.com/manuals)

Warranty information is available at [www.ricelake.com/warranties](http://www.ricelake.com/warranties)

## 1.1 Safety

### Safety Definitions:



**DANGER:** Indicates an imminently hazardous situation that, if not avoided, will result in death or serious injury. Includes hazards that are exposed when guards are removed.



**WARNING:** Indicates a potentially hazardous situation that, if not avoided, could result in serious injury or death. Includes hazards that are exposed when guards are removed.



**CAUTION:** Indicates a potentially hazardous situation that, if not avoided, could result in minor or moderate injury.



**IMPORTANT:** Indicates information about procedures that, if not observed, could result in damage to equipment or corruption to and loss of data.

### General Safety



**Do not operate or work on this equipment unless this manual has been read and all instructions are understood. Failure to follow the instructions or heed the warnings could result in injury or death. Contact any Rice Lake Weighing Systems dealer for replacement manuals.**



#### WARNING

**Failure to heed could result in serious injury or death.**

**Some procedures described in this manual require work inside the enclosure. These procedures are to be performed by qualified service personnel only.**

**Take all necessary safety precautions when installing the weigh frame, including wearing safety shoes, protective eye wear, and using the proper tools.**

**Keep hands, feet and loose clothing away from moving parts.**

**Do not approach a running conveyor from underneath.**

**Do not bend over a running conveyor.**

**Do not allow minors (children) or inexperienced persons to operate this unit.**

**Do not operate without all shields and guards in place.**

**Do not jump on the scale.**

**Do not use for purposes other than weight taking.**

**Do not place fingers into slots or possible pinch points.**

**Do not use any load bearing component that is worn beyond 5% of the original dimension.**

**Do not use this product if any of the components are cracked.**

**Do not exceed the rated load limit of the unit.**

**Do not make alterations or modifications to the unit.**

**Do not remove or obscure warning labels.**

**Do not use near water.**

## 1.2 Disposal



### Product Disposal

The product must be brought to appropriate separate waste collection centers at the end of its life cycle.

Proper separate collection to recycle the product helps prevent possible negative effects on the environment and to health, and promotes the recycling of the materials. Users who dispose of the product illegally shall face administrative sanctions as provided by law.

## 1.3 FCC Compliance

### United States

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

### Canada

This digital apparatus does not exceed the Class A limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of the Canadian Department of Communications.

Le présent appareil numérique n'émet pas de bruits radioélectriques dépassant les limites applicables aux appareils numériques de la Class A prescrites dans le Règlement sur le brouillage radioélectrique édicté par le ministère des Communications du Canada.

## 1.4 Definitions

### 1.4.1 Idlers Distance (Weigh Length)




Figure 1-1. Complete Conveyor on Load Receptor




Figure 1-2. Conveyor with One Roller on Load Receptor






Figure 1-3. Conveyor with Two Adjacent Rollers on Load Receptor




Figure 1-4. Conveyor with Many Adjacent Rollers on Load Receptor




Figure 1-5. Screw Feeder - Full Tube with Fulcrum and Load Cell at the Extreme Ends of the Tube




Figure 1-6. Screw Feeder - Full Tube with Fulcrum and Load Cell Midway on the Tube




Figure 1-7. Screw Feeder - Partially Full tube with Fulcrum and Load Cell Midway on the Tube




Figure 1-8. Weighed Partially Full Tube without Fulcrum

### 1.4.2 Length per Encoder Pulse Belt

With every encoder roller of D diameter turn, there are N pulses. The length per pulse is:

$$LPP = \pi D / N$$

### Screw Feeder

With every screw turn with  $P_t$  pitch, there are N pulses. The length per pulse is:

$$LPP = P_t / N$$

In calculation:

$$N = \text{Pulses/Turn}$$

$$P_t / \pi = \text{Diameter of Encoder Roller}$$

### 1.4.3 Belt Ratio

Belt ratio = (Pivot to LC distance) / (Pivot to idler distance) \* 1 / cos(Belt angle)




Figure 1-9. Belt Ratio

| No. | Belt Parts    |
|-----|---------------|
| 1   | Pivot         |
| 2   | Lever         |
| 3   | Load Cell     |
| 4   | Weighed Idler |

Table 1-1. Belt Parts

### 1.4.4 Zero

Load cell signal used as reference to calculate the weight on the cell. It is composed of:

zero = (static zero) + (zero belt) + (automatic zero belt)

- static zero: signal with belt structure on load cell and empty and stopped belt
- zero belt: average difference of load cell signal from static zero during the belt zero procedure After the zero belt procedure is executed the automatic zero belt is set equal to zero
- automatic zero belt: average difference of load cell signal from (static zero) + (zero belt) during the automatic zero belt procedure

### 1.4.5 Equations

Belt factor =  $1 / (\text{Idler distance}) * (\text{Belt ratio})$

Belt load =  $((\text{LC signal}) - \text{zero}) / (\text{Max LC signal}) * (\text{LC capacity}) * (\text{Belt factor}) * (\text{Correction factor})$

Belt speed =  $(\text{Encoder frequency}) * (\text{length per pulse})$

Add to total on every encoder pulse =  $(\text{Belt load}) * (\text{Length per pulse})$

Flow rate =  $(\text{Belt load}) * (\text{Belt speed}) * (\text{Flow correction})$

## 2.0 Installation

Figure 2-1 shows the wiring diagram for the SCT-4XD factory installed in an enclosure.





Figure 2-1. SCT-4XD Wiring Diagram

## 2.1 Electrical Schema



Optional 1280 Connection  
Serial Port 1  
See [Section 6.1 on page 33](#)

Figure 2-2. SCT-4XD Electrical Schema

## 2.2 Key Functions




Figure 2-3. SCT-4XD Display

| Configuration Menu |                                  | Weighing Mode |                                 |
|--------------------|----------------------------------|---------------|---------------------------------|
| ▼                  | Decreases digit<br>Scrolls down  | ▶             | Toggles between belt scale data |
| ▲                  | Increases digit<br>Scrolls up    | ◀             | Long Press: Accesses user menu  |
| ▶                  | Selects digit to modify          | ⏻             | ON<br>Standby                   |
| ⏻                  | Enters a step<br>Confirms        |               |                                 |
| ⏻                  | Clears<br>Exits a step (no save) |               |                                 |

Table 2-1. Key Functions

## 2.3 Indicator Light Descriptions

| Icon      | Description                         |
|-----------|-------------------------------------|
| ~         | Zero or span calibration in process |
| W1<br>SP1 | Digital output 1 is active          |
| W2<br>SP2 | Digital output 2 is active          |

Table 2-2. Indicator Light Descriptions

## 3.0 Setup

### 3.1 Main Menu

To enter the main menu, hold the **TARE** key on power up until `ini.SET` appears.



Figure 3-1. SCT-4XD Main Menu

| Parameter            | Description  |
|----------------------|--|
| <code>ini.SET</code> | Initial settings (see <a href="#">Section 3.2</a> )                  |
| <code>GEN.PAR</code> | General parameters (see <a href="#">Section 3.3 on page 17</a> )     |
| <code>bLT.PAR</code> | Belt parameters (see <a href="#">Section 3.4 on page 19</a> )        |
| <code>CALib</code>   | Calibration settings (see <a href="#">Section 4.0 on page 23</a> )   |
| <code>ALARMS</code>  | Alarm settings (see <a href="#">Section 5.1 on page 29</a> )         |
| <code>Commun</code>  | Communication settings (see <a href="#">Section 6.0 on page 33</a> ) |
| <code>dEFfAu</code>  | Default settings (see <a href="#">Section 3.5 on page 21</a> )       |
| <code>d iAG</code>   | Diagnostics (see <a href="#">Section 5.6 on page 32</a> )            |

Table 3-1. SCT-4XD Main Menu Parameters

### 3.2 Initial Settings




Figure 3-2. Initial Settings Menu

| Parameter            | Description   | Default                |
|----------------------|---|------------------------|
| <code>unit</code>    | Unit system: Selects the unit system for weight, flow-rate and length.<br>After selection, <code>dF.WALP</code> displays and prompts to set default values for select parameters.<br>If confirmed, the following values are set: <ul style="list-style-type: none"> <li>• Max belt speed - 200 ft/min (1 m/s)</li> <li>• Weigh length - 48 in (1000 mm)</li> <li>• Belt length - 500 ft (10 m)</li> </ul> | <b>Metric, US</b>      |
| <code>oP.NoDE</code> | Operating mode: Selects operating mode.   | <b>Belt, Bulkslide</b> |

Table 3-2. Initial Settings Parameters

If operating mode is changed, the following parameters are reset:

| Belt to Bulkslide           |                                      | Bulkslide to Belt |            |
|-----------------------------|--------------------------------------|-------------------|------------|
| Cell capacity               | 20 kg                                | Cell capacity     | 200 kg     |
| Encoder                     | Disabled                             | Encoder           | Enabled    |
| Input 1                     | If equal to Encoder, changed to None | Input 1           | Encoder    |
| Input 2                     | If equal to Encoder, changed to None |                   |            |
| Fixed speed                 | 3 m/s                                |                   |            |
| Belt zero time              | 5 seconds                            | Belt zero time    | 60 seconds |
| Idlers distance             | 1000 mm                              |                   |            |
| Pivot to load cell distance | 0 mm                                 |                   |            |
| Pivot to idler distance     | 0 mm                                 |                   |            |
| Serial                      |                                      |                   |            |
| Inclinometer                | Disabled                             |                   |            |
| Belt angle                  | 0 degrees                            |                   |            |
| Test weight                 | 0                                    |                   |            |
| Test weight delay           | 0                                    |                   |            |

Table 3-3. Operating Mode Parameter Changes

### 3.3 General Parameters




Figure 3-3. General Parameters Menu

| Parameter | Description   | Default                     |
|-----------|---|-----------------------------|
| PULSE.W   | Pulse weight: Defines how much totalized weight each pulse output represents. Value is under configured decimals and units of <i>LOAD RES</i> (see <a href="#">Table 3-9 on page 19</a> )   | <b>0</b><br>0-999999        |
| PULSE.W   | Pulse time width: Defines the length of time the digitizer pulse output is activated.<br>If value is equal to 0.0s, the following occurs: <ul style="list-style-type: none"> <li>The output is switched on when pulse weight is added to the totals</li> <li>The output is switched off after half of pulse weight is added to the totals.</li> </ul> | <b>0.0s</b><br>0.0s - 25.5s |
| INPUTS    | Inputs configuration: Functions to link to the digital 2 inputs.<br>Values: None, Zero key, Tare key, Mode key, Print key, C key, Off instrument, Keyboard lock, Run, Off track, Clear P.T., Zero belt, Extern alarm, Test weight, Encoder  | <b>Encoder</b>              |
| OUTPUT    | Outputs configuration: Selects the NO/NC configuration and functions to link to digital outputs.<br>Values: None, Run, Off track, Alarm, Lock, PULSE, Belt speed > 0, Zero belt active, Flow in dead band, Test weight, Air purge   |                             |
| GEN.PAR   | See <a href="#">Section 3.4 on page 19</a>  |                             |

Table 3-4. General Parameters



### 3.3.1 Analog Output Parameters




Figure 3-4. Analog Output Menu

| Parameter      | Description  | Default                                       |
|----------------|--|---|
| <i>Ao.Func</i> | Analog output function: Displays analog output operative mode. Proportional to flow-rate, load or speed. | <b>FLOW-RATE</b><br>LOAD<br>SPEED             |
| <i>Ao.Mode</i> | Analog output mode: Automatically sets mode for minimum and maximum value.                               | <b>4 20 mA</b><br>0 20 mA<br>2 10 V<br>0 10 V |
| <i>CALib</i>   | Analog output calibration (see <a href="#">Section 3.3.1.1</a> )   |   |
| <i>NAn.SPd</i> | Not used.  |   |

Table 3-5. Analog Output Parameters

#### 3.3.1.1 Analog Output Calibration Parameters




Figure 3-5. Analog Output Calibration Menu

| Parameter    | Description   | Default                 |
|--------------|---|-------------------------|
| <i>AoMin</i> | Minimum analog output signal: Signal level transmitted when Flow-Rate, Load or Speed is set to zero.                      | <b>12506</b><br>0-65535 |
| <i>AoMax</i> | Maximum analog output signal: Signal level transmitted when Flow-Rate, Load or Speed meet their configured maximum value. | <b>57970</b><br>0-65535 |

Table 3-6. Analog Output Calibration Parameters

### 3.3.2 Air Purge Parameters

Not visible in belt operating mode.




Figure 3-6. Air Purge Menu

| Parameter | Description  | Default              |
|-----------|--|----------------------|
| Air.int   | Air purge interval: Air is managed every set number of minutes.  | 20<br>0-255          |
| Air.tn    | Air purge time: Air purge enabled for set number of seconds.   | 5<br>0-255           |
| Air.thr   | Air purge max flow threshold: Air purge is enabled only if the flow-rate remains below set threshold for the set delay time. | 4<br>0-max flow-rate |
| Air.dly   | Air purge delay: Air purge is enabled only if the flow-rate remains below set max flow threshold for the time.               | 2<br>0-255           |

Table 3-7. Air Purge Parameters

### 3.4 Belt Parameters




Table 3-8. Belt Parameters Menu

| Parameter       | Description   | Default  |
|-----------------|---|--|
| <i>tot.rES</i>  | Total resolution<br>Values: 0.1 kg (lb), 0.2 kg (lb), 0.5 kg (lb), 1 kg (lb), 2 kg (lb), 5 kg (lb), 0.01 t (tn), 0.02 t (tn), 0.05 t (tn), 0.1 t (tn), 0.2 t (tn), 0.5 t (tn), 1 t (tn), 2 t (tn), 5 t (tn)   | <b>0.01 t</b>                                  |
| <i>Fr.rES</i>   | Flow-rate resolution: Displayed in kg/lb.   | <b>0.1 kg/lb</b><br>1, 0.01, 0.1, 1            |
| <i>MAX.Fr</i>   | Maximum flow-rate: Used by the Analog Output as the reference max value for Flow Rate. Displayed in tons.   | <b>200 t</b><br>0-65535                        |
| <i>ld.rES</i>   | Load resolution   | <b>1.000</b><br>100000<br>1.0<br>1.00<br>1.000 |
| <i>MAX.Ld</i>   | Maximum load: Used by the Analog Output as reference value for Maximum Load. Displayed in kg/m and lb/ft.   | <b>10 kg/m</b><br>0-60000                      |
| <i>EnCodr</i>   | Encoder enable: Measures belt speed<br>Not visible if operating mode is set to Bulkslide. When enabled, ensure Input 1 function is set to Encoder.  | <b>NO (Bulkslide)</b><br><b>YES (Belt)</b>     |
| <i>LEn.P.P</i>  | Length per pulse: Defines the distance between each encoder pulse (see <a href="#">Section 1.4.2 on page 10</a> )<br>Not visible if Encoder is not enabled.<br>Metric - 0.01 mm<br>US - 0.0001 in   | <b>3.14 mm</b><br>0-999999                     |
| <i>EnCod2</i>   | Encoder 2 enable: Measures belt speed<br>Not visible if operating mode is set to Bulkslide. When enabled, ensure Input 2 function is set to Encoder.  | <b>NO</b><br>YES                               |
| <i>MAX.SPd</i>  | Max belt speed: Used by the Analog Output as reference value for Maximum Belt Speed.  | <b>1 m/s / 200 ft/min</b><br>0-655.35          |
| <i>dERd.bd</i>  | Dead band: Flow-rate band in which the totals are not increased. The value is in percentage of the maximum flow-rate. When the flow-rate is lower than this step value percentage of the maximum flow-rate, the totals are not increased.   | <b>2.0%</b><br>0-99.9%                         |
| <i>Fr.d.b.</i>  | Show flow-rate in dead band: Option to see what the current flow rate is when in dead band state. If set to NO, the current flow rate inside the dead band is shown as 0.   | <b>NO</b><br>YES                               |
| <i>tot.nEG</i>  | Totalize in negative: Enables the totals decrement when the flow-rate is negative and the value is greater than the dead band percentage of the maximum flow-rate.  | <b>NO</b><br>YES                               |
| <i>FLT.PAr</i>  | Filter parameters (see <a href="#">Section 3.4.1</a> )  |  |
| <i>St.tot5</i>  | Store totals in non volatile memory: Total values are stored every 5 seconds to avoid to performance degradation. Storing values in permanent memory takes a few decimals of second. When storing is enabled, the amount of time for the indicator to answer to Modbus/ASCII requests is longer when total values are stored in permanent memory.<br>If set to NO, total values are lost when the indicator is powered off.<br>If set to YES, total values are stored in permanent memory and restored when indicator cycles power. | <b>YES</b><br>NO                               |
| <i>MAX.Fr.S</i> | Max flow-rate to store totals: Totals are stored if value is zero or if current flow-rate is less or equal to set percentage of max flow-rate. Not visible if <i>St.tot5</i> is set to NO.  | <b>0.0%</b><br>0-100.0%                        |

Table 3-9. Belt Parameters

### 3.4.1 Filter Parameters

Sets the flow-rate and load filter parameters.




Table 3-10. Filter Parameters Menu

| Parameter | Description                                    | Default                   |
|-----------|--|---------------------------|
| F.F.TIME  | Flow filtering time: Interval time in seconds. | <b>5</b><br>1-50          |
| F.F.FILT  | Hourly flow filter                             |                           |
|           | N.WIN  | <b>20</b><br>1-32         |
|           | N.MED  | <b>20</b><br>1-N.WIN      |
|           | N.PIT  | <b>0</b><br>0-(N.WIN - 2) |

Table 3-11. Filter Parameters

## 3.5 Default

Confirmation prompt displays (DEFALP) before returning device to factory settings.

# 4.0 Calibration

## 4.1 Calibration Menu




Figure 4-1. Calibration Menu

| Parameter | Description  | Default  |
|-----------|--|--|
| nChAn     | Number of load cells: Number of connected load cells   | <b>1</b><br>1-4  |
| CEL.CAP   | Load cell capacity: The total sum of the load cells capacities (in metric or US)   | <b>Belt: 200</b><br><b>Bulk: 20</b><br>0-999999                |
| CEL.SEN   | Load cell sensitivity: The total sum of the load cells sensitivities in mV/V   | <b>2 mV/V</b><br>0.1-9.99999                                   |
| ZERo      | Zero scale (see <a href="#">Section 4.2 on page 24</a> )   |  |
| LC.FILT   | Load cell filter (see <a href="#">Section 4.3 on page 25</a> )   |  |
| BE.i.LEN  | Weigh length: Length of weighing section. Not visible in bulkslide mode. When value is changed, the belt factor is re-calculated. <ul style="list-style-type: none"> <li>Metric: 1 mm resolution</li> <li>US: 0.01 in resolution</li> </ul>  | <b>Metric: 1000</b><br>0-65535<br><b>US: 48.00</b><br>0-655.35 |
| P.iUt.Lc  | Pivot to load cell distance: Not visible in bulkslide mode. When value is changed, the belt factor is re-calculated. <ul style="list-style-type: none"> <li>Metric: 1 mm resolution</li> <li>US: 0.01 in resolution</li> </ul>   | <b>0</b><br>Metric: 0-65535<br>US: 0-655.35                    |
| P.iUt.id  | Pivot to idler distance: Not visible in bulkslide mode. When value is changed, the belt factor is re-calculated. <ul style="list-style-type: none"> <li>Metric: 1 mm resolution</li> <li>US: 0.01 in resolution</li> </ul>   | <b>0</b><br>Metric: 0-65535<br>US: 0-655.35                    |
| inCL.in   | Serial inclinometer: Not visible in bulkslide mode.<br>Belt angle can be sent by a serial inclinometer connected to 232 or 485 port. The current supported inclinometer is the HPS-30-2-232 model by Level Developments. It has to send continuously a string of the form: +025.430<CR><br><br>Even dual axis inclinometer SOLAR-2, by Level Developments, is managed.<br>Example string: +025.430,-012.220<CR><br>Only first part (x axle) is considered. | <b>NO</b> , 485, 232   |
| AngLE     | Belt angle: Not visible in bulkslide mode. When value is changed, the belt factor is re-calculated.  | <b>0</b><br>0-60.0   |

Table 4-1. Calibration Parameters

| Parameter | Description   | Default  |
|-----------|---|--|
| Cor.FAC   | Correction factor: Displays current correction factor. Allows manual input of correction factor.<br><b>NOTE: 0 value is equal to 1.000000.</b><br><b>NOTE: For further instructions on manually calculating the Correction Factor, see Section 4.4.5 on page 28.</b>  | 1<br>0-9.999999  |
| ZErO.tE1  | Belt zero time: Time duration of the zero belt procedure with fixed speed and without encoder measurement sensor. Not visible if Encoder is enabled.  | <b>Belt: 60 sec</b><br><b>Bulk: 5 sec</b><br>0-600.00    |
| bELt.Ln   | Belt length: Total belt length used to calculate the number of pulses to read by the encoder during the zero belt procedure. Not visible if Encoder is disabled or in bulkslide mode.   | <b>Metric: 10.0 m</b><br><b>US: 500.0 ft</b><br>0-6553.5 |
| ZEr.rEU   | Belt revolutions: Number of belt revolutions completed during the zero belt procedure. Not visible if Encoder is disabled or in bulkslide mode.   | 1<br>1-9   |
| ZEr.rAn   | Zero range: Percent range of maximum flow-rate the zero procedure will start. If the absolute value of the flow rate related to static zero is out of the set range, the zero procedure will not start.   | 10%<br>0-99.9%   |
| Auto.zr   | Auto zero range: Percentage range of the maximum flow-rate the zero procedure will start. If the value is outside of the set range, the auto zero belt procedure stops. If the value exceeds the set range, the procedure is aborted.<br><b>NOTE: 0% means auto zero procedure disabled.</b>  | 10%<br>0-99.9%   |
| Auto.zL   | Auto zero limit: Percentage range of the maximum flow-rate the auto zero procedure will start. If the value, calculated (static zero) + (zero belt), is outside of the set range, the auto zero belt procedure stops. If the average flow-rate, calculated (static zero) + (zero belt), is outside the set range at the end of an auto zero procedure, the auto zero component value is discarded.<br><b>NOTE: 0% means no limit.</b> | 10%<br>0-99.9%   |
| tSt.Ht.C  | Test weight calibration (see Section 4.4 on page 26)  |  |

Table 4-1. Calibration Parameters (Continued)

## 4.2 Zero Scale

Load cell signal with the belt structure without material.




Figure 4-2. Zero Scale Menu

| Parameter | Description   | Default   |
|-----------|---|---|
| ZEr.inS   | Zero scale insertion: Direct insertion of dead load in mV/V.  | 0<br>0.1-9.99999                                      |
| ZEr.CAP   | Zero scale capture: Acquisition of dead load value. Belt must be empty and stationary. The stored value is the average value of 2 sec load cell signal sampling time.<br><b>NOTE: Dynamic Zero is still needed to perform a calibration procedure (see Section 4.4.1 on page 26).</b> | <b>Belt: 200 kg</b><br><b>Bulk: 20 kg</b><br>0-999999 |

Table 4-2. Zero Scale Parameters

### 4.3 Load Cell Filter

| Available Values | ADC Rate [Hz] |            |            |            | Win | Avg | Pit |
|------------------|---------------|------------|------------|------------|-----|-----|-----|
|                  | 1 Channel     | 2 Channels | 3 Channels | 4 Channels |     |     |     |
| F 1              | 5             | 3          | 3          | 3          | 32  | 16  | 0   |
| F 2              | 10            | 5          | 5          | 5          | 32  | 16  | 0   |
| F 3 (default)    | 20            | 10         | 10         | 10         | 12  | 4   | 0   |
| F 4              | 40            | 19         | 17         | 17         | 10  | 8   | 0   |
| F 5              | 80            | 34         | 30         | 30         | 16  | 8   | 0   |
| F 6              | 160           | 59         | 46         | 46         | 24  | 16  | 2   |
| F 7              | 325           | 91         | 103        | 103        | 24  | 8   | 0   |
| F 8              | 650           | 205        | 0          | 0          | 32  | 16  | 0   |
| F 9              | 1300          | 0          | 0          | 0          | 32  | 16  | 0   |
| F 10             | 2600          | 0          | 0          | 0          | 32  | 16  | 0   |
| Custom           |               |            |            |            |     |     |     |

Table 4-3. Load Cell Filter Channel Values

| Available Values | ADC Rate [Hz] | Win | Avg | Pit |
|------------------|---------------|-----|-----|-----|
| F 1              | 6.5           | 32  | 16  | 0   |
| F 2              | 12            | 32  | 16  | 0   |
| F 3 (default)    | 25            | 12  | 4   | 0   |
| F 4              | 50            | 10  | 8   | 0   |
| F 5              | 100           | 16  | 8   | 0   |
| F 6              | 200           | 24  | 16  | 2   |
| F 7              | 400           | 24  | 8   | 0   |
| F 8              | 800           | 32  | 16  | 0   |
| F 9              | 1600          | 32  | 16  | 0   |
| F 10             | 2400          | 32  | 16  | 0   |
| F 11             | 4800          | 32  | 16  | 0   |
| Custom           |               |     |     |     |

Table 4-4. Load Cell Filter Values

## 4.4 Test Weight Calibration

Not visible in bulkslide mode.




Figure 4-3. Test Weight Calibration Menu

| Parameter | Description  | Default                |
|-----------|--|------------------------|
| tEst.Wt   | Test weight: Test weight used to calculate correction factor.<br><ul style="list-style-type: none"> <li>Metric: 0.01 kg resolution</li> <li>US: 0.01 lb resolution</li> </ul>  | <b>0</b><br>0-9999.99  |
| tEst.Wt.d | Test weight delay: Interval time delay to allow the test mass to be positioned before the test weight procedure begins. If the value is 0 or no test weight output is configured, press any key to initiate a test weight procedure. | <b>0</b><br>0-6553.5   |
| t.W.d.St  | Test weight distance: Not visible if the encoder is disabled.<br><ul style="list-style-type: none"> <li>Metric: 0.01 m resolution</li> <li>US: 0.01 ft resolution</li> </ul>   | <b>0</b><br>0-655.35   |
| t.W.t.NE  | Test weight time (in seconds): Not visible if the encoder is enabled.  | <b>0</b><br>0-6553.5   |
| t.W.Mat.F | Test weight material factor:   | <b>1</b><br>0-9.999999 |

Table 4-5. Test Weight Calibration Parameters

### 4.4.1 Bulkslide Calibration Procedure

At a minimum, the following settings must be configured to the Bulkslide specifications before performing a calibration.

#### Initial Settings

- Select Metric or US
- Select Bulkslide

#### Calibration Parameters

- Capture Static Zero by entering or capturing Zero mV value (see [Section 4.2 on page 24](#)).
- Configure Loadcell Capacity
- Configure Loadcell Sensitivity

#### Save and Exit

- Press the **POWER** key to exit top level menu. Indicator prompts *SAVE?*
- Press the **PRINT** key to save changes.



Follow the instructions below to perform a Bulkslide calibration procedure:

1. Press and hold the **PRINT** key to access the User menu. *ZER CAL* displays.
2. Press the **PRINT** key to begin Dynamic Zero Capture with zero load. *HALE* displays. When complete, the indicator automatically switches to normal operating mode and adjusts any displayed load to zero.
3. Press and hold the **PRINT** key to re-access the User menu.
4. Press the **TARE** key to scroll up to Clear Partial Total.
5. Press the **PRINT** key to enter Clear Partial Total.
6. Confirm with the **PRINT** key.
7. Perform at least three runs of the same amount of material through the Bulkslide (using the Partial Total to ensure repeatability).
8. Clear the Partial Total after each run using [Step 3](#) through [Step 6](#).
9. Record the weight of the material used in [Step 7](#) by either pre-weighing or post-weighing it on a static scale.
10. Record the Partial Total Value from the SCT-4XD Partial Total.
11. Press and hold the **PRINT** key from normal operating mode to access the User menu.
12. Press the **TARE** key to scroll up to Correction Factor.
13. Press the **PRINT** key to enter Correction Factor.
14. Use one of the methods below to calculate the New Correction Factor:
  - Automatic Method: Use the *dOS CAL* feature to enter the Partial Total and the Real Weight value. *dOS CAL* will calculate and update the New Correction Factor automatically.
  - Manual Method: Calculate the New Correction Factor using the following equation.  

$$\text{New Correction Factor} = (\text{Actual Weight of Material} / \text{Displayed Weight of Material}) \times \text{previous Correction Factor}$$
15. Use the **MODE** key to select the digit to change.
16. Use the **ZERO** and **TARE** keys to modify the selected digit.
17. Press the **PRINT** key to save the New Correction Factor.

#### 4.4.2 Belt Scale Calibration Procedure

At a minimum, the following settings must be configured to the weigh frame and conveyor specifications before performing a calibration:

##### Initial Settings

- Select Metric or US

##### General Parameters

- Configure Encoder if present

##### Belt Parameters

- Enable Encoder if present
- Configure Encoder pulse length if encoder is used (see [Section 1.4.2 on page 10](#))
- Configure Fixed Belt Speed if no encoder is used

##### Calibration Parameters

- Configure the number of loadcell channels
- Capture Static Zero by entering or capturing Zero mV value (see [Section 4.2 on page 24](#))
- Configure Weigh Length (see [Section 1.4.1 on page 8](#))
- Configure Loadcell Capacity
- Configure Loadcell sensitivity
- Configure Belt Length if encoder is used
- Configure Belt Zero Time if encoder is not used

- Under Test Weight Calibration:
  - Configure Test Weight Value
  - Configure Test Distance if encoder is used
  - Configure Test time if encoder is not used

### Save and Exit

- Press the **POWER** key to exit top level menu. Indicator prompts *SAVEP*
- Press the **PRINT** key to save changes.

Follow the instructions below to perform a belt scale calibration procedure:

1. Press and hold the **PRINT** key to access the User menu. *ZEr.CAP* displays.
2. Press **PRINT** key to begin Dynamic Zero Capture with zero load. *WAIT* displays. When completed, the indicator automatically switches to normal operating mode and adjusts any displayed belt load to zero.
3. Press and hold the **PRINT** key to re-access the User menu.
4. Press the **TARE** key to scroll up to Test Weight Procedure.
5. Apply test weights to the scale.
6. With the belt running, press the **PRINT** key to begin the Test Weight Procedure. Configured test weight value displays.
7. If a temporary test weight change is required, use the **MODE** key to select the digit to change.
8. Use the **ZERO** and **TARE** keys to modify the selected digit.
9. Press the **PRINT** key to save the test weight value. Test Weight Capture initiates.
10. Indicator flashes the stability LED to indicate calibration process is running.
11. Indicator completes the Test Weight Capture, displays *Factor* briefly, and then displays the new calibrated correction factor.
12. Press the **PRINT** key. Indicator prompts *NOd.FYP*
13. Press the **PRINT** key to accept the new correction factor or the **POWER** key to discard the new correction factor.

#### 4.4.3 Test Weight Procedure by Digital Input

Since there is no interaction with the user, a configured test weight is used to save a new correction factor. With encoder, the procedure lasts the amount of time required to run the belt for the inserted test distance. Without encoder, the procedure lasts for the inserted test time.

#### 4.4.4 Calibration Equations



**NOTE: Calibration is based on the Totalizer value, not on moment belt load.**

- With encoder:  $\text{calcon} = \text{Test weight} / \text{Weigh length} * \text{Test distance} * \text{Material factor}$
- Without encoder:  $\text{calcon} = \text{Test weight} / \text{Weigh length} * (\text{TestTime} * \text{speed}) * \text{Material factor}$   
New correction factor =  $\text{calcon} / (\text{Totalized quantity}) * (\text{old correction factor})$
- Displayed error (procedure by function code) is in percentage:  $\text{error} = ((\text{Totalized quantity}) - \text{calcon}) / \text{calcon} * 100$

#### 4.4.5 New Correction Factor Equation

New Correction Factor = (Actual Weight of Material/Displayed Weight of Material) x previous Correction Factor

## 5.0 Operation

### 5.1 User Menu

Hold the **PRINT** key to access the user menu functions.

| Item   | Function   |
|--|--|
| ZEr .CAP   | Zero cell acquisition  |
| F.r.d.b.   | Show flow-rate in dead band  |
| PuLSE.W  | Pulse weight   |
| dos.CAL  | Correction factor computation confirming/inserting partial total and real total                                      |
| Cor.FAC  | Modify correction factor   |
| F.r.Corr   | (Not Used)   |
| FACtor   | Modify belt factor (on ModIF? message press ZERO key to calculate belt factor, press ENTER key to change the factor) |
| CLr.P.t.   | Clear partial total. Ask confirm with message O.P.t.?<br>Num dosages in increased.                                   |
| CLr.G.t.   | Clear general total. Ask confirm with message O.G.t.?<br>Num dosages is cleared.                                     |
| Est.W.Pr   | Test weight procedure (*)  |
| CLoCh  | Set date/time. Visible if clock board is recognized.   |
| (*) Asks for test weight then procedure starts. While test is running, the motion LED flashes. |  |

Table 5-1. User Menu Functions

### 5.2 Zero Belt Procedure

1. Press and hold the **ZERO** key to zero the belt from Normal Operation mode. Confirmation prompt displays (ZErO.b?).
2. Press the **PRINT** key to begin Zero Belt Procedure or the **POWER** key to cancel. The Zero LED will flash when performing the Zero Belt Procedure.

### 5.3 Run Input

Use Run Input for operations that should avoid totalizing unless the belt or conveyance equipment is running. To use this feature, the belt or conveyance controller needs to close a relay when running. If either input is configured to Run, the Operating logic is:

- Input Off - Flow Rate reads as Zero and Totalizing does not occur.
- Input On - Flow Rate reads according to the live Load and Totalizing occurs.

## 5.4 Available LED Data

On start-up, flow-rate data is displayed. Press the **MODE** key to display the following data:

| Item    | Description                                   |
|---------|---|
| FLoD.r  | Flow-rate                                     |
| LoAd    | Load  |
| SPEEd   | Active encoder speed in 0.01 m/s (0.1 ft/min) |
| P.totAL | Partial total                                 |
| G.totAL | General total                                 |

Table 5-2. Available LED Data

## 5.5 Alarm Settings



Figure 5-1. Alarm Settings Menu

| Parameter | Description   | Default        |
|-----------|---|----------------|
| oFF.trk   | Belt off track: A digital input must be configured with the off track function to use this alarm.   |                |
|           | • Error enabled   | NO, YES        |
|           | • Alarm delay: Alarm starts after set time beginning when the alarm condition started.  | 0<br>6553.5    |
|           | • Lock delay: Instrument enters locked state after set time since the alarm condition started. If value is set to zero, unit will never enter locked state. | 0<br>65535.5   |
| oUeR.Ld   | Flow overload error   |                |
|           | • Error enabled   | NO, YES        |
|           | • Alarm delay   | 0<br>0-6553.5  |
|           | • Lock delay: Instrument enters locked state after set time since the alarm condition started. If value is set to zero, unit will never enter locked state. | 0<br>0-65535.5 |
|           | • Flow overload % (r.F.o.L)   | 0<br>0-99.9    |

Table 5-3. Alarm Setting Parameter

| Parameter  | Description   | Default        |
|--|---|----------------|
| FlowRate   | Flow rate error   |                |
|  | • Error enabled   | NO, YES        |
|  | • Alarm delay: Alarm starts after set time beginning when the alarm condition started.  | 0<br>0-6553.5  |
|  | • Lock delay: Instrument enters locked state after set time since the alarm condition started. If value is set to zero, unit will never enter locked state. | 0<br>0-65535.5 |
|  | • Minimum flow-rate (Min.F.R.): The unit and decimals depend on the selected unit system and flow-rate resolution.  | 0<br>0-65535   |
| • Maximum flow-rate (Max.F.R.): The unit and decimals depend on the selected unit system and flow-rate resolution. | 0<br>0-65535  |                |
| UnderOverWeight  | Under/over-weight error   |                |
|  | • Error enabled   | NO, YES        |
|  | • Alarm delay: Alarm starts after set time beginning when the alarm condition started.  | 0<br>0-6553.5  |
|  | • Lock delay: Instrument enters locked state after set time since the alarm condition started. If value is set to zero, unit will never enter locked state. | 0<br>0-65535.5 |
|  | • Minimum weight on load receiver (Min.WE): Unit depends on the selected unit system (metric kg or US lb)   | 0<br>0-999999  |
| • Maximum weight on load receiver (Max.WE): Unit depends on the selected unit system (metric kg or US lb)          | 0<br>0-999999   |                |
| ExternalAlarm  | External alarm error: A digital input must be configured with the extern alarm function to use this alarm.  |                |
|  | • Error enabled   | NO, YES        |
|  | • Alarm delay: Alarm starts after set time beginning when the alarm condition started.  | 0<br>0-6553.5  |
|  | • Lock delay: Instrument enters locked state after set time since the alarm condition started. If value is set to zero, unit will never enter locked state. | 0<br>0-65535.5 |
| LCOver   | Load cell overload: Alarms when the weight on the load cell exceeds load cell capacity by 9 divisions.  |                |

Table 5-3. Alarm Setting Parameter (Continued)

## 5.6 Diagnostics




Figure 5-2. Diagnostics Menu

| Parameter | Description  |
|-----------|--|
| PrG.VER   | Program version: Displays application software release   |
| MANUF.d   | Manufacture data: Displays internal library  |
| d.W.int   | Division interval: The number of ADC counts per scale division. This determines the quality of the signal. The higher the value, the higher the signal interval per division |
| AdC.uV    | Live A/D millivolt reading   |
| AdC.Pnt   | Live A/D counts  |
| WE.Wght   | Live scale weight  |
| CR.L.PtS  | Calibration points: Displays calibration points, sample weights and ADC counts   |
| d.SPLA    | Display: Tests all LED segments to verify functionality.   |
| KEYb.     | Key buttons: Tests all key inputs to verify functionality.   |
| outPut    | Outputs: Allows operator to select and activate each output to verify functionality.   |
| inPutS    | Inputs: Shows each input state to verify functionality.  |
| SER.num   | Serial number  |

Table 5-4. Diagnostic Parameters

## 6.0 Communications

### 6.1 Serial Settings for 1280 Connection

- `CONNUN. / SERIAL / PCSEL = 485`
- `CONNUN. / SERIAL / CON.PC / PCNODE = Nodebus > Node.Addr: 1`
- `CONNUN. / SERIAL / CON.PC / BAUD = 9600`
- `CONNUN. / SERIAL / CON.PC / PARITY = None`
- `CONNUN. / SERIAL / CON.PC / BITS = 8`
- `CONNUN. / SERIAL / CON.PC / STOP = 1`

### 6.2 Analog Outputs

More repeater indicators are required to add analog outputs.

- To have analog outputs on flow, use the `ENT.FLR` protocol on an available serial port.
- To have analog outputs on load, use the `ENT.LOD` protocol on an available serial port.
- To have analog outputs on speed, use the `ENT.SPD` protocol on an available serial port.
- To have analog outputs on different data, use the `ALL.ENT` protocol on an available serial port.

Configure the following on the repeater when flow, load or speed data is transmitted by the belt indicator:

- `FNODE / FUNC = rEPE`
- `SEtUP / SERIAL / PCSEL = 232` or `485` depending on the connection between the repeater and belt indicator
- `SEtUP / SERIAL / CON.PC`
  - `PCNODE = H.rEPE`
  - `ENTERN = 10` (ASCII code of LF character)
  - `HEI.POS = 0`
  - `HEI.LEN = 8`
  - `STR.LEN = 13`
  - `DEC. = STR.ENT`
  - `StAb` and `StA.int = 0` (they are used to stabilize LED)
  - `trSHLd = SEttr.Lo` and `tr.Hi` as lower and upper bounds for the repeated data and have under/over-load displayed as all lower/upper hyphens
  - `ADU.CEd` = all values of the sub-menus can be left at 0
- `SEtUP / An.Out`
  - `CRPAC` = maximum value of the repeated data without decimals
  - `NODE = Ao YES`
  - `ANPAH` = maximum analog output (related to `CRPAC`)
  - `ANZER` = analog output when repeated data is zero
  - `ANmin` = analog output lower bound
  - `StLen = POS.it`
- Changes in `H.rEPE` settings only, example to repeat speed 1:
  - `ENTERN = 10`
  - `HEI.POS = 81`
  - `HEI.LEN = 8`
  - `STR.LEN = 135`
  - `DEC. = Stream`


### 6.3 PC Port Modes

| Item   | Description   | Sent data |   |   |   |   |   |   |   |   |   |   |   |    |    |
|--|---|-----------|---|---|---|---|---|---|---|---|---|---|---|----|----|
| <i>Ent.FLr</i>   | Continuous flow-rate  |           |   |   |   | 2 | 0 | . | 0 |   | t | / | h | CR | LF |
| <i>Ent.Lod</i> <sup>(1)</sup>  | Continuous load   |           | 1 | 5 | . | 0 | 0 | 0 | k | g | / |   | m | CR | LF |
| <i>Ent.SPd</i> <sup>(2)</sup>  | Continuous speed  |           |   |   |   | 1 | . | 2 | 6 |   | m | / | s | CR | LF |
| <i>ALL.EHt</i> <sup>(1)(2)</sup>   | Continuous $\mu$ V channels, flow-rate, load, speed, totals | (*)       |   |   |   |   |   |   |   |   |   |   |   |    |    |
| <i>rEPE.6</i>  | Repeater 6  |           |   |   |   |   |   |   |   |   |   |   |   |    |    |
| <i>andE</i>  | On demand   |           |   |   |   |   |   |   |   |   |   |   |   |    |    |
| <i>485</i>   | On demand with ID   |           |   |   |   |   |   |   |   |   |   |   |   |    |    |
| <i>Modbus</i>  | Modbus RTU communication                                    |           |   |   |   |   |   |   |   |   |   |   |   |    |    |
| <i>FLd.bus</i><br><i>[dGt4H]</i>   | Fieldbus communication (slim Fieldbus module required)      |           |   |   |   |   |   |   |   |   |   |   |   |    |    |
| <sup>(1)</sup> Load resolution depends on <i>Ld.RES</i> parameter<br><sup>(2)</sup> In US, unit speed has 1 decimal and unit is ft/m |   |           |   |   |   |   |   |   |   |   |   |   |   |    |    |

Table 6-1. PC Port Modes

(\*) ALL.EXt sent data (in gray character locations):

|   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 0 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 3 | 3 | 3 | 3 |   |   |   |
| C | H | 4 | , |   |   |   |   |   | 2 | 5 | 2 | u | V | , |   |   |   |   |   | 2 | 5 | 1 | u | V | , |   |   |   |   | 2 | 5 | 3 |   |   |   |
| 3 | 3 | 3 | 3 | 3 | 3 | 4 | 4 | 4 | 4 | 4 | 4 | 4 | 4 | 4 | 4 | 5 | 5 | 5 | 5 | 5 | 5 | 5 | 5 | 5 | 5 | 5 | 6 | 6 | 6 | 6 | 6 | 6 | 6 |   |   |
| 4 | 5 | 6 | 7 | 8 | 9 | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 |   |   |
| u | V | , |   |   |   |   |   |   | 2 | 4 | 9 | u | V | , | F | R |   |   |   | 9 | 0 | . | 5 | 8 |   | t | / | h | , | L | D |   |   |   |   |
| 6 | 6 | 7 | 7 | 7 | 7 | 7 | 7 | 7 | 7 | 7 | 7 | 8 | 8 | 8 | 8 | 8 | 8 | 8 | 8 | 8 | 8 | 8 | 9 | 9 | 9 | 9 | 9 | 9 | 9 | 9 | 9 | 9 | 1 | 1 |   |
| 8 | 9 | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 0 | 0 | 1 |   |
| 5 | . | 0 | 3 | 2 | k | g | / |   | m | , | S | 1 |   |   |   |   |   |   | 5 | . | 0 | 0 |   | m | / | s | , | S | 2 |   |   |   | 0 | . |   |
| 1 | 1 | 1 | 1 | 1 | 4 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |   |
| 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 3 | 3 | 3 | 3 | 3 | 3 |   |
| 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 0 | 1 | 2 | 3 | 4 | 5 |   |   |
| 0 | 0 |   | m | / | s | , | P | T |   |   |   | 5 | 2 | . | 4 | 8 |   |   | t | , | G | T |   |   | 7 | 8 | 4 | . | 9 | 2 |   | t | C | L |   |
|   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   | R | F |

 **NOTE: RALL command answer = same as ALL.EHt sent data.**  
 If there are less than 4 channels configured,  $\mu$ V data of non-configured channels are sent with value of zero.

### 6.4 PRN Port Modes

| Item           | Description   | Sent data                    |   |   |   |   |   |   |   |   |   |   |   |    |    |
|----------------|---|------------------------------|---|---|---|---|---|---|---|---|---|---|---|----|----|
| <i>Pr-no</i>   | Do nothing  |                              |   |   |   |   |   |   |   |   |   |   |   |    |    |
| <i>tPr</i>     | To print on TPR printer                                     | Now prints gross, tare, net. |   |   |   |   |   |   |   |   |   |   |   |    |    |
| <i>Ent.FLr</i> | Continuous flow-rate  |                              |   |   |   | 2 | 0 | . | 0 |   | t | / | h | CR | LF |
| <i>Ent.Lod</i> | Continuous load   |                              | 1 | 5 | . | 0 | 0 | 0 | k | g | / |   | m | CR | LF |
| <i>Ent.SPd</i> | Continuous speed  |                              |   |   |   | 1 | . | 2 | 6 |   | m | / | s | CR | LF |
| <i>ALL.EHt</i> | Continuous $\mu$ V channels, flow-rate, load, speed, totals | Same as PC port              |   |   |   |   |   |   |   |   |   |   |   |    |    |
| <i>rEPE.6</i>  | Repeater 6  |                              |   |   |   |   |   |   |   |   |   |   |   |    |    |

Table 6-2. PRN Port Modes



## 6.5 USB Communication

| Item           | Description   | Sent data |   |   |   |   |   |   |   |   |   |   |   |   |    |
|----------------|---|-----------|---|---|---|---|---|---|---|---|---|---|---|---|----|
| <i>Ent.FLR</i> | Continuous flow-rate  |           |   |   |   | 2 | 0 | . | 0 |   | t | / | h | C | LF |
| <i>Ent.Lod</i> | Continuous load   |           | 1 | 5 | . | 0 | 0 | 0 | k | g | / |   | m | C | LF |
| <i>Ent.SPd</i> | Continuous speed  |           |   |   |   | 1 | . | 2 | 6 |   | m | / | s | C | LF |
| <i>ALL.EHt</i> | Continuous $\mu$ V channels, flow-rate, load, speed, totals |           |   |   |   |   |   |   |   |   |   |   |   |   |    |
| <i>ondE</i>    | On demand   |           |   |   |   |   |   |   |   |   |   |   |   |   |    |
| <i>4B5</i>     | On demand with ID   |           |   |   |   |   |   |   |   |   |   |   |   |   |    |
| <i>Modbus</i>  | Modbus RTU communication                                    |           |   |   |   |   |   |   |   |   |   |   |   |   |    |

Table 6-3. USB Communication

## 7.0 Fieldbus

### 7.1 Enable Protocol

To enable a bus, set:

- Serial
  - `COMMUN/SERIAL/PCSEL = 485`
  - `Con.Pc/PCNODE = Fld.bus`
    - `bus.TYPE` = selected bus, then insert bus parameters
    - `tin.out` = allows to enable/disable continuous visualization of bus master time out
    - `baud` = set the communication baud-rate (use a baud less than 38400)
    - `PARITY` = None
    - `Word` = 8
    - `Stopb.` = 1 bit

### 7.2 Fieldbus Parameters

| Fieldbus                                | Parameters  |
|---|---|
| Profibus                                | <ul style="list-style-type: none"> <li>• Node.id (0-126): node ID</li> </ul>  |
| Ethernet/IP,<br>Profinet,<br>Modbus TCP | <ul style="list-style-type: none"> <li>• Aut.cfg: auto IP configuration (no/yes)</li> <li>• IP.Add: IP address</li> <li>• Net.msk: Subnet mask</li> <li>• Gat.way: Gateway</li> </ul> |
| CANopen                                 | <ul style="list-style-type: none"> <li>• Nod.add (1-127): node address</li> <li>• Baud.r: baud-rate, values: 1MB, 800kB, 500kB, 250kB, 125kB, 100kB, 50kB, 20kB, 10kB</li> </ul>      |
| DeviceNet                               | <ul style="list-style-type: none"> <li>• Mac.id (0-63): MAC ID</li> <li>• Baud.r: baud-rate, values: 500kB, 250kB, 125kB</li> </ul>   |

Table 7-1. Fieldbus Parameters

## 7.3 Input Data

| Register | Data  |
|----------|---|
| 30001    | Command Status Register (MSB), Current page (LSB) |
| 30002    | Belt Status Register                              |
| 30003    | Belt load (MSW) kg/m or lb/ft with 3 decimals.    |
| 30004    | Belt load (LSW)                                   |
| 30005    | Flow-rate   |
| 30006    | Always zero                                       |
| 30007    | Analog output percentage. 2 decimals.             |
| 30008    | Partial Total (W2)                                |
| 30009    | Partial Total (W1)                                |
| 30010    | Partial Total (W0)                                |
| 30011    | General Total (W2)                                |
| 30012    | General Total (W1)                                |
| 30013    | General Total (W0)                                |
| 30014    | Input Status Register                             |
| 30015    | Output Status Register                            |
| 30016    | Other data  |

Table 7-2. Input Registers 30001 - 30016

## 7.4 Output Data

| Register | Data  |
|----------|---|
| 40001    | Command Status Register (MSB), Current page (LSB) |
| 40002    | Belt Status Register                              |
| 40003    | Belt load (MSW) kg/m or lb/ft with 3 decimals.    |
| 40004    | Belt load (LSW)                                   |
| 40005    | Flow-rate   |
| 40006    | Always zero                                       |
| 40007    | Analog output percentage. 2 decimals.             |
| 40008    | Partial Total (W2)                                |
| 40009    | Partial Total (W1)                                |
| 40010    | Partial Total (W0)                                |
| 40011    | General Total (W2)                                |
| 40012    | General Total (W1)                                |
| 40013    | General Total (W0)                                |
| 40014    | Input Status Register                             |
| 40015    | Output Status Register                            |
| 40016    | Other data  |

Table 7-3. Holding Registers 40001 - 40016



**NOTE:** The only difference is in the Command Register. When the external Fieldbus module is connected through a 485 line, the higher byte is set to 1 and the lower byte is written with the command sent to the device.

## 7.5 Fieldbus Files

|                    | Profibus                         | Ethernet/IP   | Profinet  |
|--------------------|----------------------------------|---|---|
| <b>File Type</b>   | GSD                              | EDS   | GSDML   |
| <b>File Name</b>   | GSD.V.2.gsd                      | DINI NIC 52-RE EIS V1.1.EDS   | GSDML-V2.33-DINI V1.5-NIC 5X-RE PNS-20180206.xml  |
| <b>Device Name</b> | DINIPB                           | DINI NIC 52-RE/EIS  | dini.xxx  |
| <b>Mnft ID</b>     | 0DE1                             | 283   | 011E  |
| <b>Product ID</b>  | --                               | 0x11E (283)   | 010°  |
| <b>Modules</b>     | IN/OUT: 32 Byte (32 word)        | <ul style="list-style-type: none"> <li>• Input (T→O)</li> <li>• Output (O→T)</li> </ul> T = target<br>O = originator  | <ul style="list-style-type: none"> <li>• 64byteinput</li> <li>• 64byteoutput</li> </ul>   |
| <b>Qty</b>         | 1                                | 1   | 2   |
| <b>Description</b> | 32 input bytes + 32 output bytes | <ul style="list-style-type: none"> <li>• 128 byte input area module</li> <li>• 128 byte output area module</li> </ul> | <ul style="list-style-type: none"> <li>• 64 byte module for the input area</li> <li>• 64 byte module for the output area</li> </ul> |

Table 7-4. Fieldbus File Information

|                    | EtherCAT  | CANopen  | DeviceNET  |
|--------------------|---|--|--|
| <b>File Type</b>   | ESI   | EDS  | EDS  |
| <b>File Name</b>   | Dini NIC 52-RE ECS V4.2.X.xml   | DINI NIC 50-COS.eds  | DINI-NIC 50-DNS.EDS  |
| <b>Device Name</b> | DINI NIC 52-RE/ECS  | DINI NIC 50-COS  | DINI Slim-DeviceNet NIC 50-DNS   |
| <b>Mnft ID</b>     | 0xE0000044  | 0x00000044   | 283  |
| <b>Product ID</b>  | 0x00000033  | 1541540  | 35   |
| <b>Modules</b>     | <ul style="list-style-type: none"> <li>• Input</li> <li>• Output</li> </ul>   | <ul style="list-style-type: none"> <li>• Input</li> <li>• Output</li> </ul>  | <ul style="list-style-type: none"> <li>• Input (Production)</li> <li>• Output (Consumption)</li> </ul>                               |
| <b>Qty</b>         | 1   | 64   | 1  |
| <b>Description</b> | <ul style="list-style-type: none"> <li>• 200 byte module for the input area</li> <li>• 200 byte module for the output area</li> </ul> | <ul style="list-style-type: none"> <li>• 8 bytes modules for the input area (TXPDU). Min. 4 TXPDU (32 byte)</li> <li>• 8 bytes module for the output area (RXPDU). Min. 4 RXPDU (32 byte)</li> </ul> | <ul style="list-style-type: none"> <li>• 128 byte module for the input area</li> <li>• 32 byte module for the output area</li> </ul> |

Table 7-5. Fieldbus File Information

## 7.6 Messages

### 7.6.1 Profibus

| Message        | Meaning                        |
|----------------|--------------------------------|
| <i>Pb.in i</i> | Displays on startup            |
| <i>Pb.DF</i>   | Initialization is successful   |
| <i>Pb.Err</i>  | Initialization is unsuccessful |
| <i>Pb.Conn</i> | Master device connected        |
| <i>Pb.disc</i> | Master device disconnected     |

Table 7-6. Profibus Messages

## 7.6.2 Other Fieldbus

| Message             | Meaning   |
|---------------------|---|
| <i>FbuS.Er</i>      | Displays when no connection is established after 30 sec from startup or after 3 sec since last received from module |
| <i>FrrH.YY</i>      | Firmware version of the module hub  |
| <i>Fb.COnn</i>      | Initialized connection between module and scale   |
| <i>Fb.DF</i>        | Master Fieldbus connected   |
| <i>Fb.d.SC</i>      | Master Fieldbus disconnected (time out error display disabled)  |
| <i>F.b.ErrHcodE</i> | Error state (see <a href="#">Table 7-8 on page 39</a> )   |

Table 7-7. Messages for Other Fieldbus

## 7.6.3 Error Codes

| Code                 | Meaning   |
|----------------------|---|
| 1000                 | Fatal error in hub module   |
| 1001                 | Inconsistency between protocol type selected and the protocol type managed by the fieldbus module |
| 1-18                 | Other fatal error in Fieldbus module  |
| 000001 and following | Unrecoverable error in Fieldbus module  |
| 000140               | General network error   |
| 000141               | Connection closed   |
| 000142               | Time-out connection   |
| 000143               | Isolated network  |
| 000144               | Duplicated node   |
| 000145               | Network cable disconnected  |
| 600078               | Modbus TCP: Server closed the connection since no data was sent for more than 30 sec              |

Table 7-8. Error Codes

## 7.7 Ethernet Configuration

Setup the following items in *CONN / Eth.CFG*:

- *iP.TYPE* (IP address type): select Static or Dynamic
- *iP.Addr* (IP address, only visible if static IP is selected): IP address configuration
- *nEt.MSk* (Subnet Mask, only visible if static IP is selected): subnet mask configuration
- *Eth.CON* (Com Port): choose a port connected to the module (232 or 485)
- *SEnd.CF* (Send Configuration): send configuration to the module and save

## 7.8 Symbols

All data is expressed in big-endian order.

| Symbol | Meaning  |
|--------|--|
| MSW    | Most significant word  |
| LSW    | Least significant word   |
| Wx     | Word rank in a multi-word string<br>Example W2, W1, W0: W2 is the MSW, W0 is the LSW |
| MSB    | Most significant byte  |
| LSB    | Least significant byte   |

Table 7-9. Symbol Meanings

## 7.9 Input Registers

| Register | Data  |
|----------|---|
| 30001    | Command Status Register (MSB), Current page (LSB) |
| 30002    | Belt Status Register                              |
| 30003    | Belt load (MSW) kg/m or lb/ft with 3 decimals.    |
| 30004    | Belt load (LSW)                                   |
| 30005    | Flow-rate   |
| 30006    | Always zero                                       |
| 30007    | Analog output percentage. 2 decimals.             |
| 30008    | Partial Total (W2)                                |
| 30009    | Partial Total (W1)                                |
| 30010    | Partial Total (W0)                                |
| 30011    | General Total (W2)                                |
| 30012    | General Total (W1)                                |
| 30013    | General Total (W0)                                |
| 30014    | Input Status Register                             |
| 30015    | Output Status Register                            |
| 30016    | Other data  |

Table 7-10. Input Registers (Page 0)

| Register | Data  |
|----------|---|
| 30001    | Command Status Register (MSB), Current page (LSB)                   |
| 30002    | Target flow-rate (unit/decimals as in 3.3.2 - Flow-rate resolution) |
| 30003    | Scale capacity (MSW)  |
| 30004    | Scale capacity (LSW) (unit as in 3.1.1 -Unit system, 3 decimals)    |
| 30005    | Max flow-rate (unit/decimals)                                       |
| 30006    | Min flow-rate (unit/decimals), dead band flow-rate                  |
| 30007    | Dosage time (MSW)   |
| 30008    | Dosage time (LSW) (as set with function 307, 1/100 sec)             |
| 30009    | Target batch weight (W2)  |
| 30010    | Target batch weight (W1)  |
| 30011    | Target batch weight (W0) (unit/decimals)                            |
| 30012    | Digital output function   |
| 30013    | Digital output ON value (MSW)                                       |
| 30014    | Digital output ON value (LSW)                                       |
| 30015    | Digital output OFF value (MSW)                                      |
| 30016    | Digital output OFF value (LSW)                                      |

Table 7-11. Input Registers (Page 1)

| Register | Data   |
|----------|--|
| 30001    | Command Status Register (MSB), Current page (LSB)                  |
| 30002    | PID Kp (integer value with 2 decimals)                             |
| 30003    | PID Ki (integer value with 2 decimals)                             |
| 30004    | PID Kd (integer value with 2 decimals)                             |
| 30005    | PID action interval time (integer value in seconds with 1 decimal) |
| 30006    | Pulse weight (MSW)   |
| 30007    | Pulse weight (LSW) (Rel. 3.07)                                     |
| 30008    |  |
| 30009    |  |
| 30010    |  |
| 30011    |  |
| 30012    |  |
| 30013    |  |
| 30014    |  |
| 30015    |  |
| 30016    |  |

Table 7-12. Input Registers (Page 2)

| Register | Data  |
|----------|---|
| 30001    | Command Status Register (MSB), Current page (LSB)                         |
| 30002    | Belt Status Register  |
| 30003    | Belt load (MSW). Kg/m or lb/ft with Ld.Res decimals.                      |
| 30004    | Belt load (LSW).  |
| 30005    | Flow-rate   |
| 30006    | Speed encoder 2 (0.01m/s or 0.1ft/min) – CPWE Belt here has PID value     |
| 30007    | Analog output percentage (2 decimals)                                     |
| 30008    | Partial Total (W1)  |
| 30009    | Partial Total (W0)  |
| 30010    | General Total (W1)  |
| 30011    | General Total (W0)  |
| 30012    | Speed encoder 1 (0.01m/s or 0.1ft/min). Fixed speed if no encoder is used |
| 30013    | Inclination. ° with 1 decimal   |
| 30014    | Input Status Register   |
| 30015    | Output Status Register  |
| 30016    | Other data  |

Table 7-13. Input Registers (Page 3)

| Register | Data   |
|----------|--|
| 30001    | Command Status Register (MSB), Current page (LSB)                |
| 30002    | Selected article index (65535, FFFF hex, if no article selected) |
| 30003    | PID start percentage value (2 decimals)                          |
| 30004    | Target flow-rate (setup decimals)                                |
| 30005    | Weight to dose (W1)  |
| 30006    | Weight to dose (W0) (setup totals decimal and unit)              |
| 30007    | Correction factor (W1)   |
| 30008    | Correction factor (W0) (integer with 6 decimals)                 |
| 30009    | Total dosed weight (W1)  |
| 30010    | Total dosed weight (W0) (setup totals decimal and unit)          |
| 30011    | Total number of batchings (W1)                                   |
| 30012    | Total number of batchings (W0)                                   |
| 30013    |  |
| 30014    |  |
| 30015    |  |
| 30016    |  |

Table 7-14. Input Registers (Page 4)

| Register | Data  |
|----------|---|
| 30001    | Command Status Register (MSB), Current page (LSB)                       |
| 30002    | $\mu$ V channel 1   |
| 30003    | $\mu$ V channel 2   |
| 30004    | $\mu$ V channel 3   |
| 30005    | $\mu$ V channel 4   |
| 30006    | $\mu$ V sum   |
| 30007    | $\mu$ V average   |
| 30008    | Calibration status (Test weight procedure status)                       |
| 30009    | Calibration total (Totalized in the procedure, in totals resolution)    |
| 30010    | Calibration error (0.01%)   |
| 30011    | New correction factor (calculated at the end of the test procedure) (H) |
| 30012    | New correction factor (L)   |
| 30013    | Percentage progress value for zero calibration                          |
| 30014    | Percentage progress value for test weight procedure                     |
| 30015    |   |
| 30016    |   |

Table 7-15. Input Registers (Page 5)



| Register | Data   |
|----------|--|
| 30001    | Command Status Register (MSB), Current page (LSB)            |
| 30002    | Unit system (0: metrix, 1: US)                               |
| 30003    | Operative mode (0: belt, 1: bulkslide)                       |
| 30004    | Pulse weight (H)   |
| 30005    | Pulse weight (L) (totals resolution)                         |
| 30006    | Pulse time width (0.1 sec)                                   |
| 30007    | Bulkslide air purge interval (min)                           |
| 30008    | Bulkslide air purge time (sec)                               |
| 30009    | Bulkslide air purge max flow (unit, decimals flow-rate)      |
| 30010    | Bulkslide air purge delay (sec)                              |
| 30011    | Analog output function (0: flow, 1: load, 2: speed)          |
| 30012    | Analog output mode (0: 4-20mA, 1: 0-20mA, 2:2-10V, 3: 0-10V) |
| 30013    | Analog output min DAC value                                  |
| 30014    | Analog output max DAC value                                  |
| 30015    | Analog output manual belt speed (DAC)                        |
| 30016    | Load decimals (0+3)  |

Table 7-16. Input Registers (Page 6) - Set with Command 24 (18hex)

| Register | Data  |
|----------|---|
| 30001    | Command Status Register (MSB), Current page (LSB) |
| 30002    | Input 1 function                                  |
| 30003    | Input 2 function                                  |
| 30004    | Output 1 function                                 |
| 30005    | Output 1 NO/NC (0: NO, 1: NC)                     |
| 30006    | Output 2 function                                 |
| 30007    | Output 2 NO/NC                                    |
| 30008    | Output 3 function (DGT1SX)                        |
| 30009    | Output 3 NO/NC (DGT1SX)                           |
| 30010    | Output 4 function (DGT1SX)                        |
| 30011    | Output 4 NO/NC (DGT1SX)                           |
| 30012    |   |
| 30013    |   |
| 30014    |   |
| 30015    |   |
| 30016    |   |

Table 7-17. Input Registers (Page 7) - Set with Command 25 (19hex)

| Register | Data  |
|----------|---|
| 30001    | Command Status Register (MSB), Current page (LSB)                               |
| 30002    | Totals resolution   |
| 30003    | Flow-rate resolution  |
| 30004    | Max flow-rate (in flow-rate resolution)   |
| 30005    | Max load (kg/m or lb/ft)  |
| 30006    | Encoder 1 enable (0: disabled, 1: enabled)                                      |
| 30007    | Length per pulse encoder 1 (0.01mm or 0.0001in)                                 |
| 30008    | Encoder 2 enable  |
| 30009    | Length per pulse encoder 2  |
| 30010    | Fixed speed (0.01m/s, 0.1ft/min)  |
| 30011    | Max belt speed (0.01m/s, 0.1ft/min)   |
| 30012    | Encoders speed difference   |
| 30013    | Dead band % (0.1%)  |
| 30014    | Show flow-rate in dead band (0: no, 1: yes)                                     |
| 30015    | Totalize with negative flow-rate (0: no, 1: yes)                                |
| 30016    | Store totals (b15=0: no, b15=1: yes). b14-b0: max flow % to store totals (0.1%) |

Table 7-18. Input Registers (Page 8) - Set with Command 26 (1Ahex)

| Register | Data  |
|----------|---|
| 30001    | Command Status Register (MSB), Current page (LSB) |
| 30002    | Flow-rate filter time (sec)                       |
| 30003    | Flow-rate filter Win                              |
| 30004    | Flow-rate filter Avg                              |
| 30005    | Flow-rate filter Pit                              |
| 30006    | Load cell filter index                            |
| 30007    | Load cell filter rate                             |
| 30008    | Load cell filter Win                              |
| 30009    | Load cell filter Avg                              |
| 30010    | Load cell filter Pit                              |
| 30011    |   |
| 30012    |   |
| 30013    |   |
| 30014    |   |
| 30015    |   |
| 30016    |   |

Table 7-19. Input Registers (Page 9) - Set with Command 27 (1Bhex)

| Register | Data  |
|----------|---|
| 30001    | Command Status Register (MSB), Current page (LSB) |
| 30002    | Number of channels                                |
| 30003    | Load cell capacity (H)                            |
| 30004    | Load cell capacity (L) (0.001 kg/lb)              |
| 30005    | Load cell sensitivity (H)                         |
| 30006    | Load cell sensitivity (L) (0.00001mV/V)           |
| 30007    | Load cell zero mV/V (H)                           |
| 30008    | Load cell zero mV/V (L) (0.00001mV/V)             |
| 30009    | Weigh length (mm, 0.01in)                         |
| 30010    | Pivot to load cell distance (mm, 0.01in)          |
| 30011    | Pivot to idler distance (mm, 0.01in)              |
| 30012    | Serial inclinometer                               |
| 30013    | Belt angle (0.1°)                                 |
| 30014    | Correction factor (H)                             |
| 30015    | Correction factor (L) (0.000001)                  |
| 30016    | Zero belt time (0.01s)                            |

Table 7-20. Input Registers (Page 10) - Set with Command 28 (1Chex)

| Register | Data  |
|----------|---|
| 30001    | Command Status Register (MSB), Current page (LSB) |
| 30002    | Belt length (0.1 m/ft)                            |
| 30003    | Zero revolutions                                  |
| 30004    | Zero range % (0.1%)                               |
| 30005    | Auto zero range % (0.1%)                          |
| 30006    | Auto zero limit % (0.1%)                          |
| 30007    | Test weight (H)                                   |
| 30008    | Test weight (L) (0.01 kg/lb)                      |
| 30009    | Test weight delay (0.1s)                          |
| 30010    | Test weight distance (0.01 m/ft)                  |
| 30011    | Test weight time (0.1s)                           |
| 30012    | Test weight material factor (H)                   |
| 30013    | Test weight material factor (L) (0.000001)        |
| 30014    |   |
| 30015    |   |
| 30016    |   |

Table 7-21. Input Registers (Page 11) - Set with Command 29 (1Dhex)

| Register | Data  |
|----------|---|
| 30001    | Command Status Register (MSB), Current page (LSB) |
| 30002    | Error off-track enable                            |
| 30003    | Error off-track alarm time (0.1s)                 |
| 30004    | Error off-track lock time (0.1s)                  |
| 30005    | Error overload flow-rate enable                   |
| 30006    | Error overload flow-rate alarm time (0.1s)        |
| 30007    | Error overload flow-rate lock time (0.1s)         |
| 30008    | Overflow flow-rate % (0.1%)                       |
| 30009    | Error flow-rate enable                            |
| 30010    | Error flow-rate alarm time (0.1s)                 |
| 30011    | Error flow-rate lock time (0.1s)                  |
| 30012    | Min flow-rate (flow resolution)                   |
| 30013    | Max flow-rate (flow resolution)                   |
| 30014    |   |
| 30015    |   |
| 30016    |   |

Table 7-22. Input Registers (Page 12) - Set with Command 30 (1Ehex)

| Register | Data  |
|----------|---|
| 30001    | Command Status Register (MSB), Current page (LSB) |
| 30002    | Error weight enable                               |
| 30003    | Error weight alarm time (0.1s)                    |
| 30004    | Error weight lock time (0.1s)                     |
| 30005    | Min weight (H)                                    |
| 30006    | Min weight (L) (kg or lb)                         |
| 30007    | Max weight (H)                                    |
| 30008    | Max weight (L) (kg or lb)                         |
| 30009    | Error external enable                             |
| 30010    | Error external alarm time (0.1s)                  |
| 30011    | Error external lock time (0.1s)                   |
| 30012    | Error load cell over-load enable                  |
| 30013    | Error load cell over-load alarm time (0.1s)       |
| 30014    | Error load cell over-load lock time (0.1s)        |
| 30015    |   |
| 30016    |   |

Table 7-23. Input Registers (Page 13) - Set with Command 31 (1Fhex)

## 7.9.1 Command Status Register

| B15-B12        | B11-B8                      | B7-B0        |
|----------------|-----------------------------|--------------|
| Command Result | Number of executed commands | Current page |
| Result value   | Description                 |              |
| 0              | OK                          |              |
| 1              | Not allowed command         |              |
| 2              | Wrong command data          |              |
| 3              | Unknown command             |              |

Table 7-24. Command Status Registers

## 7.9.2 Belt Status Register

| B15-B12    | B11-B8         | B7-B0      |
|------------|----------------|------------|
| Belt State | Operation mode | Error code |

Table 7-25. Belt Status Registers

### 7.9.2.1 Belt State

| Value | State                          |
|-------|--------------------------------|
| 0     | ALARM                          |
| 1     | MANUAL (Input ON/OFF open)     |
| 2     | WAIT (Input ENABLE closed)     |
| 3     | PAUSE                          |
| 4     | (Unused)                       |
| 5     | RUN                            |
| 6     | START (batch start phase)      |
| 7     | END BATCH (batch end phase)    |
| 8     | LOCK                           |
| 9     | ZERO BELT underway             |
| 10    | TEST WEIGHT procedure underway |

Table 7-26. Belt State Values

### 7.9.2.2 Operation Mode

| Value | Mode                     |
|-------|--------------------------|
| 0     | Reader (PID not enabled) |
| 1     | Controller (PID enabled) |

Table 7-27. Operation Mode Values

### 7.9.2.3 Error Codes

| Value | Description                             | Enable Setup Item  |
|-------|---|--|
| 0     | NO ERROR                                |  |
| 1     | OFF TRACK ALARM                         | OFF.trf  |
| 2     | MIN FLOW RATE ALARM                     | FLOH.r.  |
| 3     | MAX FLOW RATE ALARM                     | FLOH.r.  |
| 4     | ZERO FLOW RATE                          | Set if no alarm is active, add total is enabled and flow is zero |
| 5     | WEIGHT ALARM                            | WE.wht   |
| 6     | OFF TRACK LOCK                          | OFF.trf  |
| 7     | MIN FLOW RATE LOCK                      | FLOH.r.  |
| 8     | MAX FLOW RATE LOCK                      | FLOH.r.  |
| 9     | DOSAGE WEIGHT LOCK                      | Not used   |
| 10    | LOCK due to input ON/OFF or ENABLE open | Set for 1 second, then Belt state is changed to 1                |
| 11    | WEIGHT LOCK                             | WE.wht   |
| 12    | EXTERNAL ALARM                          | EHtErrn  |
| 13    | EXTERNAL ALARM LOCK                     | EHtErrn  |
| 14    | FLOW RATE LOCK                          | QUEr.Ld  |
| 15    | LOAD CELL OVERLOAD ALARM                | LC.QUEr  |
| 16    | LOAD CELL OVERLOAD LOCK                 | LC.QUEr  |
| 17    | FLOW RATE ALARM                         | QUEr.Ld  |

Table 7-28. Error Codes

| Alarm Priority | Alarm   |
|----------------|---------|
| 1              | OFF.trf |
| 2              | WE.wht  |
| 3              | FLOH.r. |
| 4              | EHtErrn |
| 5              | QUEr.Ld |
| 6              | LC.QUEr |

Table 7-29. Alarm Priorities

### 7.9.3 Flow-Rate

Value with decimals and unit as set in flow-rate resolution (see [Table 3-10 on page 20](#)).

### 7.9.4 Analog Output Percentage

Integer with 1 decimal. Percentage of (Max value – Zero value).

### 7.9.5 Partial and general totals

Value with decimals and unit as set in total resolution (see [Table 3-10 on page 20](#)).

## 7.9.6 Input Status Register

| Bit   | Description                     | Bit meaning 01    |               |
|-------|---------------------------------|-------------------|---------------|
| (LSB) |                                 |                   |               |
| 0     | Load Polarity                   | +                 | --            |
| 1     | Weight stability                | Unstable weight   | Stable weight |
| 2     | Underload Condition             | NO                | YES           |
| 3     | Overload Condition              | NO                | YES           |
| 4     | Flow zero range                 | Out of zero range | In zero range |
| 5     | Totals unit of measure (lsb)    |                   |               |
| 6     | Totals unit of measure (msb)    |                   |               |
| 7     | Hourly Flow Polarity            | +                 | --            |
| (MSB) |                                 |                   |               |
| 8     | Flow-rate unit of measure (lsb) |                   |               |
| 9     | Flow-rate unit of measure (msb) |                   |               |
| 10    | Status of input IN 1            | disabled          | enabled       |
| 11    | Status of input IN 2            | disabled          | enabled       |
| 12    |                                 |                   |               |
| 13    |                                 |                   |               |
| 14    |                                 |                   |               |
| 15    |                                 |                   |               |

Table 7-30. Input Status Registers

### 7.9.6.1 Totals Unit of Measure

| Value | Unit                |
|-------|---------------------|
| 1     | kg                  |
| 2     | t (tn in US system) |
| 3     | lb                  |

Table 7-31. Totals Unit of Measure

### 7.9.6.2 Flow-rate unit of measure

| Value | Unit                    |
|-------|-------------------------|
| 1     | kg/h                    |
| 2     | t/h (tn/h in US system) |
| 3     | lb/h                    |

Table 7-32. Flow-rate Unit of Measure

### 7.9.7 Output Status Register

| Bit | Description                     | Bit Meaning 0 | Bit Meaning 1 |
|-----|---------------------------------|---------------|---------------|
| 0   | Digital Output 1 State          | disabled      | enabled       |
| 1   | Digital Output 2 State          | disabled      | enabled       |
| 2   | Digital Output 3 State (DGT1SX) | disabled      | enabled       |
| 3   | Digital Output 4 State (DGT1SX) | disabled      | enabled       |
| 4   |                                 |               |               |
| 5   |                                 |               |               |
| 6   |                                 |               |               |
| 7   |                                 |               |               |

Table 7-33. Output Status Register - LSB

| Bit | Description     | Bit Meaning 0 | Bit Meaning 1 |
|-----|-----------------|---------------|---------------|
| 8   | Ch 1 error      | NO            | SI            |
| 9   | Ch 2 error      | NO            | SI            |
| 10  | Ch 3 error      | NO            | SI            |
| 11  | Ch 4 error      | NO            | SI            |
| 12  | Ch global error | NO            | SI            |
| 13  |                 |               |               |
| 14  |                 |               |               |
| 15  |                 |               |               |

Table 7-34. Output Status Register - MSB

### 7.9.8 Other Data

| B15-B8            | B7-6           | B4-5               | B0-B3                      |
|-------------------|----------------|--------------------|----------------------------|
| Number of dosages | Active encoder | Flow-rate decimals | Totals decimal (rel. 3.07) |

Table 7-35. Misc Data

- Active encoder is zero when no encoder is enabled.
- Active encoder is 1 if only the first encoder is enabled or if both encoders are enabled and the first one is the working encoder.
- Active encoder is 2 if two encoders are enabled and the second one is the working encoder.

### 7.9.9 Digital Output Function

| B15-B8               | B7-B0   |
|----------------------|---|
| Digital Output Index | Digital output function as set in outputs configuration (see <a href="#">Table 3-5 on page 17</a> ) |

Table 7-36. Digital Output Function



### 7.9.10 Digital Output ON/OFF Value

Used only with digital output function Pulse weight. On and OFF values are set with the same value. Unit/decimals are as set in total resolution (see [Table 3-10 on page 20](#))

#### 7.9.10.1 Totals Resolution

| Value       | Resolution  |
|-------------|-------------|
| 0           | 0.1 kg (lb) |
| 1           | 0.2 kg (lb) |
| 2           | 0.5 kg (lb) |
| 3           | 1 kg (lb)   |
| 4           | 2 kg (lb)   |
| 5           | 5 kg (lb)   |
| 6 (default) | 0.01 t (tn) |
| 7           | 0.02 t (tn) |
| 8           | 0.05 t (tn) |
| 9           | 0.1 t (tn)  |
| 10          | 0.2 t (tn)  |
| 11          | 0.5 t (tn)  |
| 12          | 1 t (tn)    |
| 13          | 2 t (tn)    |
| 14          | 5 t (tn)    |

Table 7-37. Totals Resolutions

#### 7.9.10.2 Flow-Rate Resolution

| Value       | Resolution           |
|-------------|----------------------|
| 0           | 1 kg/h (1 lb/h)      |
| 1           | 0.01 t/h (0.01 tn/h) |
| 2 (default) | 0.1 t/h (0.1 tn/h)   |
| 3           | 1 t/h (1 tn/h)       |

Table 7-38. Flow-Rate Resolutions

## 7.10 Holding Registers

Reading Holding Registers 40001-40016 is the same as reading Input Registers 30001-30016.

Holding Registers writing:

| Register                 | Data                       |
|--------------------------|----------------------------|
| 40001                    | Command Register           |
| 40002 and following ones | Used as command parameters |

Table 7-39. Holding Registers

## 7.10.1 Available Commands

| Command Value | Command Hex Value | Description   |
|---------------|-------------------|---|
| 0             | 0                 | None  |
| 1             | 1                 | Not used  |
| 2             | 2                 | Start (clears PT in STOP status)  |
| 3             | 3                 | Pause batch/control   |
| 4             | 4                 | Stop (RUN or ENABLE input enabled)  |
| 5             | 5                 | Set flow-rate (remote flow percentage if remote setting enable)   |
| 6             | 6                 | Set dosage weight   |
| 7             | 7                 | Set dosage time   |
| 8             | 8                 | Print format  |
| 9             | 9                 | Reset general total   |
| 10            | A                 | Set output (see <a href="#">Section 7.10.2.1 on page 53</a> )   |
| 11            | B                 | Store setup (If parameters changed restart indicator, command 34)                                       |
| 12            | C                 | Change digital output index (Page 1 Input Registers) (see <a href="#">Section 7.10.2.2 on page 53</a> ) |
| 13            | D                 | Set digital output value (see <a href="#">Section 7.10.2.3 on page 53</a> )                             |
| 14            | E                 | Change page - Page to set (0 to 2)  |
| 15            | F                 | Zero belt function  |
| 16            | 10                | Set PID Kp parameter  |
| 17            | 11                | Set PID Ki parameter  |
| 18            | 12                | Set PID Kd parameter  |
| 19            | 13                | Set PID action interval time  |
| 20            | 14                | Set digital input (see <a href="#">Section 7.10.2.4 on page 53</a> )                                    |
| 21            | 15                | Select article (from rel. 3.06)   |
| 22            | 16                | Reset partial total   |
| 23            | 17                | Set pulse weight (double word value) See <a href="#">Table 7-45 on page 53</a>                          |
| 24            | 18                | Write settings 1 (page 6) (see <a href="#">Section 7.10.2.6 on page 54</a> )                            |
| 25            | 19                | Write settings 2 (page 7)   |
| 26            | 1A                | Write settings 3 (page 8)   |
| 27            | 1B                | Write settings 4 (page 9)   |
| 28            | 1C                | Write settings 5 (page 10)  |
| 29            | 1D                | Write settings 6 (page 11)  |
| 30            | 1E                | Write settings 7 (page 12)  |
| 31            | 1F                | Write settings 8 (page 13)  |
| 32            | 20                | Static zero   |
| 33            | 21                | Test weight procedure   |
| 34            | 22                | Restart indicator   |
| 35            | 23                | Confirm test weight error and store new correction factor   |
| 36            | 24                | Decline test weight error   |
| 37            | 25                | Set Modbus RTU silence time in mins (5 / 200)   |

Table 7-40. Available Commands

## 7.10.2 Commands Parameters

### 7.10.2.1 Set Output

| Register | Data                                  |
|----------|---------------------------------------|
| 40002    | Digital output setting state bit mask |

Table 7-41. Set Output

Bit 0: Set digital output 1 state

...

Bit 15: Set digital output 16 state

Bit value = 0: Digital output OFF

Bit value = 1: Digital output ON



**NOTE:** Only digital outputs with function set to None can be switched on/off with this command.

### 7.10.2.2 Change Digital Output Index

| Register | Data                          |
|----------|-------------------------------|
| 40002    | Digital output index (1 - 16) |

Table 7-42. Change Digital Output Index

### 7.10.2.3 Set Digital Output Value

| Register | Data                 |
|----------|----------------------|
| 40002    | Digital output index |
| 40003    | ON value (MSW)       |
| 40004    | ON value (LSW)       |
| 40005    | OFF value (MSW)      |
| 40006    | ON value (LSW)       |

Table 7-43. Set Digital Output Value

### 7.10.2.4 Set Digital Input

| Register | Data   |
|----------|--|
| 40002    | Bitmap of inputs to activate/deactivate <ul style="list-style-type: none"> <li>• To activate input, set bit to 1</li> <li>• To deactivate input, set bit to 0</li> </ul><br>B0: digital input 1<br>B1: digital input 2<br>B2: digital input 3<br>B3: digital input 4<br>B4: digital input 5<br>B5: digital input 6<br>B6: digital input 7<br>B7: digital input 8 |

Table 7-44. Set Digital Input

### 7.10.2.5 Set Pulse Weight

| Register | Data               |
|----------|--------------------|
| 40002    | Pulse weight (MSW) |
| 40003    | Pulse weight (LSW) |

Table 7-45. Set Pulse Weight

## 7.10.2.6 Write Settings

| Register | Data                     |
|----------|--------------------------|
| 40002    | Setting parameters start |
| ...      | ...                      |
| 40016    | Setting parameters end   |

Table 7-46. Write Settings

Example with page 6:

| Register | Data   |
|----------|--|
| 40001    | 24   |
| 40002    | Unit system (0: metrix, 1: US)                               |
| 40003    | Operative mode (0: belt, 1: bulkslide)                       |
| 40004    | Pulse weight (H)   |
| 40005    | Pulse weight (L)   |
| 40006    | Pulse time width (0.1 sec)                                   |
| 40007    | Bulkslide air purge interval (min)                           |
| 40008    | Bulkslide air purge time (sec)                               |
| 40009    | Bulkslide air purge max flow (unit, decimals flow-rate)      |
| 40010    | Bulkslide air purge delay (sec)                              |
| 40011    | Analog output function (0: flow, 1: load, 2: speed)          |
| 40012    | Analog output mode (0: 4-20mA, 1: 0-20mA, 2:2-10V, 3: 0-10V) |
| 40013    | Analog output min DAC value                                  |
| 40014    | Analog output max DAC value                                  |
| 40015    | Analog output manual belt speed (DAC)                        |
| 40016    |  |

Table 7-47. Page 6 Example

### 7.10.3 Status Holding Registers

| Register | Data  |
|----------|---|
| 40021    | Belt Command Status Register  |
| 40022    | Belt Status Register  |
| 40023    | Belt load (MSW). Kg/m or lb/ft with Ld.Res decimals.                          |
| 40024    | Belt load (LSW).  |
| 40025    | Flow-rate   |
| 40026    | Speed encoder 2 (0.01m/s or 0.1ft/min) – Zero without 2 <sup>nd</sup> encoder |
| 40027    | Analog output percentage (2 decimals)   |
| 40028    | Partial Total (W1)  |
| 40029    | Partial Total (W0)  |
| 40030    | General Total (W1)  |
| 40031    | General Total (W0)  |
| 40032    | Speed encoder 1 (0.01m/s or 0.1ft/min). Fixed speed if no encoder is used     |
| 40033    | Inclination. ° with 1 decimal   |
| 40034    | Input Status Register   |
| 40035    | Output Status Register  |
| 40036    | Other data  |
| 40037    | µV channel 1  |
| 40038    | µV channel 2  |
| 40039    | µV channel 3  |
| 40040    | µV channel 4  |
| 40041    | µV sum  |
| 40042    | µV average  |
| 40043    | Calibration status (Test weight procedure status)                             |
| 40044    | Calibration total (Totalized in the procedure, in totals resolution)          |
| 40045    | Calibration error (0.01%)   |
| 40046    | New correction factor (calculated at the end of the test procedure) (H)       |
| 40047    | New correction factor (L)   |
| 40048    | Percentage progress value for zero calibration                                |
| 40049    | Percentage progress value for test weight procedure                           |

Table 7-48. Status Holding Registers

### 7.10.3.1 Belt Command Status Register

| B15-B8         | B7-B0   |
|----------------|---|
| Command Result | Number of executed command values for module 16 |

Table 7-49. Belt Command Status Register

### 7.10.3.2 Command Result Values

| Result Value | Description         |
|--------------|---------------------|
| 0            | OK                  |
| 1            | Command not allowed |
| 2            | Wrong command data  |
| 3            | Unknown command     |

Table 7-50. Command Result Values

### 7.10.3.3 Belt Status Register

| B15-B12    | B11-B8         | B7-B0      |
|------------|----------------|------------|
| Belt State | Operation mode | Error code |

Table 7-51. Belt Status Register

| Value | State                          |
|-------|--------------------------------|
| 0     | ALARM                          |
| 1     | MANUAL (Input ON/OFF open)     |
| 2     | WAIT (Input ENABLE closed)     |
| 3     | PAUSE                          |
| 4     | (Unused)                       |
| 5     | RUN                            |
| 6     | START (batch start phase)      |
| 7     | END BATCH (batch end phase)    |
| 8     | LOCK                           |
| 9     | ZERO BELT underway             |
| 10    | TEST WEIGHT procedure underway |

Table 7-52. Belt State Values

| Value | Mode                     |
|-------|--------------------------|
| 0     | Reader (PID not enabled) |
| 1     | Controller (PID enabled) |

Table 7-53. Operation Mode Values

| Value | Description                             | Enable setup item  |
|-------|---|--|
| 0     | NO ERROR                                |  |
| 1     | OFF TRACK ALARM                         | OFF.trf  |
| 2     | MIN FLOW RATE ALARM                     | FLOW.r.  |
| 3     | MAX FLOW RATE ALARM                     | FLOW.r.  |
| 4     | ZERO FLOW RATE                          | Set if no alarm is active, add total is enabled and flow is zero |
| 5     | WEIGHT ALARM                            | WE.ght   |
| 6     | OFF TRACK LOCK                          | OFF.trf  |
| 7     | MIN FLOW RATE LOCK                      | FLOW.r.  |
| 8     | MAX FLOW RATE LOCK                      | FLOW.r.  |
| 9     | DOSAGE WEIGHT LOCK                      | Not used   |
| 10    | LOCK due to input ON/OFF or ENABLE open | Set for 1 second, then Belt state is changed to 1                |
| 11    | WEIGHT LOCK                             | WE.ght   |
| 12    | EXTERNAL ALARM                          | EHtErn   |
| 13    | EXTERNAL ALARM LOCK                     | EHtErn   |
| 14    | FLOW RATE LOCK                          | DUEr.Ld  |
| 15    | LOAD CELL OVERLOAD ALARM                | LC.DUEr  |
| 16    | LOAD CELL OVERLOAD LOCK                 | LC.DUEr  |
| 17    | FLOW RATE ALARM                         | DUEr.Ld  |

Table 7-54. Error Code Values

| Priority | Alarm   |
|----------|---------|
| 1        | OFF.trf |
| 2        | WE.ght  |
| 3        | FLOW.r. |
| 4        | EHtErn  |
| 5        | DUEr.Ld |
| 6        | LC.DUEr |

Table 7-55. Alarm Priority

| Priority | Alarm   |
|----------|---|
| 0        | Idle  |
| 1        | Positioning   |
| 2        | Start   |
| 3        | Wait start belt   |
| 4        | Wait belt regimen   |
| 5        | Run   |
| 6        | End   |
| 7        | Ask to save test weight (if executed by keyboard and test weight value = 0) |
| 8        | Ask to set new factor (if executed by keyboard)                             |
| 9        | Waiting for confirm (if executed by remote command)                         |
| 10       | Confirm (temporary status to save data, then will switch to Idle status)    |

Table 7-56. Test Weight Procedure Status Priority

## 7.10.4 Setting Registers

| Register | Data   |
|----------|--|
| 48001    | Unit system (0: metrix, 1: US)   |
| 48002    | Operative mode (0: belt, 1: bulkslide)   |
| 48003    | Pulse weight (H)   |
| 48004    | Pulse weight (L) (totals resolution)   |
| 48005    | Pulse time width (0.1 sec)   |
| 48006    | Bulkslide air purge interval (min)   |
| 48007    | Bulkslide air purge time (sec)   |
| 48008    | Bulkslide air purge max flow (unit, decimals flow-rate)                              |
| 48009    | Bulkslide air purge delay (sec)  |
| 48010    | Analog output function (0: flow, 1: load, 2: speed)                                  |
| 48011    | Analog output mode (0: 4-20mA, 1: 0-20mA, 2:2-10V, 3: 0-10V)                         |
| 48012    | Analog output min DAC value  |
| 48013    | Analog output max DAC value  |
| 48014    | Analog output manual belt speed (DAC)  |
| 48015    | Input 1 function   |
| 48016    | Input 2 function   |
| 48017    | Output 1 function  |
| 48018    | Output 1 NO/NC (0: NO, 1: NC)  |
| 48019    | Output 2 function  |
| 48020    | Output 2 NO/NC   |
| 48021    | Output 3 function (DGT1SX)   |
| 48022    | Output 3 NO/NC (DGT1SX)  |
| 48023    | Output 4 function (DGT1SX)   |
| 48024    | Output 4 NO/NC (DGT1SX)  |
| 48025    | Totals resolution  |
| 48026    | Flow-rate resolution   |
| 48027    | Max flow-rate (in flow-rate resolution)  |
| 48028    | Max load (kg/m or lb/ft)   |
| 48029    | Encoder 1 enable (0: disabled, 1: enabled)   |
| 48030    | Length per pulse encoder 1 (0.01mm or 0.0001in)                                      |
| 48031    | Encoder 2 enable   |
| 48034    | Max belt speed (0.01m/s, 0.1ft/min)  |
| 48035    | Encoders speed difference %  |
| 48036    | Dead band % (0.1%)   |
| 48037    | Show flow-rate in dead band (0: no, 1: yes)  |
| 48038    | Totalize with negative flow-rate (0: no, 1: yes)                                     |
| 48039    | Store totals (b15=0: no, b15=1: yes). b14-b0: max flow % to store totals (0.1%)      |
| 48040    | Flow-rate filter time (set on indicator restart)                                     |
| 48041    | Flow-rate filter Win   |
| 48042    | Flow-rate filter Avg   |
| 48043    | Flow-rate filter Pit   |
| 48044    | Load cell filter index (set immediately if not custom filter)                        |
| 48045    | Load cell filter rate (set if custom filter is selected, enabled when pit is writte) |
| 48046    | Load cell filter Win (set if custom filter is selected, enabled when pit is writte)  |
| 48047    | Load cell filter Avg (set if custom filter is selected, enabled when pit is writte)  |

Table 7-57. Setting Registers



| Register | Data   |
|----------|--|
| 48048    | Load cell filter Pit (set if custom filter is selected, enabled when pit is write) |
| 48049    | Number of channels (weight restarted)  |
| 48050    | Load cell capacity (H)   |
| 48051    | Load cell capacity (L) (0.001 kg/lb)   |
| 48052    | Load cell sensitivity (H)  |
| 48053    | Load cell sensitivity (L) (0.00001mV/V)  |
| 48054    | Load cell zero mV/V (H)  |
| 48055    | Load cell zero mV/V (L) (0.00001mV/V) (activate when this reg. is written)         |
| 48056    | Weigh length (mm, 0.01in)  |
| 48057    | Pivot to load cell distance (mm, 0.01in)   |
| 48058    | Pivot to idler distance (mm, 0.01in)   |
| 48059    | Serial inclinometer  |
| 48060    | Belt angle (0.1°)  |
| 48061    | Correction factor (H)  |
| 48062    | Correction factor (L) (0.000001)   |
| 48063    | Zero belt time (0.01s)   |
| 48064    | Belt length (0.1 m/ft)   |
| 48065    | Zero revolutions   |
| 48066    | Zero range % (0.1%)  |
| 48067    | Auto zero range % (0.1%)   |
| 48068    | Auto zero limit % (0.1%)   |
| 48069    | Test weight (H)  |
| 48070    | Test weight (L) (0.01 kg/lb)   |
| 48071    | Test weight delay (0.1s)   |
| 48072    | Test weight distance (0.01 m/ft)   |
| 48073    | Test weight time (0.1s)  |
| 48074    | Test weight material factor (H)  |
| 48075    | Test weight material factor (L) (0.000001)   |
| 48076    | Error off-track enable   |
| 48077    | Error off-track alarm time (0.1s)  |
| 48078    | Error off-track lock time (0.1s)   |
| 48079    | Error overload flow-rate enable  |
| 48080    | Error overload flow-rate alarm time (0.1s)   |
| 48081    | Error overload flow-rate lock time (0.1s)  |
| 48082    | Overflow flow-rate % (0.1%)  |
| 48083    | Error flow-rate enable   |
| 48084    | Error flow-rate alarm time (0.1s)  |
| 48085    | Error flow-rate lock time (0.1s)   |
| 48086    | Min flow-rate (flow resolution)  |
| 48087    | Max flow-rate (flow resolution)  |
| 48088    | Error weight enable  |
| 48089    | Error weight alarm time (0.1s)   |
| 48090    | Error weight lock time (0.1s)  |
| 48091    | Min weight (H)   |
| 48092    | Min weight (L) (kg or lb)  |
| 48093    | Max weight (H)   |
| 48094    | Max weight (L) (kg or lb)  |

Table 7-57. Setting Registers (Continued)

| Register | Data  |
|----------|---|
| 48095    | Error external enable                       |
| 48096    | Error external alarm time (0.1s)            |
| 48097    | Error external lock time (0.1s)             |
| 48098    | Error load cell over-load enable            |
| 48099    | Error load cell over-load alarm time (0.1s) |
| 48100    | Error load cell over-load lock time (0.1s)  |
| 48101    | Load decimals (0÷3)                         |

Table 7-57. Setting Registers (Continued)

## 8.0 Specifications

---

**Power**

12 to 24 VDC

**Power Consumption**

5 W

**Excitation Voltage**

5 VDC, 120 mA (up to 16 × 350 ohm cells)

**Analog Signal Input Range**

±39 mV

**Analog Signal Sensitivity**

0.3  $\mu$ V/graduation minimum

**Sample Rate**

Single-channel up to 2,600 Hz, software selectable  
4 channels up to 100 Hz, software selectable

**Analog Output (if equipped)**

Opt. isolated, 16-bit  
0 to 20 mA, 4 to 20 mA (maximum 350 ohm)  
0 to 5 VDC, 0 to 10 VDC (minimum 10,000 ohm)

**Digital I/O**

Two inputs: 12/24 VDC, 1 kHz  
Two outputs: 150 mA 48 VAC/150 mA 60 VDC

**Communication Ports**

(1) RS-485 half duplex, (1) RS-232 full duplex  
1 USB Micro B connector (device)  
for PC configuration

**Pulse Input**

Dual inputs for redundancy

**Display**

Six-digit 0.31 in (8 mm), red LED

**Keys/Buttons**

Flat membrane panel, tactile feel

**Dimensions**

Overall: 10.5 × 6.26 × 12.5 in (266 × 159 × 318 mm)

**Mounting Tabs**

8.0 × 13.12 in  
(203 × 333 mm)

**Weight**

27 lb


**Rating/Material**

NEMA 4X (if using supplied enclosure)

**Warranty**

One-year limited

**Approvals**

 CE-M EN 4550







© Rice Lake Weighing Systems Content subject to change without notice.

230 W. Coleman St. • Rice Lake, WI 54868 • USA USA: 800-472-6703 • International: +1-715-234-9171