


VIRTUi^{®3} for Windows[®]

Forklift Scale PC Program

Technical Manual



© Rice Lake Weighing Systems. All rights reserved.

Rice Lake Weighing Systems® is a registered trademark of
Rice Lake Weighing Systems.

Windows® is a registered trademark of the Microsoft Corporation
All other brand or product names within this publication are trademarks or
registered trademarks of their respective companies.

All information contained within this publication is, to the best of our knowledge, complete and accurate at the time of publication. Rice Lake Weighing Systems reserves the right to make changes to the technology, features, specifications and design of the equipment without notice.

The most current version of this publication, software, firmware and all other product updates can be found on our website:

www.ricelake.com

1.0	Introduction	9
1.1	Overview	9
1.1.1	Features	9
1.1.2	System Requirements	9
2.0	Installation	10
2.1	Junction Box Serial Port Configuration	11
3.0	Operation	12
3.1	Launching VIRTUI3	12
3.2	VIRTUI3 User Interface	13
3.2.1	Diagnostic Event	14
3.2.2	VIRTUI3 Mini Indicator for Static Mode	14
3.2.3	VIRTUI3 Mini Indicator for In-motion Mode	15
3.3	Ticket Printing	15
4.0	VIRTUI3 Menu	16
4.1	How to Access the VIRTUI3 Menu	16
4.2	About Menus Options	17
4.3	Scale Communications	18
4.4	User Mode	19
4.5	Printer Communications	20
4.6	Mini Indicator Settings	20
4.7	Scale Settings	21
4.8	Diagnostics	22
4.9	Scale Terminal	23
4.10	JBox (Junction Box) Type	23
4.11	Save and Restore Settings	24
5.0	Calibration	25
5.1	Calibration Overview	25
5.1.1	Calibration Preparation	25
5.1.2	Devices Used for Lifting of Calibration Weights	25
5.2	Calibration Process Using VIRTUI3 Virtual Indicator	26
5.2.1	Rezero Scale	26
5.2.2	Calibration Selection	26
5.2.3	Two Point Calibration	27
5.2.4	Linear Point Calibration	32
6.0	Scale Tests	36
6.1	Test Operational Elements	37
6.2	Pre-Test Diagnostics	38
6.3	Single Weight Accuracy Test	39
6.3.1	Single Weight Accuracy Test Result Examples	41
6.4	Corner Weight Accuracy Test	42
6.4.1	Corner Weight Accuracy Test Result Examples	44
6.5	Fork Angle Test	45
6.5.1	Fork Angle Test Result Examples	47
6.6	Scale Health Test	48
6.6.1	Performing Scale Health Test	49
6.6.2	Scale Status Test Result Examples	51
6.6.3	Troubleshooting Scale Status Test Failed Results	52



Rice Lake continually offers web-based video training on a growing selection of product-related topics at no cost. Visit www.ricelake.com/webinars

Contents

6.7	Scale Test - Log Files	53
6.7.1	Viewing Log Files	53
6.7.2	Saving Log Files	53
6.7.3	Single Weight Accuracy Test Entry Examples	55
6.7.4	Corner Weight Accuracy Test Entry Examples	56
6.7.5	Fork Angle Test Entry Examples	57
6.7.6	Health Test Entry Examples	59
7.0	Appendix	60
7.1	Error Messages	60
7.1.1	Invalid Data Errors	60
7.1.2	Load Cell Overload	60
7.1.3	Load Cell Underload	61
7.1.4	Angle Invalid	61
7.2	Junction Box Firmware Update	62



Technical training seminars are available through Rice Lake Weighing Systems. Course descriptions and dates can be viewed at www.ricelake.com/training or obtained by calling 715-234-9171 and asking for the training department.



Rice Lake continually offers web-based video training on a growing selection of product-related topics at no cost. Visit www.ricelake.com/webinars

Revision History

This section tracks and describes manual revisions for awareness of major updates.

Revision	Date	Description
D	December 12, 2024	Revision History Established; Software version 3.2.0.4

Table i. Revision Letter History



Technical training seminars are available through Rice Lake Weighing Systems. Course descriptions and dates can be viewed at www.ricelake.com/training or obtained by calling 715-234-9171 and asking for the training department.



Rice Lake continually offers web-based video training on a growing selection of product-related topics at no cost. Visit www.ricelake.com/webinars

1.0 Introduction

VIRTUi³ for Windows® provides a user interface for the CLS forklift scale. It is a virtual indicator utilizing a device that may already be present in an application. VIRTUi³ provides the user access to weight indication, calibration, configuration and diagnostics all in one package. This manual will aid in software installation and understanding of the software functions.



Manuals are available from Rice Lake Weighing Systems at www.ricelake.com/manuals

Warranty information is available at www.ricelake.com/warranties

1.1 Overview

The VIRTUi³ PC program interfaces with the Rice Lake Weighing Systems' CLS series junction box. It is used to display weight information, calibrate, configure and perform diagnostics.

A Windows PC VIRTUi³ server runs in the background and communicates with a CLS series junction box. Its primary function is to support the VIRTUi³ client application along with having the ability to send EDP commands for printing tickets and reports.

1.1.1 Features

- Virtual indicator: Field streams live weight or final “capture in motion” weight depending on scale configuration
- Zero button, print button (static and in-motion modes), in-motion clear button (in-motion mode)
- Pitch and roll angles displayed
- Visual step-by-step calibration procedure
- Scale Test and Diagnostics menus for field testing
- Emulates command/response format of the CLS protocol from the junction box
- Available EDP command server for customer use

1.1.2 System Requirements

- Windows 8.1, Windows 10, Windows 11 or equivalent Windows Server® operating system
- 1.6 GHz processor or faster
- 100 MB HD space needed for installation
- Microsoft.NET framework 4.6.2 (included with installer)
- 8 GB ram or greater
- Serial port connection (for digital weight indicators)
- Optional printer



NOTE: 32 bit or 64 bit versions.

2.0 Installation

VIRTUi³ version 3.2.0.0 and higher installs a client and server from a single software package. In previous software versions each instance had to be installed separately.

The VIRTUi³ client displays live data when connected and configured to the junction box. The VIRTUi³ server runs in the background and communicates with the CLS forklift junction box. The server streams weight data through an applicable port and has the ability to process some EDP commands.

1. Download VIRTUi³ software from ricelake.com and unzip the file if necessary.
2. Launch **VIRTUi3.Combined.Installer.exe**.
3. Read the Rice Lake Weighing Systems License Agreement. Enable the check box below the agreement if the terms are acceptable.




Figure 2-1. VIRTUi3 Server Setup Installation Window

4. (Optional) Perform the following to change the installation location:
 - Select **Options**, then **Browse** to install VIRTUi³ software in a user specified file location.
 - Select **OK** to return to the previous window.




Figure 2-2. VIRTUi3 Server Installation Options

5. The Installation Successfully Completed window displays, select **Close**. VIRTUi³ Server is successfully installed.




Figure 2-3. VIRTUi3 Server Setup Window Completed



NOTE: Once installed, VIRTUi³ creates the following services:

- Web server on port 9015 used by VIRTUi³ client application
- Single frame server on port 30355
- Stream frame server on port 30356
- Print ability using configured port 10000



IMPORTANT: Ensure listed ports are not being used by other services and/or blocked by firewalls.

2.1 Junction Box Serial Port Configuration

The junction box port type must be set to **CMD**.



NOTE: Ensure **ECHO** is set to **OFF**.

3.0 Operation

This section describes the VIRTU³ interface.

3.1 Launching VIRTU³

1. Launch the VIRTU³ application from Windows Start[®] menu.




Figure 3-1. VIRTU³ Start Shortcut

2. By default VIRTU³ software opens in mini indicator mode. Select **X** to close mini indicator mode and open standard the full-size application.




Figure 3-2. VIRTU³ Mini Indicator



NOTE: See [Section 4.6 on page 20](#) for information about disabling mini indicator mode at start-up.




Figure 3-3. Full-Size VIRTU³ Application

3.2 VIRTU³ User Interface




Figure 3-4. VIRTU³ Main Screen for Static




Item	Function	Description
A	Weight Display Type	The weight display area provides either live weight or final weight and is distinguished by a prompt in the top left corner of the display area. Common display items include: <ul style="list-style-type: none"> • +/-999999: Valid weight display • Invalid: Invalid weight display • ~~~~~: Pitch or roll exceeded tolerances. • ^^^: Load cell overload • _____: Load cell underload Various other scale error state conditions are represented in the weight display area.
B	Annunciators	Annunciators indicate live weight, final weight, gross mode (GROSS), net mode (NET), center of zero (→0←), stability (▴ ▾) and angle condition (⊖).
C	Scale Capacity and Count By	The capacity and count by is displayed in the bottom right corner of the weight display area.
D		Zeros the scale.
		Prints the ticket.
		Recaptures the final weight (in-motion mode only).
E	Pitch and Roll	The pitch and roll display area shows the live pitch and roll angle data received from the junction box. A valid angle data is represented as +/-99.9 .
F	Status Bar	Displays the version number, the current mode distinguishes if the user interface is in static mode or in-motion and the unit ID number which is entered during the calibration process (Section 5.0 on page 25).

Table 3-1. VIRTU³ Element Descriptions

3.2.1 Diagnostic Event

A **Diagnostic Cell Overload Event** condition displays when a diagnostic event is triggered in the junction box. See [Section 4.8 on page 22](#) and [Section 7.0 on page 60](#) for more information.




Figure 3-5. Diagnostic Event Message

3.2.2 VIRTU³ Mini Indicator for Static Mode

Select the button in the bottom right corner to launch the VIRTU³ mini indicator which can satisfy Legal for Trade NTEP requirements. This enables the operator to run other applications while still being able to display live weight information.



Figure 3-6. Launch VIRTU³ Mini Indicator by Selecting the Identified Button

 **NOTE:** The VIRTU³ mini indicator for static mode is re-sizable.




Figure 3-7. Mini indicator for Static Mode

3.2.3 VIRTUi³ Mini Indicator for In-motion Mode

The VIRTUi³ mini indicator supports in-motion forklift scales and provides the following user interface when launched with the junction box setup for an in-motion forklift scale. The following are examples of how the VIRTUi³ Mini appears on different size displays and can be resized to a predetermined minimum and maximum height and width.





Figure 3-8. Live Weight Display Examples

3.3 Ticket Printing

Printing a weigh ticket is only supported when the user interface displays the  button. A printout can be initiated by selecting the **Print** button. The button turns green to indicate the current weight information will result in a print transaction. Configure the printer port by modifying the Printer Communications settings in the options menu.

4.0 VIRTUi³ Menu

VIRTUi³ contains a menu with several options. Each option opens a new display that provides settings or additional functionality.

4.1 How to Access the VIRTUi³ Menu

1. Select **Menu** from the application tool bar.




Figure 4-1. Menu Location in Tool Bar

2. The drop-down menu expands and displays the available options.
3. Select the desired option from the Menu.




Figure 4-2. Menu Expanded

4.2 About Menu Options




Figure 4-3. Menu Drop-Down Expanded



Item	Option	Description
A		Closes the menu.
B	Scale Communications	Opens scale communication settings (see Section 4.3 on page 18).
C	Calibration	Opens scale calibration functions (see Section 5.0 on page 25).
D	User Mode	Opens junction box operating mode settings (see Section 4.4 on page 19).
E	Printer Communications	Opens printer communication settings (see Section 4.5 on page 20).
F	Mini Indicator Settings	Opens mini indicator display settings (see Section 4.6 on page 20).
G	Scale Settings	Opens basic scale settings for Primary Units, Zero Range and Weight Threshold (see Section 4.7 on page 21).
H	Scale Test	Opens junction box and load cell test functions (see Section 6.0 on page 36).
I	Diagnostics	Opens junction box and load cell diagnostic information (see Section 4.8 on page 22).
J	Terminal	Opens an EDP command terminal (see Section 4.9 on page 23).
K	JBox Type	Unlocks junction box in order to set specific User Modes (see Section 4.10 on page 23).
K	Save & Restore	Provides Save and Restore settings (see Section 4.11 on page 24).

Table 4-1. Menu Element Descriptions



4.3 Scale Communications

Access scale communications settings by selecting **Scale Communications** from the menu. Scale Communications provides parameters that configure scale port settings.


To connect with Serial communication:

1. Configure the Com Port, Baud Rate (9600), Data Bits (8), Stop Bits (1) and Parity (None).
2. Select  Connect .
3. Select  to close the screen.

To connect with USB communication:

1. Open the COM Port drop-down menu without the USB cable connected and record available com ports.
2. Connect the USB cable to the device and PC.
3. Open the COM Port drop-down menu and then select the new com port.
4. Select  Connect .
5. Select  to close the screen.



NOTE: To release Com Port settings, open the COM Port drop-down menu select COM-None followed by  Connect .




Figure 4-4. Menu - Scale Communications

4.4 User Mode

Access user mode settings by selecting **User Mode** from the menu. The junction box operates in various modes which are identified by a three digit number, for example: 100, 200, 600. These user modes allow an array of configuration parameters that are predefined to be changed in one step.

Access User Mode setting by selecting **User Mode** in the menu.

User Modes are defined as:

- 100 (1xx) modes include variations of static scales
- 200 (2xx) modes include variations of in-motion scales
- 600 (6xx) modes include variations of static scales compatible with the CLS-680.
- Other modes are customer or application specific



NOTE: Forklift scales and junction boxes ordered for In-Motion use are factory configured prior to shipping and do not require PassCalc setting.




Figure 4-5. User Mode

Certain modes require the junction box to be unlocked prior to setting them. The junction box only needs to be unlocked once. After that, the user can change modes without having to unlock the unit again. To unlock the junction box mode, perform the following.

1. Select User Mode from the Menu.
2. Call Rice Lake Weighing Systems and provide the displayed PASSCALC Seed.
3. Enter the PASSCALC Result provided by Rice Lake Weighing Systems.
4. Select the associated **Upload** button next to the PASSCALC seed.
5. The user interface will refresh and display unlocked if successful.



NOTE: The unit must be in setup mode to perform this general setting.

Once the In-Motion forklift mode is unlocked, the junction box can be switched between Static and In-Motion modes.

4.5 Printer Communications

Access printer communications settings by selecting **Printer Communications** from the menu. Set the ticket printer port setting (serial or TCPIP) using the drop down Port Type menu.




Figure 4-6. Printer Communications

4.6 Mini Indicator Settings

Access mini indicator settings by selecting **Mini Indicator Settings** from the menu.

Launch With Mini Indicator

To launch the mini indicator enable this setting first by checking the Launch box (Figure 4-7)

Force Position

Enable the Force Position checkbox (Figure 4-7) to force positional and size constraints for the mini indicator when it is launched. Perform the following steps to find the required settings.

1. Disable the **Force Position** setting in the mini indicator settings option tab.
2. Exit Mini Indicator settings and open mini indicator
3. Adjust mini indicator size and position settings.
4. Close the mini indicator to update the adjusted size and position settings.
5. Open Mini Indicator Settings.
6. Enable the **Force Position** setting in the mini indicator settings options tab (Figure 4-7).
7. Select **Save**.




Figure 4-7. Options Menu - Mini-Indicator Settings

4.7 Scale Settings

Access scale settings by selecting **Scale Settings** from the menu. Adjust the required settings followed by selecting **Upload** to update the junction box.




Figure 4-8. Scale Settings

Setting	Description
Primary Units	Identifies between pounds or kilograms (read only)
Zero Range	Specifies the range within which the scale can be zeroed
Weight Threshold	Specifies the minimum number of display divisions required to capture final weight

Table 4-2. Scale Settings Descriptions

4.8 Diagnostics

Diagnostics displays data from the connected junction box involving hardware status and voltages and firmware version. There are two possible ways to access the Diagnostics menu. Under normal operation, the Diagnostic menu can be selected from the Menu. If a diagnostic event occurs, a red **DIAGNOSTIC Event** button appears next to the roll angle display box, which when selected, displays the Diagnostic menu.




Figure 4-9. Diagnostics Menu

Test	Description
JBox Firmware Version	Displays the firmware of the junction box.
Zero Change	Displays change in zero.
Power Supply Voltage (V)	Lists power supply voltage.
Excitation Supply Voltage (V)	Lists excitation supply voltage.
Cell 1 Voltage (mV)	Lists load cell 1 value in millivolts.
Cell 2 Voltage (mV)	Lists load cell 2 value in millivolts.
Cell 1 Trim	Lists load cell 1 trim value.
Cell 2 Trim	Lists load cell 1 trim value.
Cell Connection Status	Lists the status of load cell connection: <ul style="list-style-type: none"> • OK • SC1 = Load cell 1 disconnected. • SC2 = Load cell 2 disconnected.
Overload Status	Lists overload status.
Underload Status	Lists underload status.
Power Supply Status	Lists the status of power supply.
Excitation Supply Stat	Lists the status of the excitation supply.

4.9 Scale Terminal

Access the scale terminal by selecting **Terminal** from the menu. The scale terminal sends EDP commands to the junction box and receive associated responses.



Figure 4-10. Scale Terminal Settings

4.10 JBox (Junction Box) Type

Access junction box type settings by selecting **JBox Type** from the menu. Certain user modes require the junction box to be unlocked prior to setting them. The junction box needs to be unlocked only once, after which User Modes can be changed without unlocking again. Perform the following steps to unlock the junction box type.

1. 1. Provide RLWS representative the displayed Passcalc Seed.
2. 2. Enter Passcalc result provided by RLWS representative.
3. 3. Click the upload button to update the JBox.
4. 4. The UI will refresh and display unlocked if successful.




Figure 4-11. Junction Box Type

4.11 Save and Restore Settings

Access save and restore settings by selecting **Save & Restore** from the menu. Using the Save & Restore setting allows the user to save a dump all command response to a file and save/restore junction box calibration settings.




Figure 4-12. Save and Restore





Function	Description
	Saves the DUMPALL EDP command response to a file (.txt).
	Save the DUMP.CAL EDP command response to a file (.cal).
	Uploads data from a selected calibration file (.cal) to the junction box.
	Restores factory defaults for calibration and configuration settings. NOTE: Unit must be in setup mode to restore factory defaults. A configuration service warning is displayed prior to restoring factory defaults. Configuration Service Warning This will restore factory defaults for scale calibration and configuration settings. Do you want to continue? <input type="button" value="Yes"/> <input type="button" value="Cancel"/>

Table 4-3. Save And Restore Functions

5.0 Calibration

The CLS forklift must be properly calibrated to get accurate readings. A slight percentage variation can result in inaccurate weights. Calibration is accomplished by using a two point calibration. Once the two point calibration is complete, a pitch offset calibration and linear calibration can follow as needed.

5.1 Calibration Overview

Perform the following steps to calibrate the CLS forklift.

1. Enter Serial Number of CLS forklift.
2. Level the scale and calibrate the pitch and roll.
3. Perform a zero calibration.
4. Perform a two point calibration.
 - Enter the test weight value
 - Calibrate cell #1
 - Calibrate cell #2
 - Rezero (optional)
5. Perform pitch offset calibration (option for static mode).
6. Multi-point linear calibration (optional)
 - Enter the test weight value
 - Calibrate linear point #1
 - Repeat additional multi points if desired
7. Finish and save.

5.1.1 Calibration Preparation



IMPORTANT: *There are several important tips that should be noted prior to calibrating the CLS In-Motion Forklift Scale.*

- *The test weights used to calibrate the CLS Forklift scale cannot Exceed 2500 lb*
- *Use a level to ensure the forklift tines are level prior to calibration*
- *Exercise the load cells prior to calibration by lifting weights*
- *Follow calibration sequences in order, otherwise errors will occur*

5.1.2 Devices Used for Lifting of Calibration Weights

There are many techniques and devices used for lifting the test weights during the calibration process. For the best performance, Rice Lake Weighing Systems recommends the following methods and devices.

Two Pair of Straps, Slings, Chains, Fork Sleeves with Hooks

The use of two straps, chains or fork sleeves with hooks are recommended methods used to lift weights during the calibration process. Place the devices on each fork before zero calibration step. For best performance, devices used to lift the weight should be less than 10-20 lb each.

One Single Strap Sling, Chain, Fork Sleeve with Hook

The use of a single device requires the known weight of the device to be added during the calibration process.

5.2 Calibration Process Using VIRTUi³ Virtual Indicator

Scale calibration can be performed during runtime by accessing the calibration flyout menu via the application top tool bar (Figure 4-2 on page 16). The calibration menu provides access to calibration wizards two point and linear calibration and the ability to rezero the scale.

5.2.1 Rezero Scale

The rezero scale button allows the user to rezero the scale after it's calibrated.



5.2.2 Calibration Selection

1. Select **Calibration** to enter the calibration menu.



Figure 5-1. Calibration Menu

2. Select a calibration process:

- Two point calibration  , see [Section 5.2.3 on page 27](#).
- Linear calibration  , see [Section 5.2.4 on page 32](#).



NOTE: If both calibration boxes are grayed out in [Figure 5-1](#), this indicates there is no connectivity.


5.2.3 Two Point Calibration

At minimum, a two point calibration process is required. The two point calibration process requires a known weight to be loaded on each fork independently. By loading each fork with a known weight, the scale acquires both the span calibration and trim values to account for differences between each fork.

1. Access Two Point Calibration.
2. Enter the unit serial number between 1 - 999999.

The screenshot shows a software interface for 'Two Point Calibration'. At the top, it says 'Calibration' with a back arrow. Below that, the title 'Two Point Calibration' is displayed in red. A text prompt reads 'Enter the unit serial number in range of 1 to 999999.' To the right of this prompt is a text input field containing the serial number '125632'. Below the input field is a horizontal line. On the right side of the screen, there are four vertically stacked buttons: 'Next' (with a red play icon), 'Back' (with a red left arrow icon), 'Skip' (with a red curved arrow icon), and 'Finish' (with a red play icon).

Figure 5-2. Enter Serial Number

3. Select  .
4. Level the pitch and roll angles of the scale carriage using a level.




Figure 5-3. Level Scale Carriage

5. Select  .

- Place a calibration strap, chain or channel across both forks to ensure proper digital trimming during the calibration process. If a single strap, chain or channel cannot be placed across both forks, enter the total of the device and calibration weight into the span weight value in the span text box.





Figure 5-4. Add Span Weight Value

- Select  .
- Attach the calibration weight to fork 1. Lift the forks to freely suspend the calibration weight.





Figure 5-5. Add Weight to Fork 1

- Select  .
- Attach the calibration weight to fork 2. Lift the forks to freely suspend the calibration weight.





Figure 5-6. Add Weight to Fork 2

11. Select .

 **NOTE:** At this point the two point calibration is complete. Select  to return to the weight indication.

12. Select  to perform the pitch off-set calibration process.

 **NOTE:** Off-set Calibration is required for in-motion and optional for static applications




Figure 5-7. Review Load Cell Trim Values

13. Remove all calibration weights and devices from both forks. Adjust pitch and roll angles so both are as close as possible to 0°.




Figure 5-8. Remove Calibration Weights

14. Select .

- Remove all calibration weights and devices from both forks. Pitch forks forward to approximately +3°.




Figure 5-9. Pitch Forks +3°

- Select .

- Remove all calibration weights and devices from both forks. Pitch forks backward to approximately -5°.




Figure 5-10. Pitch Forks -5°

- Select .

- Place weight on a pallet and lift with forks. Adjust the pitch and roll angles so both are as close as possible to 0°.




Figure 5-11. Bring Angles Close to 0°

20. Select .

21. Place weight on a pallet and lift with forks. Pitch the forks forward to approximately +3°.




Figure 5-12. Pitch Forks +3°

22. Select .

23. Place weight on a pallet and lift with forks. Pitch the forks backward to approximately -5°.

 **NOTE:** The pitch offset calibration is complete.





Figure 5-13. Pitch Forks -5°

24. Select  to proceed to the 5 point linearization calibration process ([Section 5.2.4 on page 32](#)).

5.2.4 Linear Point Calibration

Following the two point calibration (required), is a procedure to learn the characteristics of the scale while attached to the forklift. This is accomplished by moving the forklift mast forward and back one with no weight followed by the same process for a loaded lift. It is also recommended to follow the two point calibration with a multi point calibration (optional). This process allows two to five known weights to be calibrated as linear points.





Figure 5-14. Linear Calibration Start

Perform Linear calibration with up to 5 weigh points, where each weight value must be larger than the previous weight.

1. Place a pallet on the forks.
2. Select .
3. Enter the test weight value for linear point 1.
4. Place a test weight on the pallet.





Figure 5-15. Linear Point 1

5. Select .
6. Enter the test weight value for linear point 2.
7. Place a test weight on the pallet.





Figure 5-16. Linear Point 2

8. Select .
9. Enter the test weight value for linear point 3.
10. Place a test weight on the pallet.




Figure 5-17. Linear Point 3

11. Select .

12. Enter the test weight value for linear point 4.
13. Place a test weight on the pallet.





Figure 5-18. Linear Point 4

14. Select .
15. Enter the test weight value for linear point 5.
16. Place a test weight on the pallet.




Figure 5-19. Linear Point 5

17. Select .

18. Remove all weight, including the pallet.





Figure 5-20. Remove All Weight

19. Select .




Figure 5-21. Linear Calibration Process Complete

20. The linear point calibration process is complete. Return the scale back to the weight mode to confirm and store the calibration data.

6.0 Scale Tests

Access Scale Tests by selecting **Scale Tests** from the Menu. After selection, Scale Test opens in new window with the Home page displayed. The Home page provides a list of five user selectable tests that can aid verifying if a system is operating correctly. Performing tests typically involve user interaction and may require removing current weight or lifting tests weights in various positions on forks.




Figure 6-1. Test Functions Identified

Test Buttons






Item	Function	Description
A	 Single Weight Accuracy Test	Tests the accuracy of a weight evenly lifted by both forks (see Section 6.3 on page 39).
B	 Corner Weight Accuracy Test	Tests the accuracy of a weight on both forks one corner at a time (see Section 6.4 on page 42).
C	 Fork Angle Test	Tests the pitch and roll status of the forks (see Section 6.5 on page 45).
D	 Scale Health Test	Reports the scale health (see Section 6.6 on page 48).
E	 Test Logs	Opens the test log which lists results of each performed test (see Section 6.7 on page 53)

Table 6-1. Test Function Descriptions

6.1 Test Operational Elements

Several screen elements are used to operate tests. Figure 6-2 displays the Single Weight Test with operational elements identified.




Figure 6-2. Test Operational Elements Identified











Item	Element	Description
A	Weight:	Configures weight value during testing. NOTE: Only used during Single and Corner Weight Accuracy Tests.
B		Confirms test selection and configured weight parameters (in Single and Corner Weight Accuracy Tests).
C		Activates the test. NOTE: Some tests may require selecting this function several times.
D		Advances to the next test.
E		Returns to the previous test.
F		Not used.
G		Navigates to the Scale Test Home page.
H		Performs one of the following: <ul style="list-style-type: none">  Minimizes the Scale Test window.  Maximizes the Scale Test window.  Closes Scale Test window.

Table 6-2. Test Operational Elements Descriptions

6.2 Pre-Test Diagnostics

Each tests preforms Pre-Test Diagnostics before activation and that checks the following:

Test	Description
Scale Weight	Displays the current weight measured by the scale. In addition, displays weight failure or error states: <ul style="list-style-type: none"> • Invalid: Invalid weight display • ~~~~~: Pitch or roll exceeded tolerances • ^^^^^^^: Load cell overload • _____: Load cell underload
Load Cell 1 mV	Displays raw mV from load cell 1.
Load Cell 2 mV	Displays raw mV from load cell 2.
The mV for cell 1	Lists the configured minimum and maximum mV values in relation to load cell 1.
The mV for cell 2	Lists the configured minimum and maximum mV values in relation to load cell 2.
Pitch Angle	Displays the calculated pitch angle in degrees. For test criteria see, Section 6.5 on page 45 .
Roll Angle	Displays the calculated roll angle in degrees. For test criteria see, Section 6.5 on page 45 .
UID	Displays the Unit ID. This value is configured from the factory as the forklift serial number.
User Mode	Displays the user mode number from junction box.

Table 6-3. Pre-Test Diagnostics

Results of Pre-Test Diagnostics are not displayed during tests and can be viewed in Test Logs ([Section 6.7 on page 53](#)). Faulty or disconnected communications will cause Pre-Test Diagnostics to fail.

[Figure 6-3](#) displays Pre-Test Diagnostics occurring during the Single Weight Accuracy Test. The same text indication appears on each test.





Figure 6-3. Gathering Pre-Test Diagnostics

6.3 Single Weight Accuracy Test

The Single Weight Accuracy tests involves configuring a weight value and testing it against a known weight lifted evenly between the two forks. The test passes when the configured weight value is measured at $\pm 1.05\%$ compared to the known weight.

1. Select  from the Scale Test Home page.
2. Remove weight and then level the forks.
3. Enter weight of the test weight into the **Weight** field.
4. Select **Confirm**.




Figure 6-4. Single Weight Accuracy Test Configuration

5. Pre-Test Diagnostics processes.




Figure 6-5. Gathering Pre-Test Diagnostics

6. Pre-Test Diagnostics completes and **Run Test** becomes available.
7. Lift the weight evenly with both forks.
8. Select **Run Test**.




Figure 6-6. Single Weight Accuracy Test Execution

9. **Testing...** displays while the test occurs.




Figure 6-7. Single Weight Accuracy Test In Progress

10. The test completes and the results display ([Section 6.3.1 on page 41](#)).

6.3.1 Single Weight Accuracy Test Result Examples




Test Result	Example
Pass	 <p>Scale Test - Single Weight</p> <p>This checks the accuracy of both forks with an evenly placed test weight. Remove weights from the forks, level the forks and then select the Confirm button. Place a known weight evenly on both forks, enter the weight amount, and then press the Run Test button.</p> <p>Weight: <input type="text" value="1000"/></p> <p>Single Weight Check Status: PASSED</p> <p>The weight of 1000 lb was within the range of +/- 1.05%. Load Cell 1 is Healthy. Load Cell 2 is Healthy.</p> <p>CONFIRM RUN TEST</p> <p>Next Test Prev. Test Skip Home</p>
Fail	<p>The test failed for two reasons:</p> <ul style="list-style-type: none"> • The measured weight is greater than the configured weight by $\pm 1.05\%$ • The pre-test weight (when the scale must be empty) was greater than 5 lb.  <p>Scale Test - Single Weight</p> <p>This checks the accuracy of both forks with an evenly placed test weight. Remove weights from the forks, level the forks and then select the Confirm button. Place a known weight evenly on both forks, enter the weight amount, and then press the Run Test button.</p> <p>Weight: <input type="text" value="1000"/></p> <p>Scale Status: Single Weight Check FAILED</p> <p>The weight of 1155 lb is not within the range of +/- 1.05% (Range is 950 lb to 1050 lb.). Load Cell 1 is Healthy. Load Cell 2 is Healthy. The pre-test weight was too heavy. (45 lb > 5 lb)</p> <p>CONFIRM RUN TEST</p> <p>Next Test Prev. Test Skip Home</p>

Table 6-4. Single Weight Test Result Examples

6.4 Corner Weight Accuracy Test

Corner Weight Accuracy test involves configuring a weight value and testing it against a known weight measured in four different positions on the forks. The test passes when the configured weight value is measured at $\pm 1.05\%$ compared to the known weight at each position. This test may discover issues in either fork or to the position measurements were made.

1. Select  from the Scale Test Home page.
2. Remove weight and then level the forks.
3. Enter the weight of the test weight into the **Weight** field.
4. Select **Confirm**.




Figure 6-8. Corner Weight Accuracy Test Configuration

5. Pre-Test Diagnostics processes.




Figure 6-9. Gathering Pre-Test Diagnostics

6. Pre-Test Diagnostics completes and **Run Test** becomes available.
7. Position the test weight in the location indicated by the Corner Weight Test.
8. Lift the test weight.
9. Select **Run Test**.




Figure 6-10. Corner Weight Accuracy Test Execution

10. **Testing...** displays while the system processes the weight.




Figure 6-11. Corner Weight Accuracy Test In Progress

11. The display updates with the next position identified.
12. Lower the test weight.
13. Repeat [Step 7](#) through [Step 12](#) for positions B through D.
14. The test completes and the results display ([Section 6.4.1 on page 44](#)).

6.4.1 Corner Weight Accuracy Test Result Examples



NOTE: View Log Files (see [Section 6.7 on page 53](#)) for detailed weight measurement results in each position.

Test Result	Example
<p>Pass</p>	<p>Scale Test - Corner Weight</p> <p>This checks the accuracy of each fork corner with a test weight. Remove weights from the forks, level the forks and then select the Confirm button. Place the known test weight at the first fork position, enter the weight amount, and then press the Run Test button. Repeat for the remaining positions.</p> <p>Weight: <input type="text" value="1000"/></p> <p>Corner Weight Check Status: PASSED</p> <p>The weight was within the range of +/- 1.05% for all 4 corners. Load Cell 1 is Healthy. Load Cell 2 is Healthy. Corners A and B were 1000 and 1010. The values are good. Within 5 lbs. Corners C and D were 1000 and 1010. The values are good. Within 5 lbs.</p> <p>CONFIRM RUN TEST</p> <p>Next Test Prev. Test Skip Home</p>
<p>Fail</p>	<p>The following example suggests load cells are not functioning on the left side. This could be result of loose cables or a faulty load cell. In addition debris, binding or damage caused to the left side of scale flexure can cause issues to the weight measurement on left side.</p> <p>Scale Test - Corner Weight</p> <p>This checks the accuracy of each fork corner with a test weight. Remove weights from the forks, level the forks and then select the Confirm button. Place the known test weight at the first fork position, enter the weight amount, and then press the Run Test button. Repeat for the remaining positions.</p> <p>Weight: <input type="text" value="1000"/></p> <p>Scale Status: Corner Weight Check FAILED</p> <p>The live weight is not within the range of +/- 1.05% for all 4 corners. The following corners failed: C, D. Load Cell 1 is Healthy. Load Cell 2 is Healthy. The pre-test weight was too heavy. (995 lb > 5 lb)</p> <p>CONFIRM RUN TEST</p> <p>Next Test Prev. Test Skip Home</p>


Table 6-5. Corner Weight Test Result Examples

6.5 Fork Angle Test

The Fork Angle Test checks pitch and roll of the forklift and provides three possible results: Pass, Warning or Failed. The following table lists test criteria:

Pitch Test		Roll Test	
Test Result	Result Criteria	Test Result	Result Criteria
Pass	<ul style="list-style-type: none"> • ± 2 degrees. 	Pass	<ul style="list-style-type: none"> • ± 2 degrees.
Warning	<ul style="list-style-type: none"> • -2 to -7 degrees • 2 to 7 degrees 	Warning	<ul style="list-style-type: none"> • -2 to -3 degrees • 2 to 3 degrees
Failed	<ul style="list-style-type: none"> • -7 degrees or less • 7 degrees or greater 	Failed	<ul style="list-style-type: none"> • -3 degrees or less. • 3 degrees or greater

Table 6-6. Fork Angle Test Criteria

1. Select  from the Scale Test Home page.
2. Level the forks and then select **Confirm**.




Figure 6-12. Fork Angle Test Confirmation

3. Pre-Test Diagnostics processes.




Figure 6-13. Gathering Pre-Test Diagnostics

4. Pre-Test Diagnostics completes and **Run Test** becomes available.
5. Select **Run Test**.




Figure 6-14. Fork Angle Test Execution

6. **Testing...** displays while the test occurs.




Figure 6-15. Fork Angle Test In Progress

7. The test completes and the results display ([Section 6.5.1 on page 47](#)).

6.5.1 Fork Angle Test Result Examples

 **NOTE:** See [Table 6-6 on page 45](#) for Fork Angle Test criteria.




Test Result	Example
Pass	
Warning	<p>A Warning issued due to pitch exceeding 2 degrees while remaining less than 7 degrees.</p> 
Fail	<p>The test failed due to pitch exceeding 7 degrees.</p> 

Table 6-7. Fork Angle Test Result Examples

6.6 Scale Health Test

Scale Health Test performs three groups of tests to check for a variety of potential issues:

- Pre-Test Diagnostics (Section 6.2 on page 38)
- Test Data (Table 6-8 on page 48)
- Additional Test Data (Table 6-9 on page 48)



NOTE: The overall test result (Passed or Failed) is displayed at the completion of the Scale Health Test. Individual test results are displayed in Log Files (Section 6.7 on page 53).

Test Data

Scale Health Test performs several to checks to identify potential issues with a scale.

Test	Description
Scale Weight	Displays the current weight measured by the scale. In addition, displays weight failure or error states: <ul style="list-style-type: none"> • Invalid: Invalid weight display • ~~~~~: Pitch or roll exceeded tolerances • ^^^^^^^: Load cell overload • _____: Load cell underload
Result	Displays the test result. Results: PASSED, FAILED
Result Description	A brief description of health test results. Common Result Descriptions include: <ul style="list-style-type: none"> • All Health Checks Passed. • Overload/Underload Status Error • Fork Level Status Error
Load Cell 1 mV	Displays raw mV from load cell 1.
Load Cell 2 mV	Displays raw mV from load cell 2.
Snapshot is Valid	Displays if streaming snapshot is valid. Results: True, False
Underload Status	Displays underload test status.
Overload Status	Displays overload test status.
Power Supply Status	Displays power supply test results.
Load Cell 1 Status	Displays raw mV from load cell 1.
Load Cell 2 Status	Displays raw mV from load cell 2.

Table 6-8. Scale Health Test - Test Data Descriptions

Additional Test Data

Additional Test Data include more data items as well as data items that were previously tested. Repeated data items are included to retest items at different intervals.

Test	Description
Scale Weight	Displays the current weight measured by the scale. In addition, displays weight failure or error states: <ul style="list-style-type: none"> • Invalid: Invalid weight display • ~~~~~: Pitch or roll exceeded tolerances • ^^^^^^^: Load cell overload • _____: Load cell underload
Max Load Cell 1:	Maximum theoretical mV load of load cell 1. NOTE: Does not display when scale weight it in an error state (for example, ^^^^^^^ or _____).
Max Load Cell 2:	Maximum theoretical mV load of load cell 2. NOTE: Does not display when scale weight it in an error state (for example, ^^^^^^^ or _____).
Load Cell 1 mV	Displays raw mV from load cell 1.

Table 6-9. Scale Health Test - Additional Test Data Descriptions

Test	Description
Load Cell 2 mV	Displays raw mV from load cell 2.
Pitch Angle	Displays the calculated pitch angle in degrees. For test criteria see, Section 6.5 on page 45 .
Roll Angle	Displays the calculated roll angle in degrees. For test criteria see, Section 6.5 on page 45 .
UID	Displays the Unit ID. This value is configured from the factory as the forklift serial number.
User Mode	Displays the user mode number from junction box.

Table 6-9. Scale Health Test - Additional Test Data Descriptions (Continued)

6.6.1 Performing Scale Health Test

1. Select  from the Scale Test Home page.
2. Level the forks and then select **Confirm**.




Figure 6-16. Scale Status Test Confirmation

3. Pre-Test Diagnostics processes.




Figure 6-17. Gathering Pre-Test Diagnostics

4. Pre-Test Diagnostics completes and **Run Test** becomes available.
5. Select **Run Test**.




Figure 6-18. Scale Status Test Activation

6. **Testing...** displays while the test occurs.




Figure 6-19. Scale Status Test In Progress

7. The test completes and the results display ([Section 6.6.2 on page 51](#)).

6.6.2 Scale Status Test Result Examples



Test Result	Example
Passed	
Failed	<p>Failed due unacceptable load cell mV value (exceeded 7 mV).</p> 

Table 6-10. Scale Status Test Result Examples

6.6.3 Troubleshooting Scale Status Test Failed Results


Message	Actions
Load Cell Does Not Look Healthy.	Verify load cell is functioning correctly, load cell connection and perform load cell resistance test.
The Scale Data is in invalid.	Verify load cell connection,
The Weight Data is invalid	Verify the setup switch is not enabled. Verify load cell is functioning correctly, load cell connection and perform load cell resistance test. Verify if the load cell is experiencing overload or underload. If load cells appear to be function correctly, recalibrate the scale.
Diagnostic Data Error Flag	Verify if Diagnostic Data errors are present (underload Error, overload error or Power Supply error). If present, Verify load cell is functioning correctly, load cell connection and perform load cell resistance test and calibration.
Load Cell Status (mV Range)	Load cell output inconsistent readings with defined load. Verify load cell condition, connection or overload/underload stops adjustment. NOTE: Load cell voltage range is considered faulty when under 0 or over 7.5 mV.
Overload Status	The measured weight indication exceeds capacity limit. If no load status error is present, than overload status condition is potentially a calibration issue. Perform Single Weight or Corner Test, if no load cell status error occurs verify calibration.
Pitch and Roll Angles	Exceeds Pitch and Roll criteria ranges (Section 6.4 on page 42). Check junction box is securely mounted and verify calibration.
Power Supply Status	Verify power source supplying power to junction box is operating correctly.

Table 6-11. Scale Health Test Common Failure Messages

6.7 Scale Test - Log Files

Test Logs provide a history of tests results sorted from oldest to newest. Each test is added as an entry and provides details why a test passed or failed.

6.7.1 Viewing Log Files

1. Select  from the Scale Test Home page.
2. The Log Files display.
3. Use the scroll bar to navigate to the desired entry.




Figure 6-20. Scale Test Logs



NOTE: The log file may not load if there are two or Scale Test instances opened. If Error reading log file displays, close any additional Scale Test windows and try opening the log file again.

6.7.2 Saving Log Files

The Log Files may be saved as a text file (*.txt) for review outside of VIRTUI³.

1. Access Log Files.
2. Select the **Save** button.




Figure 6-21. Scale Test Logs Save Button

3. Save As window displays.
4. Navigate to desired file location.
5. Enter desired file name and then select **Save**.




Figure 6-22. Save As Window

6. Open the saved test log file in a text editor such as Windows Notepad[®] to view.




Figure 6-23. Test Log Text File

6.7.3 Single Weight Accuracy Test Entry Examples

<p>12/09/2024 05:15:30 PM: Single Weight Test PRE-TEST DATA Scale Weight: 0 lb Load Cell 1 mV: 0.395618 mV Load Cell 2 mV: 0.396505 mV The mV for cell 1 is within the configured min and max. of 0 and 7.5. The mV for cell 2 is within the configured min and max. of 0 and 7.5. Pitch Angle: 0.7 degrees Roll Angle: -0.1 degrees UID: 174570 User Mode: 600 TEST DATA Target Weight: 500 lb Actual Weight: 495 lb The mV for cell 1 is within the configured min and max. of 0 and 7.5. The mV for cell 2 is within the configured min and max. of 0 and 7.5. Result: PASSED Result Description: The weight of 495 lb was within the range of +/- 1.05%. Load Cell 1 is Healthy. Load Cell 2 is Healthy. ADDITIONAL TEST DATA Scale Weight: 495 lb Max Load Cell 1: 1.137747 mV Max Load Cell 2: 1.137747 mV Load Cell 1 mV: 1.117478 mV Load Cell 2 mV: 0.452008 mV Pitch Angle: 0.8 degrees Roll Angle: -0.1 degrees UID: 174570 User Mode: 600</p>	<p>12/09/2024 05:16:17 PM: Single Weight Test PRE-TEST DATA Scale Weight: 985 lb Load Cell 1 mV: 1.894527 mV Load Cell 2 mV: 0.451786 mV The mV for cell 1 is within the configured min and max. of 0 and 7.5. The mV for cell 2 is within the configured min and max. of 0 and 7.5. Pitch Angle: 0.8 degrees Roll Angle: -0.1 degrees UID: 174570 User Mode: 600 TEST DATA Target Weight: 500 lb Actual Weight: 985 lb The mV for cell 1 is within the configured min and max. of 0 and 7.5. The mV for cell 2 is within the configured min and max. of 0 and 7.5. Result: FAILED Result Description: The weight of 985 lb is not within the range of +/- 1.05% (Range is 475 lb to 525 lb.). Load Cell 1 is Too Low. (1.89 mV, minimum is 1.8945 mV) Load Cell 2 is Too Low. (0.45 mV, minimum is 0.4518 mV) The pre-test weight was too heavy. (985 lb > 5 lb) ADDITIONAL TEST DATA Scale Weight: 985 lb Max Load Cell 1: 3.371289 mV Max Load Cell 2: 3.371289 mV Load Cell 1 mV: 1.894462 mV Load Cell 2 mV: 0.451768 mV Pitch Angle: 0.8 degrees Roll Angle: -0.1 degrees UID: 174570 User Mode: 600</p>
---	--

Figure 6-24. Single Weight Test Pass and Fail Examples

6.7.4 Corner Weight Accuracy Test Entry Examples

<p>12/09/2024 01:55:55 PM: Corner Weight Test PRE-TEST DATA Scale Weight: 0 lb Load Cell 1 mV: 0.395415 mV Load Cell 2 mV: 0.396274 mV The mV for cell 1 is within the configured min and max. of 0 and 7.5. The mV for cell 2 is within the configured min and max. of 0 and 7.5. Pitch Angle: 0.6 degrees Roll Angle: -0.1 degrees UID: 174570 User Mode: 600 TEST DATA Target Weight: 1000 lb Actual Weight Right Back (A): 1010 lb Actual Weight Right Front (B): 1010 lb Actual Weight Left Back (C): 1010 lb Actual Weight Left Front (D): 1010 lb The mV for cell 1 is within the configured min and max. of 0 and 7.5. The mV for cell 2 is within the configured min and max. of 0 and 7.5. Result: PASSED Result Description: The weight was within the range of +/- 1.05% for all 4 corners. Load Cell 1 is Healthy. Load Cell 2 is Healthy. Corners A and B were 1010 and 1010. The values are good. Within 5 lbs. Corners C and D were 1010 and 1010. The values are good. Within 5 lbs. ADDITIONAL TEST DATA Scale Weight: 1010 lb Max Load Cell 1: 1.909658 mV Max Load Cell 2: 1.909658 mV Load Cell 1 mV: 1.269947 mV Load Cell 2 mV: 1.097227 mV Pitch Angle: 0.6 degrees Roll Angle: -0.1 degrees UID: 174570 User Mode: 600</p>	<p>12/09/2024 01:57:51 PM: Corner Weight Test PRE-TEST DATA Scale Weight: 995 lb Load Cell 1 mV: 0.863404 mV Load Cell 2 mV: 1.470265 mV The mV for cell 1 is within the configured min and max. of 0 and 7.5. The mV for cell 2 is within the configured min and max. of 0 and 7.5. Pitch Angle: 0.6 degrees Roll Angle: -0.1 degrees UID: 174570 User Mode: 600 TEST DATA Target Weight: 1000 lb Actual Weight Right Back (A): 995 lb Actual Weight Right Front (B): 995 lb Actual Weight Left Back (C): 1225 lb Actual Weight Left Front (D): 1225 lb The mV for cell 1 is within the configured min and max. of 0 and 7.5. The mV for cell 2 is within the configured min and max. of 0 and 7.5. Result: FAILED Result Description: The live weight is not within the range of +/- 1.05% for all 4 corners. The following corners failed: C D. Load Cell 1 is Healthy. Load Cell 2 is Too Low. (1.47 mV, minimum is 1.4703 mV) The pre-test weight was too heavy. (995 lb > 5 lb) ADDITIONAL TEST DATA Scale Weight: 1225 lb Max Load Cell 1: 2.699986 mV Max Load Cell 2: 2.699986 mV Load Cell 1 mV: 1.230286 mV Load Cell 2 mV: 1.469369 mV Pitch Angle: 0.6 degrees Roll Angle: -0.1 degrees UID: 174570 User Mode: 600</p>
--	---

Figure 6-25. Corner Weight Test Pass and Fail Examples

6.7.5 Fork Angle Test Entry Examples

<p>12/09/2024 05:06:46 PM: Angle Test PRE-TEST DATA Scale Weight: 0 lb Load Cell 1 mV: 0.395563 mV Load Cell 2 mV: 0.396607 mV The mV for cell 1 is within the configured min and max. of 0 and 7.5. The mV for cell 2 is within the configured min and max. of 0 and 7.5. Pitch Angle: 0.6 degrees Roll Angle: -0.1 degrees UID: 174570 User Mode: 600 TEST DATA Scale Weight: 0 lb Result: PASSED Result Description: The pitch angle of 0.6 is within the range of +/- 7 degrees. The roll angle of -0.1 is within the range of +/- 3 degrees. ADDITIONAL TEST DATA Scale Weight: 0 lb Max Load Cell 1: 0.395563 mV Max Load Cell 2: 0.395563 mV Load Cell 1 mV: 0.395590 mV Load Cell 2 mV: 0.396552 mV Pitch Angle: 0.6 degrees Roll Angle: -0.1 degrees UID: 174570 User Mode: 600</p>	<p>12/09/2024 05:08:16 PM: Angle Test PRE-TEST DATA Scale Weight: 0 lb Load Cell 1 mV: 0.395563 mV Load Cell 2 mV: 0.396607 mV The mV for cell 1 is within the configured min and max. of 0 and 7.5. The mV for cell 2 is within the configured min and max. of 0 and 7.5. Pitch Angle: 0.6 degrees Roll Angle: -0.1 degrees UID: 174570 User Mode: 600 TEST DATA Scale Weight: 0 lb Result: WARNING Result Description: The pitch angle of -6.4 is outside the range of +/- 2 degrees. The roll angle of -0.3 is within the range of +/- 3 degrees. ADDITIONAL TEST DATA Scale Weight: 0 lb Max Load Cell 1: 0.395563 mV Max Load Cell 2: 0.395563 mV Load Cell 1 mV: 0.395553 mV Load Cell 2 mV: 0.396441 mV Pitch Angle: -6.4 degrees Roll Angle: -0.3 degrees UID: 174570 User Mode: 600</p>
--	--

Figure 6-26. Angle Test Pass and Warning Examples

```
12/09/2024 05:08:42 PM:
Angle Test
PRE-TEST DATA
Scale Weight: 0 lb
Load Cell 1 mV: 0.395563 mV
Load Cell 2 mV: 0.396607 mV
The mV for cell 1 is within the configured min and max. of 0 and 7.5.
The mV for cell 2 is within the configured min and max. of 0 and 7.5.
Pitch Angle: 0.6 degrees
Roll Angle: -0.1 degrees
UID: 174570
User Mode: 600
TEST DATA
Scale Weight: ~~~~~ lb
Result: FAILED
Result Description: The pitch angle of -7.2 is outside the range of
+/- 7 degrees.
The roll angle of -0.3 is within the range of +/- 3 degrees.
ADDITIONAL TEST DATA
Scale Weight: ~~~~~
Load Cell 1 mV: 0.395637 mV
Load Cell 2 mV: 0.396404 mV
Pitch Angle: -7.2 degrees
Roll Angle: -0.3 degrees
UID: 174570
User Mode: 600
```

Figure 6-27. Angle Test Fail Example

6.7.6 Health Test Entry Examples

<p>12/09/2024 05:09:43 PM: Scale Health Test PRE-TEST DATA Scale Weight: 0 lb Load Cell 1 mV: 0.395738 mV Load Cell 2 mV: 0.396515 mV The mV for cell 1 is within the configured min and max. of 0 and 7.5. The mV for cell 2 is within the configured min and max. of 0 and 7.5. Pitch Angle: 0.6 degrees Roll Angle: -0.1 degrees UID: 174570 User Mode: 600 TEST DATA Scale Weight: 0 lb Result: PASSED Result Description: All Health Checks Passed. Load Cell 1: 0.40 mV Load Cell 2: 0.40 mV Indicator Data Error: No Error Snapshot is Valid: True Underload Status: OK Overload Status: OK Power Supply Status: OK Load Cell 1 Status: 0.395710 Load Cell 2 Status: 0.396487 ADDITIONAL TEST DATA Scale Weight: 0 lb Max Load Cell 1: 0.395738 mV Max Load Cell 2: 0.395738 mV Load Cell 1 mV: 0.395710 mV Load Cell 2 mV: 0.396487 mV Pitch Angle: 0.6 degrees Roll Angle: -0.1 degrees UID: 174570 User Mode: 600</p>	<p>12/09/2024 05:19:31 PM: Scale Health Test PRE-TEST DATA Scale Weight: ^^^^^^^ lb Load Cell 1 mV: 9.866320 mV Load Cell 2 mV: 9.648698 mV The mV for cell 1 is not within the configured min and max. of 0 and 7.5. The mV for cell 2 is not within the configured min and max. of 0 and 7.5. Pitch Angle: 0.7 degrees Roll Angle: -0.1 degrees UID: 174570 User Mode: 600 TEST DATA Scale Weight: ^^^^^^^ lb Result: FAILED Result Description: Overload Status Error Load Cell 1 Does Not Look Healthy Load Cell 2 Does Not Look Healthy Load Cell 1: 9.87 mV Load Cell 2: 9.65 mV Indicator Data Error: No Error Snapshot is Valid: True Underload Status: OK Overload Status: OK Power Supply Status: OK Load Cell 1 Status: 9.866310 Load Cell 2 Status: 9.648716 ADDITIONAL TEST DATA Scale Weight: ^^^^^^^ lb Load Cell 1 mV: 9.866310 mV Load Cell 2 mV: 9.648716 mV Pitch Angle: 0.7 degrees Roll Angle: -0.1 degrees UID: 174570 User Mode: 600</p>
--	--

Figure 6-28. Status Health Test Pass and Fail Examples

7.0 Appendix

7.1 Error Messages

The following are common error messages that may display occur.

7.1.1 Invalid Data Errors

Failed Connections

Invalid displays in the live weight display when the indicator fails to connect or parse data.



Figure 7-1. Invalid Data

7.1.2 Load Cell Overload

The live weight displays indicates when a load cell is overloaded. Typically occurs when gross value exceeds overload limit. Check configuration or signal input level.




Figure 7-2. Cell Overload Warning

7.1.3 Load Cell Underload

The live weight displays indicates when a load cell is underloaded. Typically occurs when a gross value exceeds underload limit. Check configuration or signal input level.




Figure 7-3. Cell Overload Warning

7.1.4 Angle Invalid

Pitch or roll values exceeded operating tolerances. Move forklift onto level ground and try again.




Figure 7-4. Invalid Angle

7.2 Junction Box Firmware Update

The junction box firmware update tool is a stand alone application that is launched via the program files menu. Prior to using the firmware update tool, connect to the comm port **COM-None** via the Scale Communications menu. Close the VIRTU³ Client to release the junction box communication port. Follow the instructions in the application.




Figure 7-5. Firmware Update Screen



© Rice Lake Weighing Systems Content subject to change without notice.

230 W. Coleman St. • Rice Lake, WI 54868 • USA USA: 800-472-6703 • International: +1-715-234-9171