



RL2200 Load Cell Mounting Kit

Mild Steel

Part Number/Price

Ref#	Part#	Description	Price
	49596	Installation manual	Consult
Rated Capacity: 2,500 lb and 10,000 lb			
1	45562	Top-plate	Consult
2	45567	Shoulder screw	Consult
3	45569	Load cell bolts	Consult
4	76654	Load cell, RL2200 - 2,500 lb	Consult
4	45708	Load cell, RL2200 - 5,000 lb	Consult
4	45709	Load cell, RL2200 - 10,000 lb	Consult
5	45564	Bearing, upper insert	Consult
6	45556	Base plate	Consult
7	45565	Rocker pin	Consult
8	50861	Dust boot	Consult
9	14949	Set screws	Consult
Rated Capacity: 25,000 lb and 50,000 lb			
1	45547	Top-plate	Consult
2	45553	Shoulder screw	Consult
3	45554	Load cell bolts	Consult
4	45710	Load cell, RL2200 - 25,000 lb	Consult
4	45711	Load cell, RL2200 - 50,000 lb	Consult
5	45549	Bearing, upper insert	Consult
6	45541	Base plate	Consult
7	45550	Rocker pin	Consult
8	45566	Dust boot	Consult
9	45696	Set screws	Consult

(See Diagram RL2200-A)



RL2200-A