

RS-130 (Non-backlight)

Main Unit



Part Number/Price

Ref#	Part#	Description	Price
1	85709	Keypad cover and switch panel overlay	Consult
—	85711	In use dust cover	Consult
2	85712	Front display-overlay (operator)	Consult
3	85713	Rear display-overlay (customer)	Consult
4	85714	Base plate (molded plastic)	Consult
5	85715	Upper cover (molded plastic)	Consult
6	50624	Load cell, 20 kg	Consult
7	85716	Foot	Consult
—	15438	Power cord	Consult
—	85718	Power switch (on/off type)	Consult
9	85723	Rear-display PCB	Consult
10	87711	Main PCB (with keyboard tare function)	Consult
—	92714	Main PCB (with RS-232C output for PN89483)	Consult
—	88574	Plastic platter	Consult
—	88575	Stainless steel platter	Consult
—	115263	Sealing pin	Consult
—	115927	Level bubble	Consult
11	85710	Rechargeable battery	Consult

(Diagram RS-130-A)

RS-130 (Non-backlight) Main Unit




Diagram RS-130-A Bench

Parts not listed are no longer available. Some parts listed may not be available.

An ISO 9001 registered company ©2021 Rice Lake Weighing Systems 09/21 Prices and specifications subject to change without notice. Visit ricelake.com for current prices.