

RS-130/RS-160

Pole

Non-Printing Scales



RS-130

Part Number/Price

Ref #	Part #	Description	Price
1	85715	Upper plastic cover	Consult
2	170025	Rear overlay, RS-130/RS-160	Consult
4	170013	Keyboard	Consult
5	170018	Operator display overlay RS-130	Consult
	170019	Operator display overlay RS-160	Consult
6	193898	Main board, 30 lb	Consult
	193899	Main board, 60 lb	Consult
7	171656	Upper aluminum structure	Consult
8	50624	Load cell, 30 lb	Consult
	132268	Load cell, 60 lb	Consult
9	171657	Base aluminum structure	Consult
10	85710	Rechargeable battery	Consult
11	85714	Base plastic plate	Consult
12	85718	Power switch	Consult
13	85716	Rubber foot	Consult
14	170023	Front pole display overlay, RS-130	Consult
	170024	Front pole display overlay, RS-160	Consult
15	170012	Rear pole display, PCB 30 lb	Consult
	171699	Rear pole display, PCB 60 lb	Consult
16	170022	Rear display cover, operator side	Consult
17	171654	Pole plastic cover, customer side	Consult
18	171659	Stainless steel tube	Consult
19	171658	Indicator plastic tube support	Consult
20	171655	Pole plastic cover, operator side	Consult
21	178072	Transformer	Consult
	175421	AC base seat	Consult
	15438	Power cord	Consult
	85711	Dust cover	Consult
	88574	Plastic platter	Consult
	88575	Stainless steel cover for the platter	Consult
	178058	Backlight kit	Consult
	178057	CPU, Eprom RS-160	Consult
	170262	CPU, chip for main board	Consult
	115263	Plastic sealing pin	Consult
	115927	Level bubble	Consult

RS-130/RS-160

Pole

Non-Printing Scales

