

Display, External Mount

Tracer Airline Baggage Scale Display

Part Number/Price

Ref#	Part#	Description	Price
	104872	Cable assembly, remote display	Consult
1	93215	Lens, remote display red	Consult
2	108731	Enclosure housing, low	Consult
3	104292	Spacer, brass 0.25 diameter	Consult
4	93561	Board, printed circuit	Consult
5	108735	Standoff, female to female 8-32NC	Consult
6	108732	Back plate, low profile	Consult
7	108733	Screw, MACH 8-32NC x 3/16	Consult
9	15134	Washer, lock no. 8 type A	Consult
10	108934	Nut, wing 8-32	Consult

(See Diagram A)




Diagram A

Remote Displays

Display, Panel Mount RD-1 and RD-2

Tracer Airline Baggage Scale Display

Part Number/Price

Ref#	Part#	Description	Price
RD-1			
1	93559	Front panel assembly, remote	Consult
2	93215	Lens, remote display red	Consult
3	104292	Spacer, brass 0.25 diameter	Consult
4	93561	Board, printed circuit	Consult
5	14626	Nut, kep 8-32NC HEX	Consult
6	93213	Enclosure, back cover	Consult
8	15134	Washer, lock no. 8 type A	Consult
9	108934	Nut, wing 8-32	Consult
	104872	Cable assembly, remote display	Consult
RD-2			
1	167183	Front panel assembly	Consult
2	166485	Remote display lens	Consult
4	163879	Board, printed circuit	Consult
6	164384	Back cover enclosure	Consult
	104872	Cable assembly	Consult

(See Diagram B)



Diagram B