

880 Performance™ Series Panel Mount Sealing Kit

In certain Legal for Trade applications, it may be necessary to seal the 880 indicator to restrict access to the setup switch.



Manuals and additional resources are available from the Rice Lake Weighing Systems website at www.ricelake.com

Warranty information can be found on the website at www.ricelake.com/warranties

880 Panel Mount Sealing Kit (PN 153660)

Part No.	Part	Qty
158402	Load Cell Locking Clip	1
158207	6-32 x 1/4" Fillister Head Screw	4

Table 1. Optional Sealing Kit Parts List

1. Remove the screw highlighted in Figure 1.




Figure 1. Bottom Plate Screw

2. Slide the load cell sealing clip over the load cell connector.




Figure 2. Secure Load Cell Locking Clip

3. Replace the removed screw with a fillister head screw found in the sealing kit.
4. Install another fillister screw into the setup switch hole.




Figure 3. Setup and Configuration Switch Hole

5. Replace the two screws on the DIN rail bracket with the remaining two fillister screws.
 - If required, a provision of fillister screws are provided to properly seal the unit.




Figure 4. DIN Rail Bracket Screw Locations

6. Thread a sealing wire through the four installed fillister screws and the installed load cell locking clip.



Figure 5. Install Sealing Wire



© Rice Lake Weighing Systems Specifications subject to change without notice.
Rice Lake Weighing Systems is an ISO 9001 registered company.

230 W. Coleman St. • Rice Lake, WI 54868 • USA
U.S. 800-472-6703 • Canada/Mexico 800-321-6703 • International 715-234-9171 • Europe +31 (0)26 472 1319