User-Definable Operator Card

- Display simple instructions
- Display service contact information
- Display multilingual instructions
- Post accuracy requirements

These are just a few examples of how this card can benefit your process. Simply print information on the reverse side of this card and insert it under the overlay of your DC-100, or use the preprinted instruction cards provided.

RICE LAKE
WEIGHING SYSTEMS
To be the best by every measure®

DIGI®

82312 03/11

Sample and Count

1. Press **REZERO**.

2. Place empty bin on scale and press **TARE**.

3. Place a 10 piece sample in bin*. Press **PIECES**.
   If ten pieces are not enough for scale to get an accurate sample, scale prompts you to add more pieces. Add these pieces and press PIECES again.

4. Add remaining pieces to be counted into bin.

*Add the entire 10 piece sample at one time, instead of adding them one or two at a time.

82312 03/11

Sample, Count and Print Label

1. Press **REZERO**.

2. Place empty bin on scale and press **TARE**.

3. Place a 10 piece sample in bin*. Press **PIECES**.
   If 10 pieces are not enough for scale to get an accurate sample, scale prompts you to add more pieces. Add these pieces and press PIECES again.

4. Add remaining pieces to be counted into bin.

5. Press **PRINT**.

*Add the entire 10 pieces sample at one time, instead of adding them on or two at a time.

82312 03/11

_____

_____

_____

_____

_____

_____

Scan ID Bar Code, Count and Print Label

1. With the scale turned on and in weighing mode, enter the ID Code by scanning the ID bar code.

2. Press **REZERO** to zero the weight display

3. Place the product on the platter.

4. Press **PRINT** to issue a receipt or label.

Negative Counting

1. Place full container on scale. Press **TARE**.

2. Remove a 10 piece sample from container and press **PIECES**. After the unit weight has been calculated, return the 10 piece sample to the container.

3. *For a total count of a full container:*
    Key in known tare weight and press **TARE**. Total count is displayed.

    For a total count from a full container:
    Remove parts needed. Amount removed is displayed. If label is required, press **+** and then **TARE**.