

Ishida OMNi-4000 Auto Wrapper Daily Cleanup Procedures

1. Turn off heater.
2. Turn off main power.
3. Wipe down with lightly damp cloth:
 - Wrapper body
 - Infeed conveyor
 - Touch screen or replace plastic cover piece.
4. Empty Infeed catch tray.
5. Cover wrapper with wash down cover.
6. Wash down room as normal.
7. Remove wash down cover from wrapper.
8. Turn on main power

IMPORTANT: Morning crew must turn on heater
15 minutes before wrapping.

Ishida OMNi-4000 Auto-Envoltorio Procedimientos de Limpieza Diaria

1. Apagar el calentador.
2. Apagar la alimentación eléctrica principal.
3. Limpiar o enjuagar con un trapo un poco húmedo:
 - El cuerpo del envoltorio
 - La cinta transportadora de ingreso
 - La pantalla táctil (o reemplacen la cubierta plástica)
4. Vaciar la bandeja de captura de ingreso.
5. Cubrir el envoltorio con una cubierta a prueba de agua.
6. Lavar el cuarto como normal.
7. Remover la cubierta impermeable del envoltorio.
8. Prender la alimentación eléctrica principal.

IMPORTANTE: El personal de la mañana tiene que prender el calentador 15 minutos antes de comenzar al envolver.

이시다 OMNI-4000 자동 포장기 일일 청소 절차

1. 히터를 꺼 주십시오.
2. 전원 스위치를 꺼 주십시오.
3. 젖은 천으로 가볍게 구석구석 닦아 주십시오.
 - 포장기 몸체
 - 공급벨트 (계량부 컨베이어)
 - 터치 스크린 또는 플라스틱 커버 교체부분
4. 트레이 내를 깨끗이 비워 주십시오 .
5. 포장기 커버를 씻어 주십시오
6. 평상시처럼 현장을 깨끗이 해주십시오
7. 포장기에서 커버를 제거 해주십시오
8. 전원 스위치를 켜 주십시오.

중요 : 포장기 가동전에 반드시 15 분 동안 히터를 켜주시고 사용하기 바랍니다.